



369/500/600 Series Temporary Revision

Manual: CSP-HMI-2, Handbook of Maintenance Instructions
Models: 369D/E/FF – 500/600N Helicopters
Issued: 31 October 1990
Revision 39: 11 April 2007
TR 07-001: 09 July 2007

FILING INSTRUCTIONS:

- (1) Before inserting this change, ensure the manual is current.
Check the existing List of Effective Pages in the manual to ensure all prior revisions are inserted.
(Do not insert this revision if prior revisions are not inserted).
- (2) Insert this page in front of Page A of the List of Effective Pages (LOEP).
- (3) Incorporate this change by removing old pages and inserting new pages as indicated below.

Temporary Revision Number / Date	Section	Page	Page Revision
*TR 07-001 / 09 July 2007	05-20-00	3 and 4	TR 07-001
	53	i thru vi	TR 07-001
	53-50-30	205 thru 212	TR 07-001

* Signifies latest Temporary Revision.

This Page Intentionally Left Blank

Table 1. 100-Hour or Annual Inspection (Cont.)

Registration No. _____		Serial No. _____		
Helicopter Hours _____		Torque Events _____		
Model	Requirement		Chap/Sect	Initial
500/600N	<ul style="list-style-type: none"> * Thruster cones and tip cap (500N only) for damage and security. Inspect for wear between thruster cones and tailboom at points of contact. * Using a flashlight and 10X magnifying glass, inspect horizontal stabilizer mounting brackets for cracks (pay particular attention to the forward inboard legs) (Ref. Tailboom Inspection). * Using a bright flashlight, inspect fore and aft radii of the lower portion of the three upper slot bridges for cracks, illuminate area under the flap. The flap may be raised slightly, using finger pressure only, to aid in checking this area (Ref. Tailboom Inspection). * Using a bright light and 10X magnifying glass, inspect the four tailboom attachment lugs for cracks and fiber damage. Pay particular attention to area on top of the lug from the radius block to 2 inches aft (Ref. Tailboom Inspection). * Tailboom closeout fairings for security of attachment hardware. Inspect for damage and chafing between closeout fairing and tailboom. 		53-40-30 53-50-30	
369D/E/FF	<p>Horizontal stabilizer for:</p> <ul style="list-style-type: none"> * Skin damage and loose rivets. * Tip plates for damage. Check for secure attachments (Ref. Horizontal Stabilizer and Tip Plates Inspection). 		53-50-10	
500/600N	<p>Horizontal stabilizer for:</p> <ul style="list-style-type: none"> * Skin damage and loose rivets. * Mounting fittings for cracks and security. * Stabilizer attach bolts for security. 		53	
369D/E/FF	<p>Vertical stabilizer for:</p> <ul style="list-style-type: none"> * Damage to leading and trailing edges and damaged stressed side panels (no repair of side panels permitted). * Mounting fittings for cracks and security. * Tail skid for obvious damage and security (Ref. Vertical Stabilizer Inspection). 		53-50-10	
500/600N	<p>Vertical stabilizers for:</p> <ul style="list-style-type: none"> * Damage to leading or trailing edges and damaged side panels. * Cracks in skin, no cracks permitted (pay particular attention to areas around mounting bolts). * Stabilizer attach bolts for security. * Stabilizer mount bushings for wear, security and correct installation. * Excess play in control linkage, bearings and security of attaching hardware. 		53	

Table 1. 100-Hour or Annual Inspection (Cont.)

Registration No. _____		Serial No. _____		
Helicopter Hours _____		Torque Events _____		
Model	Requirement		Chap/Sect	Initial
LANDING GEAR				
ALL	Landing gear skid tubes and fairings for: * Wear and damage in excess of permissible limits. * Upper fairing fillets for freedom of movement and general condition. * Strut attachment points for security and pivot (swivel) bearings for excessive play. * Landing gear dampers for correct extension, security of attachment and for signs of fluid leakage. Pivot bearings for excessive play. * Passenger steps for security and damage.		32	
369D/E/FF 500N	Remove landing gear fairing fillets and visually inspect landing gear strut assemblies for cracks and damage.			
369D/E/FF 500N	For aircraft 369D; 001 & subs, 369E; 0001 thru 0528, 369FF; 0001 thru 0114 and 500N; 001 thru 077: Remove plug button from inboard of fairing assembly. Using a bright light and 10X magnifying glass, inspect rivet hole in underside of strut for cracks. If crack is found, strut must be scrapped.			
CABIN				
ALL	Compartment heat and anti-icing valve controls for: * Easy and correct operation and rigging. * Heating system heat diffusers for security.		21	
ALL	* Seat belts for condition and security. * Inertia reels for condition and proper extension/retraction.		25	
ALL	Pilot/copilot controls for: * Wear, looseness and general condition of control rods and rod end bearings. * Quick-release pins for condition. * Cyclic, collective and anti-torque controls for free movement. * Cyclic trim actuators for security. * Collective torque tube, support bracket and bungee support bracket for evidence of cracks, gouges or other visible damage in attach lug and bungee support bracket attach areas; gaps between bracket and cradle cap of collective torque tube (use bright light and mirror). * N ₁ power controls for obvious damage. * Check for minimum cyclic friction adjustment (resistance to turning spring with fingers). * Flight control system one-way lock (Uniloc) for oil leakage, condition and security. Fluid reservoir 1/2 – 3/4 full; replenish if low.		67 76	

TABLE OF CONTENTS

Para/Figure/Table	Title	Page
53-00-00 Fuselage		A
Maintenance Practices		201
1. Fuselage – General		201
2. Stressed Sheet Metal Panels		201
3. Stressed Sheet Metal Panel Inspection		201
4. Non-Stressed Sheet Metal Panels		201
5. Negligible Damage Inspection		201
Table 201. Negligible Damage Inspection – Fuselage		202
Figure 201. Fuselage – Major Sections		203
Figure 202. Fuselage – Model 600N		204
53-10-00 Windshields and Aft Section Windows		A
Maintenance Practices		201
1. Windshields		201
2. Aft Section Windows		201
3. Aft Section Windows Replacement		201
A. Aft Section Windows Removal		201
B. Aft Section Windows Installation		201
4. Windshield Frame Replacement		201
A. New-Style Windshield Installation		201
5. Windshield Inspection		201
6. Windshield Repair		201
7. Water Leak Prevention		202
8. Geon Strips Repair		202
Table 201. Negligible Damage of Canopy/Windshield		202
Figure 201. (Round Nose) Windshields and Aft Section Windows		203
Figure 202. (Extended Nose) Windshield and Aft Section Windows		204
Figure 203. Windshield Installation (New Style)		205
Figure 204. (Extended Nose) Windshields and Aft Section Windows (New Style)		206
53-20-00 Lower Center Fuselage		A
Maintenance Practices		201
1. Lower Center Fuselage – General		201
2. Lower Center Fuselage Inspection		201
3. Fuel Tank Support Skin Inspection (Fuel Cells Removed)		201
4. Fuel Tank Support Skins Repair (Fuel Cells Removed)		201
Figure 201. Lower Center Fuselage (369D/E/FF – 500N)		202

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
	Figure 202. Lower Center Fuselage (Model 600N)	203
53-30-00 Upper Aft Section Fuselage (369D/E/FF)	A
Maintenance Practices	201
1. Upper Firewall Replacement	201
2. Firewall and Plenum Chamber Panels Replacement	201
Figure 201. Soundproofing Insulation – Firewall and Plenum Chamber (Sheet 1 of 2)	202
A. Mast Support Structure	204
3. Mast Support Structure Inspection	204
A. Firewalls	204
4. Firewalls Inspection	204
Figure 202. Firewall and Aft Section	205
A. Firewall, Station 124.00 Insulation and Soundproofing	205
5. Firewall and Plenum Chamber Soundproofing Panel Inspection	205
A. Engine Air Inlet Fairing	205
6. Engine Air Inlet (Plenum Chamber) Inspection	206
A. Upper Aft Section General Repair	206
B. Aft Fuselage Fittings	206
C. Aft Fuselage Fittings General Repair	206
7. Aft Section Strut Repair	206
8. Silver Brazing Procedure – Upper Firewall Shell Patch	206
Figure 203. Major Bulkheads and Structural Members – Aft Fuselage	207
9. Plenum Chamber Hole Sealing	208
10. Forward Fuselage Section Structure Rework	208
11. Transmission Compartment Air Baffle, Seal and Cover Initial Installation	209
Table 201. Weight and Balance Data	210
Figure 204. Forward Fuselage Section Structure Rework	211
Figure 205. Installation of Air Baffle, Seal and Cover Assemblies (Sheet 1 of 2)	212
53-30-30 Upper Aft Section Fuselage (500/600N)	A
Maintenance Practices	201
1. Engine/Anti-Torque Air Inlet Fan Fairings	201
2. Engine Air and Fan Inlet (Plenum Chamber Area) Inspection	201
Figure 201. Upper Aft Section (500N)	202
Figure 202. Upper Aft Section Fuselage (600N)	203
A. Upper Aft Section General Repair	204
3. Upper Fuselage Controls Fairing (600N)	204

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
4.	Upper Fuselage Controls Fairing Replacement (600N)	204
A.	Upper Fuselage Controls Fairing Removal	204
B.	Upper Fuselage Controls Fairing Installation	204
5.	Engine Inlet Fairings Replacement	204
A.	Engine Inlet Fairing Removal	204
B.	Engine Inlet Fairing Installation	204
6.	Anti-Torque Fan Air Inlet Screen Replacement	204
A.	Fan Air Inlet Screen Removal	204
B.	Fan Air Inlet Screen Installation	204
7.	Fan Hub and Transmission Cover Fairing Replacement	204
A.	Fan Hub and Transmission Cover Removal	204
B.	Fan Hub and Transmission Cover Installation	205
8.	Engine Plenum Access Cover Replacement	205
A.	Engine Plenum Access Cover Removal	205
B.	Engine Plenum Access Cover Installation	205
9.	Tailboom Attach Fitting Inspection	205
	Figure 203. Tailboom Attach Fitting Inspection	206
10.	Lower Longeron Inspection (L158, R158)	207
11.	Forward Upper Longeron Inspection (L137, R137)	207
	Figure 204. Inspection Hole Locations	208
12.	Control Tunnel (FS 78.50) Beam Inspection	209
	Figure 205. Control Tunnel (FS 78.50) Beam Inspection	209
53-40-00	Tailboom (369D/E/FF)	A
Maintenance Practices	201
1.	Tailboom – General	201
2.	Tailboom Replacement	201
A.	Tailboom Removal	201
B.	Tailboom Installation	201
	Figure 201. Tailboom Assembly and Tailboom Extension	202
3.	Tailboom Extension Replacement (369FF)	202
4.	Tailboom Inspection	203
5.	Tailboom Repair	203
	Figure 202. Tailboom Installation and Removal	204
53-40-30	Tailboom (500/600N)	A
Maintenance Practices	201
1.	Tailboom Description	201

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
2.	Tailboom Replacement	201
A.	Tailboom Removal	201
	Figure 201. Tailboom Assembly (Sheet 1 of 3)	202
B.	Tailboom Installation	205
3.	Tailboom Inspection	205
	Figure 202. Tailboom Flap Inspection	206
4.	Tailboom Repair	207
5.	Stator Replacement	207
A.	Stator Removal	207
B.	Stator Installation	207
6.	Stator Blade Replacement	207
7.	Rotating Thruster Cone Replacement	207
A.	Rotating Thruster Cone Removal	207
B.	Rotating Thruster Cone Installation	207
8.	Rotating Thruster Cone Inspection	207
9.	Stationary Thruster Cone Replacement	208
A.	Stationary Thruster Cone Removal	208
B.	Stationary Thruster Cone Installation	208
10.	Stationary Thruster Cone Inspection	208
11.	Conduit and Support Strap Rebonding	208
	Figure 203. Conduit and Support Strap Rebonding	209
12.	Horizontal Stabilizer Mount Fitting Replacement	210
13.	500N3500-5 Cover Installation	211
	Figure 204. 500N3500-5 Cover Installation	212
14.	Tail Skid Replacement	212
A.	Tail Skid Removal	212
B.	Tail Skid Installation	212
	Figure 205. Tail Skid Installation	213
53-50-10	Stabilizer (T-Tail) (369D/E/FF)	A
Maintenance Practices	201
1.	Stabilizer – General	201
A.	Stabilizer Troubleshooting	201
2.	Horizontal Stabilizer and Tip Plate Replacement	201
A.	Horizontal Stabilizer and Tip Plate Removal	201
B.	Horizontal Stabilizer and Tip Plate Installation	201
3.	Vertical Stabilizer Replacement	202

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
A. Vertical Stabilizer Removal	202	
B. Vertical Stabilizer Installation	202	
4. Horizontal Stabilizer and Tip Plate Inspection	202	
5. Vertical Stabilizer Inspection	202	
Figure 201. Stabilizer T-Tail Removal and Installation	203	
6. Horizontal Stabilizer and Tip Plate Repair	204	
7. Vertical Stabilizer Repair	204	
8. Angle of Incidence Measurement	204	
Table 201. Horizontal Stabilizer Angle of Incidence	204	
9. Angle of Incidence Adjustment	205	
10. Horizontal Stabilizer Tab Weight Installation	205	
Table 202. Troubleshooting Tailboom and Tail Surfaces	205	
Figure 202. Horizontal Stabilizer Incidence Angle Measuring Tool	206	
Figure 203. Establishing Horizontal Stabilizer Angle of Incidence	206	
Figure 204. Sealing – Vertical Stabilizer (0003D – 0286D)	207	
53-50-30 Stabilizer (500/600N)	A	
Maintenance Practices	201	
1. Stabilizers Description	201	
A. Horizontal Stabilizer Description	201	
B. Vertical Stabilizers Description	201	
2. Vertical Stabilizer Replacement	201	
A. Vertical Upper and Lower Stabilizer Removal	201	
B. Vertical Upper and Lower Stabilizer Installation	201	
3. Horizontal Stabilizer Replacement	202	
A. Horizontal Stabilizer Removal	202	
B. Horizontal Stabilizer Installation	202	
Figure 201. Stabilizer Installation with YSAS (Sheet 1 of 2)	203	
4. Horizontal Stabilizer Eye Bolt Replacement	205	
A. Horizontal Stabilizer Eye Bolt Removal	205	
B. Horizontal Stabilizer Eye Bolt Installation	205	
5. Horizontal/Vertical Stabilizer Control Tube and Bellcrank Replacement	205	
A. Horizontal/Vertical Stabilizer Control Tube and Bellcrank Removal	205	
B. Horizontal/Vertical Stabilizer Control Tube and Bellcrank Installation	205	
6. Vertical Stabilizer Inspection	205	
7. Vertical Stabilizer Repair	205	
8. Horizontal Stabilizer Inspection	205	
9. Vertical Stabilizer Torque Tube Replacement	206	

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
A.	Vertical Stabilizer Torque Tube Removal	206
B.	Vertical Stabilizer Torque Tube Installation	206
	Figure 202. Stabilizer Installation without YSAS	207
	Figure 203. Vertical Stabilizer Installation with Expandable Bolts	208
10.	Horizontal Stabilizer Repair	209
11.	Vertical Stabilizer Torque Tube and/or Bushing Replacement (Non-Bonded Bushings)	209
12.	Vertical Stabilizer Torque Tube and/or Bushing Replacement (Bonded Bushings)	209
13.	Vertical Stabilizer Torque Tube Bushing Rework (Non-Bonded Bushings to Bonded Bushings)	210
14.	Vertical Stabilizer Torque Tube Bearing Race Replacement	211
15.	Stabilizer Troubleshooting	212
	Table 201. Troubleshooting Tailboom and Tail Surfaces	212

4. Horizontal Stabilizer Eye Bolt Replacement

A. Horizontal Stabilizer Eye Bolt Removal

- (1). Remove horizontal stabilizer.
- (2). Remove eye bolts by holding the flat surface of eye bolt with a wrench and removing nut.

B. Horizontal Stabilizer Eye Bolt Installation

- (1). Install eye bolts in horizontal stabilizer, the short eye bolts in the forward holes and the longer eye bolts with spacer to the aft holes of horizontal stabilizer.
- (2). Torque eye bolts to **80 - 120 inch-pounds (9.04 - 13.56 Nm) plus drag torque.**
- (3). Install horizontal stabilizer.

5. Horizontal/Vertical Stabilizer Control Tube and Bellcrank Replacement

(Ref. Figure 201 and Figure 202)

A. Horizontal/Vertical Stabilizer Control Tube and Bellcrank Removal

- (1). Remove horizontal stabilizer end tip covers and center access cover for access to bellcranks and control tubes.
- (2). Remove cotter pin, nut, washer and bolt from center bellcrank shaft. Index mark bellcrank with grease pencil in relationship to shaft. Disconnect bellcrank.
- (3). Disconnect control tube from vertical stabilizer torque tube bellcrank. Remove controls from horizontal stabilizer as required for maintenance.

B. Horizontal/Vertical Stabilizer Control Tube and Bellcrank Installation

Refer to adjustment and test control rigging during installation.

- (1). Connect bellcrank to center bellcrank shaft and install bolt, washers and nut. Torque bolt to standard aircraft torque values and install cotter pin.

- (2). Install control tubes and bellcranks as required, safety wire or cotter pin.
- (3). Install center access plate with seven screws and washers.

6. Vertical Stabilizer Inspection

(Ref. Figure 201 and Figure 202)

- (1). Inspect skin for cracks, bonding separation, delamination and obvious damage.
- (2). Inspect stabilizer for freedom of movement through pedal travel range, check for clearance between vertical to horizontal.
- (3). Check mounting fitting holes for elongation.

NOTE: Internal stabilizer fitting may display cracking after installation of expandable bolts. This cracking, internal fitting only, is acceptable for continued service. Cracking of the external skin from the mounting bolt holes is unacceptable and stabilizer must be removed from service and scrapped.

7. Vertical Stabilizer Repair

Refer to MDHI Field Service Representative.

8. Horizontal Stabilizer Inspection

- (1). Inspect skin for cracks, bonding separation, delamination and obvious damage.
- (2). Inspect mounting fitting and attachment hardware for condition.
- (3). Inspect center access panel and nut plate fasteners for condition, end tip plate access covers and position lights for condition.
- (4). Inspect vertical stabilizer torque tubes for excessive axial and radial movement, 0.010 inch (0.254 mm) axial end play maximum allowable.
- (5). Inspect torque tube bushings for wear and security.
- (6). If the bushings are not bonded to the horizontal stabilizer, rework Vertical Stabilizer Torque Tube Bushings.

9. Vertical Stabilizer Torque Tube Replacement**A. Vertical Stabilizer Torque Tube Removal**

- (1). Remove vertical stabilizers (Ref. Vertical Stabilizer Replacement).
- (2). Remove horizontal tip plate access cover and disconnect YSAS torque tube (if installed) from vertical stabilizer bellcrank.
- (3). Remove bellcrank from torque tube by removing expandable bolt.
- (4). Remove cotter pin, locknut and bushing from torque tube. Remove torque tube by lifting upward.

B. Vertical Stabilizer Torque Tube Installation

- (1). Slide torque tube from the top thru the horizontal stabilizer.

(2). Apply one layer of teflon tape (CM726) to threads of torque tube prior to installing locknut.

(3). Install locknut, hand tighten and adjust to a 0.005–0.010 inch (0.127–0.254 mm) gap; Install cotter pin.

NOTE: When installing the bellcrank, opening in bellcrank must face outboard.

- (4). Install bellcrank, with opening facing outboard, on torque tube and install expandable bolt; Torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** plus **drag torque**; Install cotter pin.
- (5). Connect YSAS actuator to vertical stabilizer torque tube bellcrank. Torque nut to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** and install cotter pin.
- (6). Install end plate access covers.
- (7). Install vertical stabilizer (Ref. Vertical Stabilizer Replacement).





Figure 202. Stabilizer Installation without YSAS



NOTE:
THE BOLT, WASHER, THICK WASHER, SPACERS AND NUT ARE
COMPONENTS OF THE EXPANDABLE DIAMETER BOLT ASSEMBLY.

53-5007

Figure 203. Vertical Stabilizer Installation with Expandable Bolts

10. Horizontal Stabilizer Repair

Refer to MDHI Field Service Representative.

11. Vertical Stabilizer Torque Tube and/or Bushing Replacement (Non-Bonded Bushings)

(Ref. Figure 201) The following procedure is for replacing the early style (non-bonded) torque tube bushings.

**Consumable Materials
(Ref. Section 91-00-00)**

<u>Item</u>	<u>Nomenclature</u>
CM726	Tape, teflon

- (1). Remove vertical stabilizers (Ref. Vertical Stabilizer Replacement).
- (2). Remove horizontal tip plate access cover and disconnect YSAS torque tube (if installed) from vertical stabilizer bellcrank.
- (3). Remove bellcrank from torque tube by removing expandable bolt.
- (4). Remove cotter pin, locknut and bushing from torque tube. Remove torque tube by lifting upward.
- (5). Remove bushing from bearing race of torque tube.
- (6). Install one bushing on bearing race of torque tube and insert torque tube through fitting of horizontal stabilizer from the top downward.
- (7). Apply one layer of teflon tape (CM726) to threads of torque tube prior to installing locknut.
- (8). Install bushing and locknut, hand tighten locknut and adjust to a 0.005-0.010 inch (0.127-0.254 mm) gap; Install cotter pin.

NOTE: Ensure shouldered bushings are installed in bellcrank.

- (9). Install bellcrank on torque tube and install expandable bolt and washers; Torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** plus drag torque; Install cotter pin.

4.52 Nm) plus drag torque; Install cotter pin.

- (10). Connect YSAS actuator to vertical stabilizer torque tube bellcrank. Torque nut to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** and install cotter pin.
- (11). Install end plate access covers.
- (12). Install vertical stabilizer (Ref. Vertical Stabilizer Replacement).

12. Vertical Stabilizer Torque Tube and/or Bushing Replacement (Bonded Bushings)

(Ref. Figure 201) The following procedure is for replacing the current style (bonded) torque tube bushings.

**Consumable Materials
(Ref. Section 91-00-00)**

<u>Item</u>	<u>Nomenclature</u>
CM222	1,1,1-Trichloroethane
CM402	Adhesive
CM726	Tape, teflon
CM802	Abrasive cloth, aluminum oxide

- (1). Remove vertical stabilizers (Ref. Vertical Stabilizer Replacement).
- (2). Remove horizontal tip plate access cover and disconnect YSAS torque tube (if installed) from vertical stabilizer bellcrank.
- (3). Remove bellcrank from torque tube by removing expandable bolt.
- (4). Remove cotter pin, locknut and bushing from torque tube. Remove torque tube by lifting upward.

CAUTION In the following steps, care must be taken to not damage the fibers of the horizontal stabilizer.

- (5). Remove bushing(s) from horizontal stabilizer by gently working a sharp scraper between bushing and stabilizer.
- (6). Sand excess sealant from horizontal stabilizer taking care not to disturb the composite fibers of the stabilizer.
- (7). Clean faying surfaces of horizontal stabilizer, where bushings are to be

bonded, with 1,1,1-trichloroethane (CM222).

- (8). Wipe dry using a clean dry rag and then allow to air dry for 15 minutes.
- (9). Lightly abrade the faying surface of the new bushings with abrasive cloth (CM802) until all gloss is removed. Wipe clean with 1,1,1-trichloroethane.
- (10). Wipe dry using a clean dry rag and then allow to air dry for 15 minutes.
- (11). Mix adhesive (CM402) according to manufacturers instructions. Apply adhesive within 2 hours of cleaning.
- (12). Apply a thin uniform layer of adhesive to faying surfaces.

CAUTION Do not apply too much pressure, damage to horizontal stabilizer may occur.

- (13). Press the faying surfaces firmly together and maintain contact pressure or apply 50 psi (3.45 kPa) maximum for 24 hours at ambient temperature.
- (14). Using 1,1,1-trichloroethane, clean excess adhesive from parts before adhesive has had time to cure.
- (15). Slide torque tube from the top thru the horizontal stabilizer.
- (16). Apply one layer of teflon tape (CM726) to threads of torque tube prior to installing locknut.
- (17). Install locknut, hand tighten and adjust to a 0.005-0.010 inch (0.127-0.254 mm) gap; Install cotter pin.
- (18). Install bellcrank on torque tube and install expandable bolt; Torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** plus drag torque; Install cotter pin.
- (19). Connect YSAS actuator to vertical stabilizer torque tube bellcrank. Torque nut to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** and install cotter pin.
- (20). Install end plate access covers.
- (21). Install vertical stabilizer (Ref. Vertical Stabilizer Replacement).

13. Vertical Stabilizer Torque Tube Bushing Rework (Non-Bonded Bushings to Bonded Bushings)

(Ref. Figure 201) The following procedure is for converting the vertical stabilizer torque tube to the current 500N3980-3 bushings, 500N3970-3 locknuts and MS24665-361 cotter pins.

Consumable Materials (Ref. Section 91-00-00)

Item	Nomenclature
CM222	1,1,1-Trichloroethane
CM402	Adhesive
CM726	Tape, teflon
CM802	Abrasive cloth, aluminum oxide

- (1). Remove vertical stabilizers (Ref. Vertical Stabilizer Replacement).
- (2). Remove cotter pins, locknuts and bushings, and scrap. Remove torque tube by lifting upward. Remove bushing and scrap.
- (3). Clean faying surfaces of horizontal stabilizer, where bushings are to be bonded, with 1,1,1-trichloroethane (CM222).
- (4). Wipe dry using a clean dry rag and then allow to air dry for 15 minutes.
- (5). Lightly abrade the faying surface of the new bushings with abrasive cloth (CM802) until all gloss is removed. Wipe clean with 1,1,1-trichloroethane.
- (6). Wipe dry using a clean dry rag and then allow to air dry for 15 minutes.
- (7). Mix adhesive (CM402) according to manufacturers instructions. Apply adhesive within 2 hours of cleaning.
- (8). Apply a thin uniform layer of adhesive to faying surfaces.

CAUTION Do not apply too much pressure, damage to horizontal stabilizer may occur.

- (9). Press the faying surfaces firmly together and maintain contact pressure or apply 50 psi (3.45 kPa) maximum for 24 hours at ambient temperature.

- (10). Using 1,1,1-trichloroethane, clean excess adhesive from parts before adhesive has had time to cure.
- (11). Slide torque tube from the top thru the horizontal stabilizer.
- (12). Apply one layer of teflon tape (CM726) to new 500N3970-3 locknut.
- (13). Install locknut, hand tighten and adjust to a 0.005-0.010 inch (0.127-0.254 mm) gap; Install MS24665-361 cotter pin.
- (14). Install bellcrank on torque tube and install expandable bolt; Torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** **plus drag torque**; Install cotter pin.
- (15). Install end plate access covers.
- (16). Install vertical stabilizer (Ref. Vertical Stabilizer Replacement).

14. Vertical Stabilizer Torque Tube Bearing Race Replacement

(Ref. Figure 201) The following procedure is for removal of the bearing race from the vertical stabilizer torque tube. Some special tools will need to be manufactured for this procedure.

Consumable Materials (Ref. Section 91-00-00)

<u>Item</u>	<u>Nomenclature</u>
CM234	Solvent, dry-cleaning
CM318	Primer
CM730	Tape, duct

Special Tools (Ref. Section 91-00-00)

<u>Item</u>	<u>Nomenclature</u>
N/A	Arbor press

- (1). Remove vertical stabilizers (Ref. Vertical Stabilizer Replacement).
- (2). Remove vertical stabilizer torque tubes (Ref. Vertical Stabilizer Torque Tube Replacement).
- (3). Fabricate the following tool for bearing race removal.

- (a). Locate a steel plate of approximately 0.250 inch (6.35 mm) thickness.
- (b). Drill a 1.510 inch (38.3540 mm) hole in the plate.
- (c). Deburr edges of hole to prevent damage to torque tube.
- (d). Apply tape (CM730) to tool to prevent damage to bearing race.
- (4). Insert torque tube through the removal tool and install on arbor press.

CAUTION In the following steps, care must be taken to not damage the horizontal stabilizer torque tube.

- (5). Place suitable device over torque tube end to protect tube from damage from arbor press.
- (6). Remove bearing from the torque tube by gently pressing torque tube through the removal tool.
- (7). Using solvent (CM234), clean primer residue from torque tube.
- (8). Inspect torque tube for damage to bearing race contact surface.
- (9). Fabricate the following tool for bearing race installation.
- (a). Locate a steel plate of approximately 0.250 inch (6.35 mm) thickness.
- (b). Drill a 1.390 inch (35.306 mm) hole in the plate.
- (c). Deburr edges of hole to prevent damage to torque tube.
- (d). Apply tape (CM730) to tool to prevent damage to bearing race.

- (10). Insert bearing race into tool and mount on arbor press.

- (11). Coat torque tube bearing race mating surface with primer (CM318).

CAUTION In the following steps, care must be taken to not damage the horizontal stabilizer torque tube.

- (12). Place suitable device over torque tube end to protect tube from damage from arbor press.



In the following step, ensure bearing race is not cocked on torque tube, this will cause non-repairable damage to bearing race and torque tube.

- (13). While primer is wet, press torque tube down through the bearing race until bearing race is tight against flange on torque tube.
- (14). Inspect bearing race flanged surface to

ensure no warpage occurred during installation.

- (15). Reinstall vertical stabilizer torque tubes (Ref. Vertical Stabilizer Torque Tube Replacement).
- (16). Reinstall vertical stabilizers (Ref. Vertical Stabilizer Replacement).

15. Stabilizer Troubleshooting

(Ref. Table 201)

Table 201. Troubleshooting Tailboom and Tail Surfaces

Symptom	Probable Trouble	Corrective Action
High frequency vibration	Fan assembly out of balance	Re-balance fan assembly.
	Loose fan blades	Replace and re-balance fan assy.
	Loose bolts/nuts on Horizontal or Vertical stabilizer	Inspect mounting hardware; adjust or replace as necessary.

NOTE: High frequency vibrations in helicopter can be caused by components in other systems (Ref. Sec. 64-00-00, 63-25-10, 63-25-30 and 71-00-00).