



Manual: CSP-HMI-2, Handbook of Maintenance Instructions
Models: 369D/E/FF - 500/600N Helicopters
Issued: 31 October 1990
Original: **Revision 42:**
1 June 2009

FILING INSTRUCTIONS:

1. Before inserting this change, ensure the manual is current.
Check the existing List of Effective Pages in the manual to ensure all prior revisions are inserted. **(Do not insert this revision if prior revisions are not inserted).**
2. Incorporate this change by removing old pages and inserting new pages as indicated below.

Remove Pages	Insert Pages	Remove Pages	Insert Pages
	Cover/Title		63-10-00
Cover/Title	Cover/Title	405 and 406	405 and 406
	Temporary Revision		63-15-10
1 and 2	1 and 2	401 thru 410	401 thru 410
	List of Effective Pages		63-21-00
TR08-001	None	407 thru 412	407 thru 414
A thru J	A thru J		63-22-00
	Table of Contents	203 and 204	203 and 204
i and ii	i and ii		64
	Service Bulletins	i thru iv	i thru iv
1 thru 9/(10 blank)	None		64-25-30
	01-00-00	401 thru 404	401 thru 404
203 and 204	203 and 204	601 and 602	601 and 602
	04-00-00	801 thru 806	801 thru 808
1 thru 16	1 thru 16		67
	05	i thru xii	i thru xii
i and ii	i and ii	105 and 106	105 and 106
	05-50-00		67-10-00
1 thru 10	1 thru 12	503 and 504	503 and 504
	53-50-30		67-20-30
201 and 202	201 and 202	803 thru 806	803 thru 806
	63		76-10-00
i thru x	i thru x	215 thru 218	215 thru 218
		17 and 18	91-00-00
			17 and 18

This Page Intentionally Left Blank




MDHI MODEL HELICOPTERS

MODELS 369D/E/FF – 500/600N

Basic Handbook of Maintenance Instructions

(CSP-HMI-2)

SERVICING AND MAINTENANCE



**MD Helicopters, Inc.
4555 East McDowell Road
Mesa, Arizona 85215-9734**

PROPRIETARY RIGHTS NOTICE

The technical data and information contained in this publication is the property of and proprietary to MD Helicopters, Inc. and is not to be disclosed or reproduced in whole or in part without the written consent of MD Helicopters, Inc.

RESTRICTED USE

MDHI provides this manual for use by owners, operators and maintainers of MDHI products and authorized parts. Use by STC or PMA applicants or holders as documentation to support their certificates is not an authorized use of this manual and is prohibited. MDHI takes no responsibility for customer's use of parts manufactured under an STC or PMA when this manual is used as documentation with the Federal Aviation Administration to justify the STC or PMA. Use of unauthorized parts on MDHI products will void the MDHI warranty offered to the customer on components and may void the warranty on the helicopter.

RECORD OF TEMPORARY REVISIONS

Rev. No.	Date Inserted	By	Date Removed	By	Rev. No.	Date Inserted	By	Date Removed	By
91-001			Removed by Revision 3		95-003			Removed by Revision 13	
91-002			Removed by Revision 4		96-001			Removed by Revision 13	
92-001			Removed by Revision 5		96-002			Removed by Revision 13	
92-002			Removed by Revision 5		97-001			Removed by Revision 18	
92-003			Removed by Revision 5		97-002			Removed by Revision 18	
92-004			Removed by Revision 5		98-001			Removed by Revision 20	
92-005			Removed by Revision 6		98-002			Removed by Revision 21	
93-001			Removed by Revision 7		98-003			Removed by Revision 21	
93-002			Removed by Revision 8		98-004			Removed by Revision 22	
93-003			Removed by Revision 9		98-005			Removed by Revision 22	
93-004			Removed by Revision 9		99-001			Removed by Revision 22	
93-005			Removed by Revision 9		01-001			Removed by Revision 31	
93-006			Removed by Revision 9		02-001			Removed by Revision 32	
94-001			Removed by Revision 9		02-002			Removed by Revision 32	
94-002			Removed by Revision 11		03-001			Removed by Revision 34	
95-001			Removed by Revision 12		03-002			Removed by Revision 34	
95-002			Removed by Revision 13		03-003			Removed by Revision 35	

[illegible]

LIST OF EFFECTIVE PAGES

INSERT LATEST CHANGE PAGES, DESTROY SUPERSEDED PAGES

The highest revision number indicates pages changed, added or removed by the current change.

Date of original and revision pages are:

Original	31 October 1990	Revision 22	10 March 1998
Revision 1	29 March 1991	Revision 23	01 June 1999
Revision 2	10 May 1991	Revision 24	07 December 1999
Revision 3	09 September 1991	Revision 25	28 April 2000
Revision 4	20 January 1992	Revision 26	17 August 2000
Revision 5	24 August 1992	Revision 27	09 October 2000
Revision 6	21 December 1992	Revision 28	30 November 2000
Revision 7	01 June 1993	Revision 29	11 May 2001
Revision 8	23 July 1993	Revision 30	11 July 2001
Revision 9	22 April 1994	Revision 31	05 November 2001
Revision 10	26 September 1994	Revision 32	18 March 2002
Revision 11	18 January 1995	Revision 33	24 June 2002
Revision 12	06 October 1995	Revision 34	21 August 2003
Revision 13	31 May 1996	Revision 35	20 May 2004
Revision 14	13 September 1996	Revision 36	11 November 2004
Revision 15	15 November 1996	Revision 37	13 December 2005
Revision 16	06 January 1997	Revision 38	25 May 2006
Revision 17	24 February 1997	Revision 39	10 April 2007
Revision 18	17 October 1997	Revision 40	10 November 2007
Revision 19	16 December 1997	Revision 41	03 March 2008
Revision 20	01 June 1998	Revision 42	01 June 2009
Revision 21	24 August 1998		

Cover/Title	Chapter 01
Cover/Title	i/(ii blank)
	Revision 42
	Revision 26
Change Request	01-00-00
CRi and CRii	1
N/A	Revision 26
	2 thru 4
	Revision 23
Temporary Revision	5 and 6
	Revision 26
1 and 2	7
Revision 42	Revision 29
	8
	Revision 28
List of Effective Pages	201
A thru J	Revision 23
Revision 42	202
	Revision 40
Table of Contents	203
	Revision 23
i	204
Revision 42	Revision 42
ii	205 thru 208
Revision 29	Revision 23
iii	209
Revision 34	Revision 36
iv	210
Revision 38	Revision 30
v and vi	211 and 212
Revision 29	Revision 36

Chapter 04

i and ii Revision 34

04-00-00

1 thru 16 Revision 42

04-00-01

1/(2 blank) Revision 26

Chapter 05

i and ii Revision 42

05-00-00

1 thru 4 Revision 38

05-10-00

1 Revision 34

2 Revision 40

3 Revision 37

4 Revision 34

05-20-00

1 Revision 35

2 Revision 39

3 Revision 40

4 thru 6 Revision 35

7 thru 12 Revision 39

05-20-10

1 thru 3 Revision 39

4 Revision 38

05-20-15

1 Revision 29

2 and 3/(4 blank) Revision 31

05-20-20

1 Revision 36

2 thru 4 Revision 37

5 Revision 38

6 Revision 36

05-50-00

1 thru 11/(12 blank) Revision 42

Chapter 06

i and ii Revision 34

06-00-00

201 thru 205 Revision 23

206 Revision 39

207 thru 210 Revision 23

211 Revision 36

212 Revision 34

Chapter 07

i/(ii blank) Revision 23

07-00-00

201 thru 206 Revision 23

Chapter 08

i/(ii blank) Revision 23

08-00-00

201 thru 203/(204 blank) Revision 23

08-10-00

201 Revision 39

202 and 203 Revision 27

204 thru 210 Revision 23

211 Revision 36

212 thru 217/(218 blank) Revision 23

Chapter 09

i/(ii blank) Revision 23

09-00-00

201 thru 204 Revision 23

Chapter 10

i/(ii blank) Revision 23

10-10-00

201 thru 204 Revision 23

10-20-00

201 thru 203/(204 blank) Revision 23

10-30-00

201 thru 206 Revision 23

Chapter 11

i/(ii blank) Revision 23

11-00-00

201 thru 217/(218 blank) Revision 23

11-40-00

201 thru 211/(212 blank) Revision 23

Chapter 12

i Revision 23

ii Revision 32

12-00-00

301 and 302 Revision 23

303 Revision 24

304 Revision 34

305 Revision 26

306 and 307 Revision 24

308 Revision 26

309 Revision 23

310 and 311 Revision 32

312 Revision 23

Chapter 18

i thru iii/(iv blank) Revision 23

18-10-00

201	Revision 23
202	Revision 31
203 and 204	Revision 37
401 thru 404	Revision 23
501	Revision 23
502	Revision 34
503 thru 505	Revision 23
506 and 507	Revision 24
508 and 509	Revision 23
510	Revision 39

18-10-60

201	Revision 23
202 and 203/(204 blank)	Revision 31
401 thru 404	Revision 23
501	Revision 23
502	Revision 34
503 thru 509	Revision 23
510	Revision 37
511 and 512	Revision 23

18-20-00

201	Revision 34
202 and 203	Revision 23
204	Revision 34
205	Revision 39
206	Revision 23

18-20-30

201 thru 205/(206 blank)	Revision 23
--------------------------------	-------------

Chapter 20

i and ii	Revision 41
----------------	-------------

20-10-00

201 thru 206	Revision 38
--------------------	-------------

20-20-00

201 and 202	Revision 23
-------------------	-------------

20-30-00

201 and 202	Revision 23
203 thru 206	Revision 34

20-40-00

201 thru 204	Revision 23
--------------------	-------------

20-90-00

201	Revision 38
202 thru 204	Revision 40

Chapter 21

i and ii	Revision 23
----------------	-------------

21-10-00

201 thru 204	Revision 23
--------------------	-------------

21-40-00

201 thru 207	Revision 23
208	Revision 27
209	Revision 37
210	Revision 23
901 thru 911/(912 blank)	Revision 23

Chapter 25

i	Revision 24
ii thru vii/(viii blank)	Revision 23

25-00-00

1 and 2	Revision 23
---------------	-------------

25-10-00

201 thru 205	Revision 23
206	Revision 24
207 and 208	Revision 23

25-15-00

201 thru 204	Revision 23
901 and 902	Revision 23

25-20-00

201 thru 211/(212 blank)	Revision 23
--------------------------------	-------------

25-21-00

201/(202 blank)	Revision 23
901 thru 908	Revision 23

25-30-00

201 thru 214	Revision 23
--------------------	-------------

25-40-00

201 thru 207/(208 blank)	Revision 23
--------------------------------	-------------

25-50-00

101 thru 106	Revision 23
401 thru 408	Revision 23
601 and 602	Revision 23
901 thru 907/(908 blank)	Revision 23

25-60-00

201 and 202	Revision 23
-------------------	-------------

25-63-00

201 thru 216	Revision 23
901 thru 910	Revision 23

Chapter 26

i/(ii blank)	Revision 23
--------------------	-------------

26-10-00

201 thru 203/(204 blank)	Revision 23
--------------------------------	-------------

26-20-00

201 and 202	Revision 23
-------------------	-------------

Chapter 28

i	Revision 19
ii	Revision 37
iii and iv	Revision 28
v thru vii/(viii blank)	Revision 31

28-00-00

1 and 2	Revision 19
101	Revision 29
102 and 103	Revision 19
104	Revision 23
201 and 202	Revision 19
401 thru 414	Revision 19
415 and 416	Revision 36
417 thru 422	Revision 19
501 thru 504	Revision 19
505	Revision 36
506	Revision 19
507	Revision 29
508 thru 510	Revision 19
601 thru 603	Revision 19
604	Revision 28
605 thru 607/(608 blank)	Revision 19
801 thru 807/(808 blank)	Revision 19

28-00-60

1 thru 3/(4 blank)	Revision 19
101	Revision 29
102	Revision 19
103/(104 blank)	Revision 21
201	Revision 32
202	Revision 39
401 thru 405	Revision 19
406 and 407	Revision 34
408 thru 422	Revision 19
501 and 502	Revision 22
503/(504 blank)	Revision 21
601	Revision 19
602 thru 606	Revision 31
801 thru 805/(806 blank)	Revision 19

28-25-00

1	Revision 39
2	Revision 20
101/(102 blank)	Revision 20
201 and 202	Revision 20
203 thru 205/(206 blank)	Revision 19
601 and 602	Revision 20
603 thru 605/(606 blank)	Revision 19

901 and 902	Revision 20
903	Revision 28
904 thru 918	Revision 19

Chapter 32

i	Revision 19
ii thru vi	Revision 26

32-10-00

1/(2 blank)	Revision 19
301 thru 308	Revision 19
401 and 402	Revision 19
403 and 404	Revision 26
405	Revision 19
406 and 407/(408 blank)	Revision 26
601	Revision 31
602 thru 605/(606 blank)	Revision 26
801 thru 805	Revision 19
806 and 807/(808 blank)	Revision 26
901 thru 908	Revision 19

32-10-60

1/(2 blank)	Revision 19
301 thru 303/(304 blank)	Revision 19
401	Revision 19
402	Revision 26
403	Revision 34
404	Revision 20
405 and 406	Revision 19
407/(408 blank)	Revision 20
601	Revision 31
602	Revision 19
603/(604 blank)	Revision 22
801 thru 803/(804 blank)	Revision 19

32-40-00

201 thru 206	Revision 19
--------------------	-------------

32-40-60

201 and 202	Revision 19
-------------------	-------------

32-81-00

201 thru 204	Revision 19
901 thru 910	Revision 19

32-82-00

201 thru 206	Revision 19
401 thru 407/(408 blank)	Revision 19
901 thru 912	Revision 19

Chapter 52

i thru iv	Revision 36
-----------------	-------------

52-10-00

201 thru 213	Revision 25
--------------------	-------------

214 thru 216	Revision 36
217	Revision 25
218 thru 224	Revision 36

52-40-00

201 thru 205/(206 blank)	Revision 18
--------------------------------	-------------

52-50-00

201 thru 206	Revision 18
207	Revision 31
208 thru 210	Revision 18

Chapter 53

i thru vi	Revision 40
-----------------	-------------

53-00-00

201	Revision 19
202	Revision 37
203	Revision 19
204	Revision 20

53-10-00

201 thru 206	Revision 19
--------------------	-------------

53-20-00

201 thru 203/(204 blank)	Revision 19
--------------------------------	-------------

53-30-00

201	Revision 35
202 and 203	Revision 19
204 thru 214	Revision 38

53-30-30

201	Revision 26
202 thru 210	Revision 34

53-40-00

201 thru 204	Revision 19
--------------------	-------------

53-40-30

201	Revision 36
202	Revision 19
203	Revision 22
204	Revision 19
205 thru 214	Revision 39

53-50-10

201 and 202	Revision 19
203	Revision 22
204 and 205	Revision 37
206	Revision 40
207/(208 blank)	Revision 19

53-50-30

201 and 202	Revision 42
203 and 204	Revision 33
205 thru 212	Revision 40

Chapter 62

i thru viii	Revision 37
-------------------	-------------

62-00-00

101	Revision 20
102	Revision 31

62-10-00

401 thru 403/(404 blank)	Revision 20
601 thru 605	Revision 20
606	Revision 40
607	Revision 20
608	Revision 33
609	Revision 29
610 and 611	Revision 35
612	Revision 20
801	Revision 33
802 thru 808	Revision 20
809	Revision 34
810 and 811/(812 blank)	Revision 20

62-20-00

401	Revision 36
402 and 403	Revision 20
404	Revision 36
405 and 406	Revision 20
601 and 602	Revision 20
603	Revision 29
604	Revision 25
605 thru 607	Revision 20
608	Revision 37
609 and 610	Revision 20
801	Revision 20
802	Revision 34
803 thru 810	Revision 20
811 thru 813	Revision 37
814	Revision 21
815	Revision 35
816	Revision 34
817 and 818	Revision 40
819 and 820	Revision 37

62-20-60

401	Revision 36
402	Revision 20
403 and 404	Revision 36
405/(406 blank)	Revision 20

601 and 602	Revision 20	409	Revision 39
603	Revision 33	410	Revision 32
604	Revision 20	411	Revision 34
605	Revision 34	412 thru 414	Revision 32
606 and 607	Revision 33	601	Revision 26
608	Revision 20	602	Revision 20
609	Revision 25	603	Revision 26
610	Revision 20	604 thru 606	Revision 20
801 thru 804	Revision 20	801 thru 804	Revision 20
805 thru 808	Revision 37	63-15-10	
809	Revision 22	401	Revision 20
810	Revision 37	402 thru 404	Revision 42
811	Revision 22	405	Revision 20
812 and 813	Revision 34	406 and 407	Revision 42
814	Revision 37	408	Revision 20
62-30-00		409	Revision 42
401	Revision 20	410	Revision 28
402	Revision 36	601 thru 603	Revision 20
403 and 404	Revision 31	604	Revision 37
405	Revision 36	605/(606 blank)	Revision 20
406	Revision 27	801 and 802	Revision 20
407 and 408	Revision 35	63-15-30	
601 and 602	Revision 32	201	Revision 20
801 thru 807/(808 blank)	Revision 20	202	Revision 36
62-30-60		203 thru 207/(208 blank)	Revision 20
401	Revision 20	63-20-00	
402	Revision 27	201 thru 203	Revision 20
403	Revision 31	204 and 205	Revision 36
404 thru 406	Revision 35	206 and 207/(208 blank)	Revision 20
407/(408 blank)	Revision 20	63-20-25	
601 and 602	Revision 32	201 and 202	Revision 20
801 and 802	Revision 20	203	Revision 41
Chapter 63		204	Revision 28
i thru x	Revision 42	205	Revision 24
63-00-00		206 thru 209/(210 blank)	Revision 29
101	Revision 28	63-21-00	
102	Revision 29	401 and 402	Revision 20
103	Revision 30	403	Revision 28
104	Revision 28	404 thru 407	Revision 20
63-10-00		408 thru 413/(414 blank)	Revision 42
401 thru 403	Revision 20	601	Revision 41
404	Revision 36	602	Revision 36
405	Revision 27	603	Revision 37
406	Revision 42	604	Revision 36
407	Revision 20	801 and 802	Revision 22
408	Revision 32	803	Revision 37
		804 and 805	Revision 36

806 and 807	Revision 37
808 and 809	Revision 36
810	Revision 22

63-22-00

201 and 202	Revision 20
203	Revision 42
204	Revision 20
401 thru 413/(414 blank)	Revision 20
601 and 602	Revision 20
901 thru 917/(918 blank)	Revision 20

63-25-10

201	Revision 36
202	Revision 20
203	Revision 40
204 thru 207/(208 blank)	Revision 20

63-25-30

201	Revision 36
202	Revision 20
203	Revision 33
204	Revision 20

63-30-00

201 and 202	Revision 20
203 and 204	Revision 36
205	Revision 29
206	Revision 36

Chapter 64

i thru iv	Revision 42
-----------------	-------------

64-00-00

101	Revision 21
102	Revision 34

64-00-05

901 thru 908	Revision 21
--------------------	-------------

64-10-00

201	Revision 34
202 thru 206	Revision 21
207	Revision 32
208 thru 210	Revision 21
211 thru 214	Revision 22

64-20-00

201 thru 203	Revision 21
204	Revision 28
205 thru 207/(208 blank)	Revision 21

64-25-30

401	Revision 41
402 thru 404	Revision 42

408	Revision 34
601	Revision 42
602	Revision 39
801	Revision 42
802	Revision 21
803 thru 807/(808 blank)	Revision 42

64-30-00

201	Revision 21
202	Revision 36
203 and 204	Revision 21
205	Revision 40
206 and 207	Revision 34
208 thru 210	Revision 21

Chapter 67

i thru xii	Revision 42
------------------	-------------

67-00-00

101	Revision 30
102 and 103	Revision 21
104	Revision 29
105 and 106	Revision 42
107 thru 111/(112 blank)	Revision 30

67-10-00

1 thru 5/(6 blank)	Revision 21
401 thru 405	Revision 21
406	Revision 37
407 thru 411	Revision 21
412	Revision 29
413	Revision 24
414	Revision 21
415 thru 417	Revision 29
418	Revision 39
419	Revision 21
420	Revision 29
421	Revision 21
422	Revision 29
423	Revision 31
424	Revision 29
501 thru 503	Revision 21
504	Revision 42
505	Revision 34
506	Revision 21
507	Revision 34
508 and 509	Revision 21
510	Revision 24
511	Revision 38
512 thru 515	Revision 21
516	Revision 36

517 thru 521	Revision 21	503	Revision 20
522	Revision 36	504	Revision 18
523	Revision 29	505	Revision 30
524	Revision 31	506	Revision 18
525 and 526	Revision 36	507	Revision 26
527 thru 530	Revision 21	508	Revision 30
601	Revision 28	509	Revision 37
602	Revision 21	510 and 511	Revision 30
603	Revision 28	512	Revision 36
604	Revision 39	513 thru 516	Revision 30
605	Revision 21	601	Revision 34
606 and 607	Revision 39	602	Revision 35
608	Revision 28	603	Revision 39
609 and 610	Revision 39	604 and 605	Revision 24
801 thru 813	Revision 21	606	Revision 39
814 and 815	Revision 31	801 thru 803	Revision 18
816	Revision 21	804 thru 806	Revision 42
67-10-20		Chapter 71	
201 thru 202	Revision 21	i thru x	Revision 36
203	Revision 40	71-00-00	
204 thru 208	Revision 21	1/(2 blank)	Revision 22
67-20-10		401 thru 405	Revision 22
1 and 2	Revision 21	406	Revision 30
401 and 402	Revision 21	407 thru 411	Revision 22
403	Revision 34	412 and 413/(414 blank)	Revision 26
404	Revision 26	71-00-30	
405 thru 407/(408 blank)	Revision 21	1/(2 blank)	Revision 22
501 thru 504	Revision 21	401 thru 404	Revision 22
601 and 602	Revision 21	405 and 406	Revision 34
801 thru 806	Revision 21	407 thru 411	Revision 22
67-20-30		412	Revision 26
1	Revision 34	71-00-47	
2	Revision 25	1 thru 3/(4 blank)	Revision 22
401	Revision 18	401 thru 406	Revision 22
402	Revision 34	407	Revision 36
403	Revision 18	408 thru 411/(412 blank)	Revision 29
404	Revision 33	71-10-00	
405	Revision 38	201 thru 206	Revision 22
406	Revision 34	71-10-05	
407	Revision 38	201/(202 blank)	Revision 22
408	Revision 25	901 thru 904	Revision 22
409 thru 412	Revision 33	71-10-10	
413	Revision 25	1	Revision 22
414 thru 416	Revision 30	2	Revision 36
501	Revision 33	3 and 4	Revision 22
502	Revision 18	101 thru 106	Revision 36
		201 thru 207/(208 blank)	Revision 22

401	Revision 22	101 and 102	Revision 22
402	Revision 37	76-10-00	
403/(404 blank)	Revision 22	201 thru 214	Revision 22
601	Revision 39	215	Revision 35
602 and 603	Revision 22	216 and 217	Revision 42
604	Revision 38	218 and 219	Revision 35
801 thru 814	Revision 22	220 and 221	Revision 22
901 thru 923/(924 blank)	Revision 22	222 and 223	Revision 35
71-10-60		224	Revision 22
1/(2 blank)	Revision 22	76-20-00	
101/(102 blank)	Revision 22	201 thru 213/(214 blank)	Revision 22
401	Revision 22	76-47-00	
402 thru 404	Revision 29	201	Revision 22
601	Revision 29	202 and 203	Revision 37
602	Revision 33	204	Revision 33
71-20-00		205 and 206	Revision 37
1/(2 blank)	Revision 22	207	Revision 22
401	Revision 26	208 thru 211	Revision 37
402	Revision 22	212	Revision 36
403 and 404	Revision 34	Chapter 78	
405/(406 blank)	Revision 22	i and ii	Revision 35
601/(602 blank)	Revision 22	78-20-00	
801/(802 blank)	Revision 22	201 thru 203	Revision 38
71-30-00		204 thru 209/(210 blank)	Revision 22
1 and 2	Revision 22	78-30-00	
101 thru 103/(104 blank)	Revision 22	201	Revision 38
401 thru 412	Revision 22	202 thru 204	Revision 35
413 and 414	Revision 26	Chapter 79	
601 and 602	Revision 32	i and ii	Revision 23
801 thru 804	Revision 22	79-00-00	
901 thru 905/(906 blank)	Revision 22	201 thru 212	Revision 23
71-60-00		79-10-10	
201 thru 205/(206 blank)	Revision 22	201 and 202	Revision 26
Chapter 75		901 thru 903/(904 blank)	Revision 23
i/(ii blank)	Revision 22	Chapter 91	
75-10-00		i/(ii blank)	Revision 29
201 thru 203	Revision 22	91-00-00	
204	Revision 37	1	Revision 21
205 and 206	Revision 22	2	Revision 34
Chapter 76		3	Revision 36
i thru iv	Revision 37	4 thru 16	Revision 41
76-00-00		17	Revision 42
1 and 2	Revision 22	18 thru 22	Revision 41

This Page Intentionally Left Blank

TABLE OF CONTENTS

CSP-HMI-2

[Cover / Title Page](#)

[Technical Manual Recommended Change Report](#)

[Record of Temporary Revisions](#)

[List of Effective Pages](#)

01	<u>Introduction</u>
04	<u>Airworthiness Limitations</u>
05	<u>Continued Airworthiness Checks / Inspections</u>
06	<u>Dimensions and Areas</u>
07	<u>Lifting and Jacking</u>
08	<u>Leveling / Weight and Balance</u>
09	<u>Towing</u>
10	<u>Parking and Mooring</u>
11	<u>Placards and Markings</u>
12	<u>Servicing</u>
18	<u>Vibration and Noise Analysis</u>
20	<u>Standard Practices</u>
21	<u>Environmental Control System</u>
25	<u>Equipment / Furnishings</u>
26	<u>Fire Protection</u>
28	<u>Fuel System</u>
32	<u>Landing Gear</u>
52	<u>Doors</u>
53	<u>Fuselage</u>
62	<u>Main Rotor</u>
63	<u>Transmission and Drive System</u>
64	<u>Anti-Torque Assembly</u>
67	<u>Flight Controls</u>
71	<u>Power Plant</u>
75	<u>Engine Anti-Ice System</u>
76	<u>Engine Power Controls</u>
78	<u>Engine Exhaust System</u>
79	<u>Engine Oil Supply System</u>
91	<u>Charts</u>

CSP-HMI-3

- 95** [Instruments](#)
- 96** [Electrical Power](#)
- 97** [Avionics](#)

Table 201. Related Publications and Directives (Cont)

Component and Manufacturer, or Source	Publication Title	Publication or Directive No.
MDHI Publications		
MD Helicopters Inc. M615-G048 4555 E. McDowell Rd. Mesa, AZ 85215-9734 Technical Publications Order Desk: (480) 346-6373 or (800) 388-3378 FAX: (480) 346-6809	369D Pilot's Flight Manual (with applicable Equipment Supplements)	CSP-D-1 (1)
	369E Pilot's Flight Manual (with applicable Equipment Supplements)	CSP-E-1 (1)
	369FF Pilot's Flight Manual (with applicable Equipment Supplements)	CSP-FF-1 (1)
	500N Pilot's Flight Manual (with applicable Equipment Supplements)	CSP-520N-1 (1)
	600N Pilot's Flight Manual (with applicable Equipment Supplements)	CSP-600NRFM-1 (1)
	Illustrated Parts Catalog (IPC), Model 369D/E/F - 500/600N	CSP-IPC-4 (1)
	Basic Handbook of Maintenance Instructions (HMI-2) Servicing and Maintenance, Model 369D/E/F - 500/600N	CSP-HMI-2 (1)
	Basic Handbook of Maintenance Instructions (HMI-3) Instruments-Elec- trical-Avionics, Model 369D/E/F - 500/600N	CSP-HMI-3 (1)
	Component Overhaul Manual (COM), Model 369D/E/F - 500/600N	CSP-DEF-5 (1)
	Structural Repair Manual (SRM), Model 369D/E/F - 500N	CSP-DEF-6 (1)
	Illustrated Structures Catalog (ISC), Model 369D	CSP-D-7 (1)
	Illustrated Structures Catalog (ISC), Model 369D/E/FF - 500N	CSP-ICS-7 (1)
	Corrosion Control Manual	CSP-A-4
Battery		
Marathon Battery Company Cold Spring, NY 10516 Phone: (817) 776-0650 (formerly Sonotone)	Marathon Battery Instruction Manual	BA-89 (REV 2-71)

Table 201. Related Publications and Directives (Cont)

Component and Manufacturer, or Source	Publication Title	Publication or Directive No.
Engine		
Rolls-Royce Corporation P.O. BOX 420 Indianapolis, IN 46206 USA Phone: 317-230-3774 Fax: 317-230-6084 email: indy.pubs.services@rolls-royce.com	Operation and Maintenance Manual, Turboshaft Engine Model 250-C20, -C20B	10W2 (1)
	Overhaul Manual, Turboshaft Engine Model 250-C20, -C20B	10W3 (1)
	Illustrated Parts Catalog, Turboshaft Engine Model 250-C20, -C20B	10W4 (1)
	Installation Bulletin, Three Cubic Inch Accumulator for 250-C20 Bendix Fuel System	1005 (1)
	Operation and Maintenance Manual, Turboshaft Engine Model 250-C20R/2	GTP-5232-2 (1)
	Overhaul Manual, Turboshaft Engine Model 250-C20R/2	GTP-5232-3 (1)
	Illustrated Parts Catalog, Turboshaft Engine Model 250-C20R/2	GTP-5232-4 (1)
	Operation and Maintenance Manual, Turboshaft Engine Model 250-C30	14W2 (1)
	Overhaul Manual, Turboshaft Engine Model 250-C30	14W3 (1)
	Illustrated Parts Catalog, Turboshaft Engine Model 250-C30	14W4 (1)
	Operation and Maintenance Manual, Turboshaft Engine Model 250-C47M	CSP 21004 (1)
	Overhaul Manual, Turboshaft Engine Model 250-C47M	CSP 22004 (1)
	Illustrated Parts Catalog, Turboshaft Engine Model 250-C47M	CSP 23001 (1)
Starter-Generator		
Aircraft Parts Corporation 160 Finn Court Farmingdale, NY 11735 Phone: (516) 249-3053 Datafax: (516) 249-2577	Brush Seating - APC Brushes in High Speed Starter Generators: MDHI Part Nos. 369A4550 and 369D28550	SB150SG105
	Overhaul Manual With Illustrated Parts Breakdown	TM 101
TRW Aeronautical Systems Lucas Aerospace 30 Van Nostrand Ave. Englewood, NJ 07631-4396 Phone: (201) 541-3250 Datafax: (201) 894-1965	Overhaul Instructions with Parts Breakdown, Models 23032-010, 23032-011, 23032-020, 23032-022, 23032-028, 23081-001	Call or write
Fargo Manufacturing Co. 2750 North Elston Ave. Chicago, Illinois 606447	Starter/Generator Cooling System Supplemental Type Certificate	STC No. SH907GL

AIRWORTHINESS LIMITATIONS














Type Certificate No. H3WE













FAA Approved Airworthiness Limitations for MD Helicopters, Inc., Models 369D/E/F/FF and 500/600N.





1. General

The Airworthiness Limitations section is FAA approved and specifies maintenance required under Code of Federal Regulations (CFR), Title 14, Federal Aviation Regulation (FAR), Part 43.16 and 91.403 unless an alternative program has been FAA approved.

REVISION:	DATE	FAA SIGNATURE AND DATE
Original Issue:	October 31, 1990	Not FAA approved
Revision 1:	March 29, 1991	Not FAA approved this revision
Revision 2:	May 10, 1991	Michael W. Arban 6/20/91
TR 91-001	August 12, 1991	Mark P. Cook 8/14/91
Revision 3:	September 9, 1991	Michael W. Arban 9/12/91
TR 91-002	November 5, 1991	Michael E. O'Neil 11/7/91
Revision 4:	January 20, 1992	Michael W. Arban 01/16/92
TR 92-004	May 20, 1992	Michael W. Arban 5/27/92
Revision 5:	August 24, 1992	Michael W. Arban 08/19/92
TR 92-005	November 20, 1992	Michael W. Arban 11/12/92
Revision 6:	December 21, 1992	Michael W. Arban 12/4/92
Revision 7:	June 1, 1993	Section 04-00-00 Not Affected This Revision
TR 93-002	May 27, 1993	Michael W. Arban 5/27/93
Revision 8:	July 23, 1993	Al B. 7/13/93
TR 94-001	January 21, 1994	Michael W. Arban 02/09/94
Revision 9:	April 22, 1994	James Long 3-23-94 ACTING MGR.
Revision 10:	September 26, 1994	Section 04-00-00 Not Affected This Revision
TR 94-002	October 24, 1994	Michael W. Arban 10/24/94

REVISION:	DATE	FAA SIGNATURE AND DATE
Revision 11:	January 18, 1995	 01/23/95
Revision 12:	October 6, 1995	Section 04-00-00 Not Affected This Revision
TR 96-002:	April 24, 1996	 04/24/96
Revision 13:	May 31, 1996	 6/12/96 <small>acting Mgr AD/M (301)</small>
Revision 14:	September 13, 1996	 09/09/96
Revision 15:	November 15, 1996	Section 04-00-00 Not Affected This Revision
Revision 16:	January 6, 1997	Section 04-00-00 Not Affected This Revision
Revision 17:	February 24, 1997	 02/20/97
TR 97-001:	July 2, 1997	 07/02/97
TR 97-002:	August 19, 1997	 08/19/97
Revision 18:	October 17, 1997	Section 04-00-00 Not Affected This Revision T/R 97-001 and 97-002 Previously Signed
Revision 19:	December 16, 1997	 12/19/97
TR 98-001:	March 25, 1998	 03/25/98
Revision 20:	June 1, 1998	Section 04-00-00 Not Affected This Revision T/R 98-001 Previously Signed
TR 98-002:	June 22, 1998	 7/10/98 <small>ACTING MGR.</small>
TR 98-003:	3 August 1998	 8/3/98
Revision 21:	24 August 1998	Section 04-00-00 Not Affected This Revision T/R 98-002 and 98-003 Previously Signed
Revision 22:	10 March 1999	Section 04-00-00 Not Affected This Revision
Revision 23:	1 June 1999	Section 04-00-00 Not Affected This Revision
Revision 24:	7 December 1999	 12/30/99 <small>ACTING MGR</small>
Revision 25:	28 April 2000	Section 04-00-00 Not Affected This Revision
Revision 26:	17 August 2000	 8/11/00
Revision 27:	9 October 2000	Section 04-00-00 Not Affected This Revision
Revision 28:	30 November 2000	Section 04-00-00 Not Affected This Revision

REVISION:	DATE	FAA SIGNATURE AND DATE
Revision 29:	11 May 2001	 5/4/01 5/14/01
Revision 30:	11 July 2001	Section 04-00-00 Not Affected This Revision
TR 01-001:	10 August 2001	 8/9/01
Revision 31:	5 November 2001	Section 04-00-00 Not Affected This Revision T/R 01-001 Previously Signed
TR 02-002:	30 January 2002	 1/23/02
Revision 32:	18 March 2002	 3/15/02
Revision 33:	24 June 2002	 6/11/02
TR 03-001:	18 June 2003	 6/13/03
TR 03-002:	25 June 2003	 7/2/03
Revision 34:	21 August 2003	Section 04-00-00 Not Affected This Revision T/R 03-001 and 03-002 Previously Signed
TR 03-003:	30 September 2003	 12/3/03
TR 03-004:	17 December 2003	 1/7/04
Revision 35:	20 May 2004	Section 04-00-00 Not Affected This Revision T/R 03-003 and 03-004 Previously Signed
TR 04-001:	28 May 2004	 6/7/04
Revision 36:	11 November 2004	 11/3/04
Revision 37:	13 December 2005	Section 04-00-00 Not Affected This Revision
TR 05-002:	16 December 2005	 12/29/05 12/29/05
Revision 38:	25 April 2006	Section 04-00-00 Not Affected This Revision T/R 05-002 Previously Signed

REVISION:	DATE	FAA SIGNATURE AND DATE
TR 06-001:	05 July 2006	 7/17/06
Revision 39:	10 April 2007	Section 04-00-00 Not Affected This Revision
TR 07-001:	11 April 2007	Section 04-00-00 Not Affected This Revision
Revision 41:	03 March 2008	 2/29/08
TR 08-001	14 March 2008	 3/14/08
TR 08-002	07 November 2008	 11/6/08
Revision 42:		Section 04-00-00 Not Affected This Revision T/R 08-001 and 08-002 Previously Signed

AIRWORTHINESS LIMITATIONS

2. Component Mandatory Replacement

The Airworthiness Limitation Replacement Schedule specifies the mandatory replacement time, structural inspection interval and related structural inspection procedures approved per the certificate basis of the Type Certificate Data Sheet No. H3WE and CAR 6 (6.250, 6.251) and CFR 27.571 for models 500/600N unique components only. At the listed finite-life, components or assemblies must be removed from the helicopter and permanently retired from service. At the listed inspection interval, the components or assemblies must be inspected in accordance with the Handbook of Maintenance Instructions (HMI). The title of the task and section of the HMI are referred to which provide the inspection procedures and criteria.

NOTE: Refer to CFR Part 43.10 for latest requirements for the removal, installation, storage and disposition of life-limited parts.

- (1). A “life-limited” part is a physical component of the helicopter to which a maximum number of allowable operating hours or cycles are assigned. Certain assemblies and components on the helicopter have a limited life established by MDHI and approved by FAA Engineering. For example, a part with an assigned limit of 1000 hours, may accumulate 1000 hours of operation in service. Upon completion of the 1000 hours of operation, useful life of the part is ended. The finite-life assigned to different parts varies according to engineering fatigue tests, part experience, etc. The parts listed in this section must be removed from the helicopter at the finite-life indicated and identified as to its expired life (Ref, Table 1, Note (1)).
- (2). All parts not having an assigned life or stated to be of unlimited life, have a life of not less than 20,000 hours.
- (3). When a life-limited part or an assembly that incorporates a life-limited part is installed on a new or used helicopter, the nomenclature, part number, serial

number, component time and current helicopter hours are recorded in the Log Book and component log for the helicopter. Whether the life-limited part is new or used, the remaining number of useful life hours and previous inspection time, if applicable, for the part is added to the existing helicopter time. The total helicopter hours obtained then denotes the subsequent time at which the part must be removed from the helicopter or inspected.

- (4). If a life-limited part, is part of an assembly, the assembly must be removed from the helicopter when the time expires. The assembly may be overhauled and restored to maximum number of hours of useful life by installing new life-limited parts plus all other parts specified in the overhaul instructions (Refer to Component Overhaul Manual).
- (5). If interchanged between different model helicopters (for instance, Model 369D to 369FF or vice versa), any component having a limited life or overhaul schedule must be restricted to the lowest service life or TBO schedule indicated for the helicopter models and serial numbers affected.
- (6). Refer to the appropriate Allison Operation and Maintenance Manual for engine component replacement requirements.

3. Component Mandatory Inspections

Some components with mandatory inspection intervals require inspections to be completed in accordance with procedures detailed in other sections of this maintenance manual. The appropriate inspection procedures are referenced in the **Notes** flagged to each component to be inspected. All maintenance manual procedures which are referenced in the FAA Approved Airworthiness Limitations Component Mandatory Replacement Schedule are FAA approved procedures which cannot be changed without FAA review and approval of the proposed changes.

4. Retirement Index Number (RIN)

- (1). A Retirement Index Number (RIN) is a number that accounts for different usage spectra in assigning the retirement time for a component.

The RIN is calculated as the sum of an adjustment factor times flight hours plus another adjustment factor times Torque Events.

When a component reaches 1,000,000 RIN's, it has reached it's maximum life and is to be scrapped.

For external lift operators, an external load is recorded as two (2) TE's (pick-up and drop-off).

Hover taxi with no external load will typically result in no TEs.

5. Torque Event (TE)

A Torque Event (TE) is defined as:

The transition to a hover from forward flight.

Any external lift operation.

NOTE: An external lift can either be on the cargo hook, external hoist or in external baskets.

6. External Lift and Torque Event (TE) Requirements

The 369D/E/F/FF - 500/600N helicopters are multi-use helicopters. If the helicopter is used primarily for external lifts or training flights (high TE flights), there may be a reduction in inspection intervals of some components.



For safe operation of the helicopter, TE's must be recorded in the Rotorcraft Log Book. Each external lift will be recorded as two (2) TE's.

- (1). Determine the number of TE's and external lifts the helicopter accumulates per hour of flight time.
- (2). Record all TE's in Rotorcraft Log Book and continue to record all TE's.
- (3). Perform required TE inspections.

Table 1. Airworthiness Limitations Schedule

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Main Rotor System				
Blade assembly, main rotor	369D/E (5)(6)	369D21100	3530 (37)	25 (11)(20)
		369D21100-516	3530 (37)	100 (20)
		369D21100-517	2500 (31)	25 (22)
		369D21100-517	3530 (37)	100 (20)
		369D21100-523	4000 (37)	100 (20)
		369D21120-501	3530 (37)	100 (20)
		369D21120-503	3530 (37)	100 (20)
		369D21120-505	3530 (37)	100 (20)
	369F/FF (6)	369D21102	3430 (37)	25 (11)(20)
		369D21102-503	3430 (37)	100 (20)
		369D21102-517	2500 (31)	25 (22)
		369D21102-517	3430 (37)	100 (20)
		369D21102-523	4000 (37)	100 (20)
		369D21121-501	3430 (37)	100 (20)
		369D21121-503	3430 (37)	100 (20)
		369D21121-505	3430 (37)	100 (20)

Table 1. Airworthiness Limitations Schedule (Cont.)

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Blade assembly, main rotor	500N (6)	369D21102-503	3430 (37)	100 (20)
		369D21102-517	2500 (31)	25 (22)
		369D21102-517	3430 (37)	100 (20)
		369D21102-523	4000 (37)	100 (20)
		369D21121-501	3430 (37)	100 (20)
		369D21121-503	3430 (37)	100 (20)
		369D21121-505	3430 (37)	100 (20)
	600N (6)	369D21102-517 (21)	1900 (32)(37)	100 (20)
		369D21102-523	3200 (33)(37)	100 (20)
		369D21121-501	3200 (33)(37)	100 (20)
		369D21121-503	3200 (33)(37)	100 (20)
		369D21121-505	3200 (33)(37)	100 (20)
Folding pin, main rotor blade attach	369D/E/F/FF	369A1004	2850	
		369A1004-3	2850	
		369A1004-5	7600	
	500/600N	369A1004-5	7600	
Hub subassembly, main rotor	369D/E/F/FF 500N	369D21201	8900	
Pitch housing assembly, main rotor hub	369D	369D21300	9100	
		369D21300-501	9100	
	369E/F/FF 500N	369D21300-501	9100	
Retention strap assembly, main rotor hub	369D	369D21210	2770	100 (4)
		369D21210-501	2770	100 (4)
	369E/F/FF	369D21210-501	2770	100 (4)
	500/600N	369D21210-501	2770	100 (4)
Bolt – lead-lag hub, main rotor	369D	369A1220	6120	
	369D/E/F/FF 500N	369D21220	6120	
	600N	369D21220	5400 (34)	

Table 1. Airworthiness Limitations Schedule (Cont.)

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Link assembly – lead lag hub, main rotor	369D/E	369H1203-BSC (39)	5762	25 (23)
		369H1203-21 (39)	5762	25 (23)
		369H1203-31 (39)	5762	25 (11)
		369H1203-51 (39)	11080	
		369H1203-53 (40)	11080	
		369H1203-61 (39)	11080	
	369F/FF	369H1203-21 (39)	5762	25 (23)
		369H1203-31 (39)	5762	25 (11)
		369H1203-51 (39)	11080	
		369H1203-53 (40)	11080	
		369H1203-61 (39)	11080	
	500N	369H1203-51 (39)	11080	
		369H1203-53 (40)	11080	
		369H1203-61 (39)	11080	
	600N	369H1203-51 (39)	11080	
		369H1203-53 (40)	11080	
Lead lag damper – main rotor	369D	369D21400-501 M50452	6060 On Cond.	(16)
	369D/E/F/FF 500/600N	369D21400-503	On Cond.	(16)
Drive shaft, main rotor	369D/E	369D25510	5020	300 (8)
	369F/FF	369D25510	3675	300 (8)
	500N	369D25510-21	3260	300 (15)
	369D/E	369F5510	(42)	
	369F/FF	369F5510	(42)	
	500N	369F5510	(42)	
	600N	600N5510	14000 (35)	
Mast assembly, main rotor	369D/E/F/FF 500N	369D22014	10450	
	600N	369D22014	3500	

Table 1. Airworthiness Limitations Schedule (Cont.)

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Drive Shafts, Couplings and Clutches				
Drive shaft, main rotor transmission	369D/E/F	369A5510	3790	
Coupling, main transmission drive shaft	369D/E/F/FF	369H5660	4300	
	500N	369H5660	3200	
Overrunning clutch assembly	369D/E/F/FF 500/600N	369F5450–501	On Cond.	100 (24)
Sprag assembly, overrunning clutch	369D/E/F/FF	369A5364 369D25351	(3)	300 (10)
	500N	369D25351	(3)	300 (10)
	369D/E/F/FF 500/600N	369F5456	(3)	300 (17)
Drive shaft, fan	500N	500N5200	2620	
	600N	500N5200	1200 (36)	
Drive shaft, tail rotor	369D/E	369D25518	13900	
	369F/FF	369DSK152–11 369D25518–503	13900 14610	
Coupling – tail rotor drive shaft (Bendix) (NOTE: Not certified on 369FF Model) (9)	369D/E/F	369A5501	4980	
		369H92564 (7)	4980	
Anti-Torque System				
Gearshaft assembly, tail rotor input	369D/E	369D25434	12000	
	369F/FF	369D25434	3365	
Gearshaft, tail rotor output pinion	369D/E/F/FF	369D25430	7290	
Blade assembly, tail rotor	369D/E	369D21613	5200	
		369D21613–11	5140	
		369D21613–31	5140	
		369D21613–41	5140	
		369D21613–51	5140	
		369D21613–61	5140	
		369D21613–71	5140	
		369D21640–501 (38)	400	
		369D21640–503 (38)	5140	
		369D21640–505 (38)	5140	
		369D21640–507 (38)	5140	
	369F/FF	369D21606	5140	
		369D21642–501 (38)	400	
		369D21642–503 (38)	5140	
		369D21642–505 (38)	5140	
		369D21642–507 (38)	5140	

Table 1. Airworthiness Limitations Schedule (Cont.)

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Blade assembly, tail rotor (optional 4-blade)	369D/E	369D21615	10000	
		369D21641-501 (38)	400	
		369D21641-503 (38)	10000	
		369D21641-505 (38)	10000	
		369D21641-507 (38)	10000	
Hub, tail rotor	369D/E/F/FF	369A1725	3450	
Retention strap assembly, tail rotor	369D/E/F	369A1706	5100	
	369FF	369A1706-507	5100	
		369A1706-509	5100	
Blade assembly, NOTAR fan	500N	500N5310-15	7500	
		500N5310-19	7500	
	600N	500N5310-19	12500	
Hub, fan	500N	500N5352-7	7500	
		500N5352-9	7500	
	600N	500N5352-9	7500	
Tension-Torsion Strap, NOTAR®	500N	500N5311-5	(43)(44)	
	600N			
Shaft, NOTAR fan support	600N	500N5357-13	4000	
Pitch plate assembly	500/600N	500N5363-7	7500	
Tube assembly, fan pitch	500N	500N7113-3	600 (18)	
Rotating cone assembly	500N	500N3740-1	10000	
		500N3740-41	10000	
Rotating cone assembly	600N	500N3740-61	10000	
Tailboom				
Bolts, tailboom attach	369D/E/F/FF	MS21250-06014	21950	
Tailboom assembly	369D/E	369D23500	10300	
	369F/FF	369D23500-507	10300	
	500N	500N3500-19	10000	100 (14)
		500N3500-29	10000	
		500N3500-501	10000	
		500N3600-501	10000	
	600N	600N3500-503	2500 (25)	
		600N3500-505	5900	
		600N3500-507	1000	
		600N3500-509	6000 (19)	
		600N3500-511	6000 (19)	
		600N3500-513	2500 (25)	
		600N3500-515	5900	
		600N3500-517	1000	
Empennage fittings	600N	500N3530-7/8	On Cond.	100 (26)
		500N3530-9/10	On Cond.	100 (26)

Table 1. Airworthiness Limitations Schedule (Cont.)

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Vertical stabilizer assembly	369D/E	369D23600	12700	
	369F/FF	369D23600-505	3388	
Torque tube, horizontal stabilizer	500N	500N3950-5	5000	
	600N	500N3950-7 600N3950	3000 1000 (19)	
Horizontal stabilizer assembly	369D (12)	369D23601	7700	
	369E (12)	421-087-505	7700	
		421-087-905 (13)	7700	
	369F/FF (12)	421-087-503	7700	
		421-087-903	7700	
	600N	500N3910-25 500N3910-27	10000 (19) 10000 (19)	
Controls				
Longitudinal idler bellcrank assembly	369D	369A7301	6500	
		369A7301-501	6500	
	369E/F/FF	369A7301-501	6500	
	500N	369A7301-501	2870	
Idler assembly, longitudinal pitch mixer	369D/E/F/FF	369A7603	13600	
	500N	369A7603	6050	
Longitudinal control rod	500N	369A7011-13	7740	
		369A7011-15	7740	
Socket, cyclic stick	600N	369A7141	1000	8 (27)
Cyclic tube assembly	600N	369D27132-503	1200	8 (27)
Housing, collective stick	600N	369A7347	450	
Tube, collective pitch control	600N	369A7348	400	
Tube assembly, collective pitch (pilot)	600N	369H7354-3	600	
Socket, cyclic stick	600N	369A7802	1000	8 (27)
Tube, collective pitch (co-pilot)	600N	369A7809	1800	
Housing, collective stick	600N	369A7820	450	
Housing, collective stick	600N	369H7837	450	
Tube assembly, collective pitch (co-pilot)	600N	369H7838-3	1000	
Fuselage Sta. 75 controls support bracket	600N	369N2608-11	6000 (41)	
		600N2608-9	Unlimited	
Airframe				
Landing gear brace	600N	600N6010-17/19	5900 (28)	
Landing gear strut	600N	600N6022-7/8	696 (29)	
Landing gear foot	600N	600N6043-3	3900 (30)	

Table 1. Airworthiness Limitations Schedule (Cont.)

Component (1)	Model	Part Number (2)	Finite Life Hours (1)	Mandatory Inspection Hours
Floats				
Squib cartridge, used on Emergency float kit 369D292473-5, -6, -9, -10, -11, -12 NOTE: Life is based from original date of manufacture.	369D/E/F/FF 500N	12552-1 (Holex, Inc.)	5 years	
		281993 (Walter Kidde)	5 years	
		12754-1 (Holex, Inc.)	5 years	
		5003527 (Tavco)	5 years	
Stabilizer support, utility float	369D/E	369D292036	3190	
		369DSK66	3190	

NOTES:

- (1) Life-limited components interchanged between models or configurations must be restricted to the lowest service life indicated for the models or configurations affected. Life-limited components removed at retirement are to be mutilated/destroyed or conspicuously marked to prevent inadvertent return to service. Parts are applicable only on models under which a service life is listed. Life-limited components cannot be altered or permanently marked in any manner without compromising the part integrity. Part tagging or other record keeping system is required. Related component records must be updated each time component is removed from service.
- (2) Service life shown for the basic (no dash number) part numbers apply to all dash numbered versions unless otherwise indicated.
- (3) With no cargo hook attached: – No retirement life assigned (Ref. Sec. 05-10-00, Component Overhaul or Recommended Replacement Schedule).
With cargo hook attached and no separate log: – 1800 hours.
With cargo hook attached and with separate log: – 1800 hours of external load operating time when logged separately.
(For 369D/E/F/FF helicopters with 369A5364 or 369D25351 sprag assembly, Refer to AD 90-19-02.)
- (4) Inspect in accordance with Main Rotor Strap Pack Lamination Inspection at 100-hour intervals, or 25-hour intervals if 2 laminates (369D/E/F/FF – 500N) or 1 laminate (600N) have failed in any one leg or tongue area of any strap assembly. A single cracked laminate between the shoes at the outboard end of a strap pack is cause for rejection of the hub assembly
369D/E/F/FF – 500N: (Ref. Sec. 62-20-00, Main Rotor Strap Pack Lamination Inspection).
600N: (Ref. Sec. 62-20-60, Main Rotor Strap Pack Lamination Inspection).
(For 369D/E/F/FF helicopters, refer to AD 89-02-01.)
- (5) The 369D21100-513, -515, 516, 517 and -523 main rotor blades are not interchangeable with any earlier configuration blades (Basic, -505 or -509); however, the -505 and -509 blades are interchangeable and the -513 and -515 blades are interchangeable. The -505 and -509 configuration blades may be modified to the -513M configuration, which is fully compatible with the -513 blade. (For information concerning modification, contact MDHI Customer Service Department.)
- (6) For the 369D/E helicopters, the 369D21120-501, -503 main rotor blade has all the same inspections and interchangeability as the 369D21100-517 main rotor blade.
For the 369F/FF – 500N helicopters, the 369D21121-501, -503 main rotor blade has all the same inspections and interchangeability as the 369D21102-517 main rotor blade.
For the 600N helicopters, the 369D21121-501, -503 main rotor blade has all the same inspections and interchangeability as the 369D21102-523 main rotor blade.
- (7) Used with 369H90123 Rotor Brake Kit.

- (8) Inspect main rotor drive shaft every 300 hours (Ref. Sec. 63-10-00, Main Rotor Drive Shaft Inspection (300 Hour)) (Reference AD 81-26-01).
- (9) Failsafe device, P/N 369D25530 bolt and 369D25531 socket, must be used at both ends of tail rotor driveshaft in accordance with Tail Rotor Drive Shaft Installation with Bendix Couplings (Reference AD 86-20-07).
- (10) For helicopters equipped with a cargo hook, inspect overrunning clutch sprag assembly P/N 369D25351, clutch inner race P/N 369A5353 and outer race 369A5352 every 300 hours (Ref. C.O.M., Sec. 63-10-10, Overrunning Clutch Sprag Inspection (300 Hour)). To establish time in service, either clutch total time with hook attached or a separate and permanent log of external load operating time per CFR 91.417, may be used.
(For 369D/E/F/FF helicopters with 369A5364 or 369D25351 sprag assembly, Refer to AD 90-19-02.)
- (11) Inspect main rotor blade root fittings and main rotor lead-lag link assemblies every 25 hours in accordance with Main Rotor Blade Upper and Lower Root Fitting Attach Lug and Lead-Lag Link Attach Lug Inspection (25 Hour) and every 100 hours in accordance with Main Rotor Blade Upper and Lower Root, Fitting Attach Lug and Lead-Lag Link Attach Lug Inspection (100 Hour) (Ref. Sec. 62-10-00) (Reference AD 95-03-13).
- (12) Tip plates, tip weights (where applicable) and attaching hardware have no retirement life and may be reused on replacement horizontal stabilizers.
- (13) 421-087-903 and -905 require addition of tip plates, tip weights and attaching hardware before installation.
- (14) Inspect the three upper slot bridges for cracks (Ref. Sec. 05-20-00).
- (15) Inspect main rotor drive shaft every 300 hours (Ref. Sec. 63-10-00, Main Rotor Drive Shaft Inspection (300 Hour)).
- (16) Inspect for deterioration every 600 hours up to a total time of 4200 hours and every 300 hours thereafter until deterioration is sufficient to retire assembly
369D/E/FF - 500N: (Ref. Sec. 62-20-00, Main Rotor Damper and Attachments Inspection)
600N: (Ref. Sec. 62-20-60, Main Rotor Damper and Attachments Inspection).
- (17) For helicopters equipped with a cargo hook, inspect overrunning clutch sprag assembly P/N 369F5456, clutch inner race P/N 369F5455 and outer race 369F5453 every 300 hours. To establish time in service, either clutch total time with hook attached or a separate and permanent log of external load operating time may be used.
- (18) 500N7113-11 tube assembly, fan pitch is an On-Condition part and replaces the 500N7113-3 tube assembly.
- (19) Interim hours: life extension testing in progress.
- (20) Inspect upper and lower blade root fittings every 100 hours in accordance with Main Rotor Blade Upper and Lower Root, Fitting Attach Lug and Lead-Lag Link Attach Lug Inspection (100 Hour) (Ref. Sec. 62-10-00)
(For 369D/E/F/FF - 500N helicopters, Reference AD 96-10-09).
- (21) Main rotor blades, P/N 369D21102-517 with S/N 1976 thru 2100, 2106 thru 2115 are not to be installed on 600N helicopter (Reference Service Bulletin SB600N-007R2) (Reference AD 98-15-26).
- (22) Inspect main rotor blades with 600 or more hours of operation every 25 hours of helicopter operation with a 10X magnifying glass for cracking of the lower surface of the blade emanating from the root fitting and doubler at the inboard end of the blade and to detect debonding between the blade root end fitting and doubler if missing or cracked adhesive or paint is observed. (Reference Service Bulletins SB369D-195R3, SB369E-088R3, SB369F-075R3, SB500N-015R3) (Reference AD 98-15-26).
- (23) Perform Main Rotor Blade Upper and Lower Root, Fitting Attach Lug and Lead-Lag Link Attach Lug Inspection (25 Hour) up to a total time of 500 hours and every 15 hours thereafter and every 100 hours in accordance with Main Rotor Blade Upper and Lower Root Fitting, Attach Lug and Lead-Lag Link Attach Lug Inspection (100 Hour) (Ref. Sec. 62-10-00) until retirement of 369H1203-BSC and -21 Lead-Lag Link Assembly. (Reference AD 95-03-13).
- (24) Inspect clutch retainer and bearing carrier for evidence of spinning and/or wear (Ref. Sec. 05-20-20).

- (25) The 600N3500–503 tailboom may be reworked to a 600N3500–505 tailboom, and the 600N3500–513 tailboom may be reworked to a 600N3500–515 tailboom by modifying the attachment fittings to all-steel fittings.
- (26) (Ref. Sec. 05–20–00) Using a flashlight and 10X magnifying glass, inspect horizontal stabilizer mounting brackets for cracks (pay particular attention to the forward inboard legs) (Ref. Tailboom Inspection).
- (27) Sockets must be inspected for cracks every eight hours after the initial 100 hour inspection.
- (28) Log all landings: Brace life is limited to 35400 logged landings or 5900 hours flight time if landing are not logged (assumed six landings per one hour of flight time).
- (29) Log all landings: Strut life is limited to 4170 logged landings or 696 hours flight time if landing are not logged (assumed six landings per one hour of flight time).
- (30) Log all landings: Foot life is limited to 23780 logged landings or 3900 hours flight time if landing are not logged (assumed six landings per one hour of flight time).
- (31) The following main rotor blades have a finite life of 2,500 hours or 15,000 torque events*, whichever occurs first;
P/N 369D21100–517 with S/N H664, H665, H667, H669, H671, H672, H674, H676, H679, H680, H683 thru H724, H726 thru H999 and J000 thru J039, J041 thru J055 and
P/N 369D21102–517 with S/N 1976 thru 2100, 2106 thru 2115.
* TORQUE EVENT (TE) – A TE is recorded for every transition from forward flight to a hover (Reference Service Bulletins SB369D–195R3, SB369E–088R3, SB369F–075R3, SB500N–015R3).
- (32) $RIN = (200 \times Hrs.) + (52 \times TE)$.
- (33) $RIN = (160 \times Hrs.) + (24 \times TE)$.
- (34) $RIN = (153 \times Hrs.) + (3 \times TE)$.
- (35) $RIN = (50 \times Hrs.) + (3 \times TE)$.
- (36) $RIN = (768 \times Hrs.) + (11 \times TE)$.
- (37) After accumulation of 750 flight hours and 13,720 TE, perform Main Rotor Blade Torque Event Inspection (Ref. Sec. 62–10–00) every 35 flight hours or 200 TE's (whichever occurs first).
- (38) The 369D21640–501, –503, –505, –507 tail rotor blades are two-way interchangeable with the 369D21613 tail rotor blades in sets of two only.
The 369D21641–501, –503, –505, –507 tail rotor blades are two-way interchangeable with the 369D21615 tail rotor blades in sets of two only (installed on the same inboard or outboard hub).
The 369D21642–501, –503, –505, –507 tail rotor blades are two-way interchangeable with the 369D21606 tail rotor blades in sets of two only.
- (39) The 369H1203–BSC, –11, –21, –31, –51 and –61 lead lag link assemblies can only be installed using the 369H1235–BSC bearing.
- (40) The 369H1203–53 lead lag link assembly can only be installed using the 369H1235–1 bearing.
- (41) The 369N2608–11 Control Support Bracket must be removed from 600N helicopters equipped with YSAS (Ref. SB600N–040).
- (42) $RIN = (29 \times Hrs.) + (1 \times TE)$.
- (43) The tension–torsion straps have a 5 year calendar life that starts the day the package is opened (Ref. Sect 64–25–30). If the date the package was opened is unknown, the 5 year calendar life is based on the manufacturing cure date.

For straps installed before 06 March 2008 on model 500N helicopters serial numbers LN–001 thru LN–105 and Model 600N helicopters serial numbers RN003 thru RN074, the initial calendar replacement is based on the cure date on the strap. Refer to Table 2 to find the expiration date.
- (44) 500N5311–5 straps previously installed on MD900 helicopters are life limited to 2,500 hours when installed on 500N and 600N series helicopters.

Table 2. Tension-Torsion Strap Expiration Date	
Manufacturers Cure Date	Expiration Date
Before 03/1999	09/2008
03/1999 thru 02/2001	03/2009
03/2001 thru 02/2005	03/2010
03/2005 thru 02/2008	Cure Date Plus 5 Years

This page intentionally left blank!

TABLE OF CONTENTS

Para/Figure/Table	Title	Page
05-00-00 Continued Airworthiness		A
Checks/Inspections		1
1. General Description of Inspections		1
A. Airworthiness Limitations		1
B. Continued Airworthiness		1
2. Documentation		2
A. Records of Aircraft Inspection		2
B. Additional Documentation		2
3. Visual Inspection Criteria		2
A. General Visual Inspection		2
05-10-00 Continued Airworthiness		A
Component Overhaul/Recommended Replacement		1
1. Component Overhaul or Recommended Replacement Schedule		1
Table 1. Component Overhaul Schedule		1
Table 2. Component Recommended Replacement Schedule		3
05-20-00 Continued Airworthiness		A
100-Hour or Annual Inspection Checklist		1
1. 100-Hour or Annual Inspection		1
Table 1. 100-Hour or Annual Inspection		1
2. Retirement Index Numbers Attachment		11
Table 2. Permanent Record of Retirement Index Numbers/Torque Events		11
05-20-10 Continued Airworthiness		A
300-Hour Inspection Checklist		1
1. 300-Hour Inspection		1
Table 1. 300-Hour Inspection		1
05-20-15 Continued Airworthiness		A
Yearly Inspection Checklist		1
1. Yearly Inspection		1
Table 1. Yearly Inspection		1
05-20-20 Continued Airworthiness		A
Special Inspections		1
1. Special Inspection Hourly and Calendar		1
Table 1. Special Inspections Hourly		1
Table 2. Special Inspections Calendar		5

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
05-50-00	Continued Airworthiness	A
	Conditional Inspections	1
1.	General	1
2.	Hard Landing	1
3.	Overspeed	1
4.	Overtorque	1
5.	Sudden Stoppage	2
6.	Lightning Strike	2
7.	Conditional Inspection Table	2
	Table 1. Conditional Inspections	3

CONTINUED AIRWORTHINESS CONDITIONAL INSPECTIONS

1. General

This section contains the unscheduled or conditional inspections. You must do the necessary Maintenance Manual specific inspections and procedures shown in Table 1 to make sure there is continued airworthiness of the helicopter.

If there is an incident with your helicopter not shown in this section, record all information regarding the incident and speak to the Field Service Department at MDHI, Mesa, Arizona. Telephone 1-800-388-3378 or (480) 346-6387. DATAFAX: (480) 346-6813 for inspections and maintenance procedures you need to do.

It is possible you will need to do more than one of the inspections or procedures shown in Table 1 of this section. Do all inspections that are applicable.

NOTE: Refer to the applicable Rolls-Royce Engine Operation and Maintenance Manual (Ref. Section 01-00-00, Table 201) for detailed requirements on inspection of the engine for specific or unique conditions comparable to those listed.

WARNING

- **All components, assemblies, or parts that are removed for overhaul or repair must be identified with the cause for removal.**
- **All other components, assemblies, or parts that need to be replaced, must be discarded.**

2. Hard Landing

A hard landing is an incident or accident in

which the helicopter hits the ground with sufficient force to cause:

- main rotor blade to hit the tailboom or upper fairings or cowlings.
- permanent deformation of the landing gear more than permitted limits.
- the lower fuselage, lower tailboom surface, tailrotor, or thruster to touch the ground.

Use the schedule of inspections in Table 1, Conditional Inspections, After Hard Landing if you think a hard landing has occurred.

3. Overspeed

Overspeed is an incident in which the rotor speed (N_R) is more than the limits shown in the applicable Rotorcraft Flight Manual. Use the schedule of inspections in Table 1, Conditional Inspections, After Main Rotor Overspeed when an overspeed has occurred.

4. Overtorque

Overtorque is an incident in which the main transmission torque loads are more than the permitted limits. Use the schedule of inspections in Table 1, Conditional Inspections, After Main Transmission Overtorque Beyond Transient Limits when an overtorque has occurred.

5. Sudden Stoppage

Sudden stoppage is a rapid deceleration of the main rotor, rotor drive system, tail rotor, or anti-torque fan.

Sudden stoppage of the main rotor and rotor drive system is caused when the main rotor blades hit the ground, water, snow, thick vegetation, or other object of sufficient mass to cause deceleration. Sudden stoppage of the main rotor and rotor drive system can also occur during a hard landing if the blades hit the fuselage or the tailboom. Use the schedule of inspections in Table 1, Conditional Inspections, After Main Rotor Blade/Drive System Sudden Stoppage when sudden stoppage of the main rotor has occurred.

Sudden stoppage of the tail rotor is caused when the tail rotor blades hit the ground, water, snow, thick vegetation, or other object of sufficient mass to cause deceleration. Use the schedule of inspections in Table 1, Conditional Inspections, After Tail Rotor Blade Strike

when sudden stoppage of the tail rotor has occurred.

6. Lightning Strike

When you think there has been a lightening strike on the helicopter, use the schedule of inspections in Table 1, Conditional Inspections, After Lightening Strike inspection procedures.

7. Conditional Inspection Table

- Inspections in this table are for MDHI 369D/E/FF and 500/60N helicopters only. The first column of the table denotes which model helicopter the inspections are applicable to.
- The second column of the table has a short description of the necessary inspection or procedure.
- The third column of the table shows, if applicable, the manual or section that has the specific inspection or procedure.

Table 1. Conditional Inspections

Model	Requirement	Chap/Sect
AFTER HARD LANDING		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be discarded.		
ALL	Main rotor blades for bending, cracks or wrinkles.	62
ALL	Main rotor blade droop stops for damage.	62
ALL	Main rotor hub assembly and strap pack assembly for evidence of damage.	62
ALL	Accessible areas of main rotor mast assembly and transmission attachment area for damage.	63
ALL	Perform Landing Gear Inspection. Forward and aft rub plates for condition.	32-10-00
ALL	Perform Tailboom Inspection; retorque mount bolts.	53-40-00 53-40-30
ALL	Inspect tailboom attachment area for damage.	53
500/600N	Inspect stationary thruster attachment flange for damage; retorque mount bolts.	53
369D/E/FF	Tail rotor drive shaft and damper, tail rotor transmission and tail rotor for distortion, loose mounting or attaching parts, buckling, breaks or other damage. Tail rotor drive shaft for contact with bulkheads.	63 64
500/600N	Main transmission-to-fan transmission drive shaft, fan transmission, fan drive shaft, fan and fan control rod for distortion, loose mounting or attaching parts, buckling, breaks or other damage. Drive shafts for contact with bulkheads. Fan control rod for freedom of movement.	63 67
ALL	Perform Engine Mounts and Fittings Inspection. Inspect mounting pads and firewall for damage and distortion. Inspect all suspected parts by magnetic particle or dye-penetrant methods, as applicable (Ref. CSP-SRM-6).	71
ALL	All flight and engine control system push-pull tubes, links, bellcranks and bearings for bends, cracks, security and free movement.	67
ALL	Tunnel area A-frame for distortion, buckling or any other damage.	53
ALL	Fuselage fittings for bends and cracks.	53
ALL	Main transmission chip detectors for metal particles. Main transmission mounting flanges for cracks.	63
ALL	Perform Main Transmission Drive Shaft Inspection.	63-10-00
ALL	All engine accessories for cracked flanges, loose bolts and nuts, connections and general condition.	79
ALL	Engine accessory drive housing for cracks.	79
ALL	Engine chip detectors for metal particles.	79
ALL	Engine oil tank, supports, tubing and hoses for leaks, cracks and security.	79
ALL	Fuel cells, supports, tubing and hoses for leaks, cracks and security.	28
ALL	Armor for security of attachment, buckling and distortion.	CSP-014
ALL	Rotor brake installation for security of attachment and disc alignment.	63

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
AFTER MAIN ROTOR OVERSPEED		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be scrapped.		
If overspeed is between 523 and 549 (369D/E) or 508 and 533 (369FF, 500N) rpm, or 106 and 112 percent (600N):		
ALL	Main rotor blades for visible damage and distortion; main rotor blade tip caps for security; all bond lines for evidence of separation; root doublers and attachment fittings for security. Replace any blade with visible bond line separation. Main rotor blade dampers for security.	62
369D/E/FF	Tail rotor blades and hub for visible damage, free movement and security.	64
500/600N	NOTAR fan blades and hub for visible damage, free movement and security.	64
ALL	Main rotor hub and strap pack assembly for evidence of damage.	62
If overspeed is over 549 (369D/E) or 533 (369FF, 500N) rpm, or 112 percent (600N):		
ALL	Remove main rotor hub assembly for overhaul inspection.	MDHI
ALL	Remove and scrap main rotor blades.	62
500/600N	Inspect anti-torque fan assembly.	64
369D/E/FF	Remove tail rotor hub assembly for overhaul inspection.	64
AFTER MAIN TRANSMISSION OVERTORQUE BEYOND TRANSIENT LIMITS		
ALL	Main transmission for freedom of movement.	63
ALL	Main transmission chip detectors for metal particles. Re-inspect after 8 hours of operation.	63
AFTER AIRSPEED 10% BEYOND V^{NE} LIMIT		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be scrapped.		
ALL	Main rotor blades for visible damage and distortion; main rotor blade tip caps for security; all bond lines for evidence of separation; root doublers and attachment fittings for security. Replace any blade with visible bond line separation. Main rotor hub assembly and strap pack assembly for evidence of damage. Main rotor blade dampers for security.	62
369D/E/FF	Tail rotor blades and hub for visible damage, freedom of movement and security.	64
369D/E/FF	Horizontal stabilizer for skin damage and loose rivets. Tip plates and vertical stabilizer for damage to leading and trailing edges and damaged stressed side panels (no repair of side panels permitted). Mounting fittings for cracks and security. Retorque stabilizer attach bolts.	53
500/600N	Horizontal stabilizer for skin damage and loose rivets. 600N – Damage to gurney flap. Vertical stabilizers for damage to leading and trailing edges and damaged side panels. Mounting fittings for cracks and security. Retorque stabilizer attach bolts.	53

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
ALL	Tailboom for visible deformation, loose or missing rivets, cracks and security; attaching points to fuselage for cracks and security.	53
ALL	Canopy glass for security	53
<p align="center">AFTER MAIN ROTOR BLADE/DRIVE SYSTEM SUDDEN STOPPAGE</p> <p>WARNING: Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be scrapped.</p> <p>Sudden stoppage of the main rotor and rotor drive system is any rapid deceleration of the main rotor drive system. This may be caused by contact of one or more of the main rotor blades with the ground, water, snow, dense vegetation or any other object of sufficient mass to cause deceleration or impact damage to the main rotor blades.</p> <p>A main rotor blade strike in which one or more of the main rotor blades exceed the repair limits in the maintenance manual is defined as sudden stoppage.</p> <p>Sudden stoppage of the main rotor may also occur simultaneously with hard landing in which the blades contact the upper fuselage structure or the tailboom.</p> <p>The inspection requirements, After Main Rotor Drive System Sudden Stoppage – Level 1, is to be used when sudden stoppage of the main rotor drive system has occurred.</p> <p>After Main Rotor Drive System Sudden Stoppage – Level 1</p>		
ALL	Perform inspection of main rotor blades. Pay particular attention to the upper and lower root fittings and attach lug areas. If inspection determines that one or more blades have separation of the trailing edge bond, due to leading edge impact, the blade is bent or shows evidence of a significant impact, and the damage occurred with the engine running, perform the additional inspection in After Main Rotor Drive System Sudden Stoppage – Level 2.	62
ALL	Perform inspection of the main rotor hub and lead-lag link attach lugs. If the lead-lag lug is broken or the pitch housing striker strip shows evidence of contact with the main rotor hub and damage occurred the the engine running, perform the additional inspection in After Main Rotor Drive System Sudden Stoppage – Level 2.	62
ALL	Perform Main Rotor Strap Pack Lamination Inspection.	62-20-00 62-20-60
ALL	Perform Main Rotor Blade and Damper Attach Pin Disassembly and Special Inspection. If a pin is found cracked or bent and damage occurred with the engine running, perform the additional inspection in After Main Rotor Drive System Sudden Stoppage – Level 2.	62-10-00
ALL	Perform Main rotor Damper and Attachments Inspection. If damage to a damper is suspected, perform Main Rotor Damper Weight Loading and Extension Check.	62-20-00 62-20-60
ALL	Perform Main Rotor Drive Shaft Inspection. If main rotor drive shaft is rejected for broken shaft splines, straightness or sheared shaft, perform the additional inspection in After Main Rotor Drive System Sudden Stoppage – Level 2.	63-10-00
ALL	Inspect overrunning clutch sprag assembly (Ref. Detailed Inspection after Cleaning).	COM
<p>CAUTION: Kamatic couplings are a balanced unit and cannot be disassembled.</p>		
ALL	Perform a visual inspection of all power train drive shafts and couplings for distortion, breaks, cracks, contact with bulkheads and other damage.	63
ALL	Perform a visual inspection of the oil cooler blower assembly.	63

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
ALL	Check main rotor transmission for freedom of movement. Visually check main rotor transmission mounting flanges for cracks. Inspect main rotor transmission chip detectors for metal accumulation. Reinspect chip detectors after eight hours of helicopter operation.	63
ALL	Perform visual inspection of main rotor flight controls.	67
ALL	Perform visual inspection of the anti-torque system.	64
ALL	Perform visual inspection of engine mounts for security, cracks or misalignment.	71
ALL	Perform visual inspection of the engine control linkage for bends, breaks and proper alignment.	76
ALL	Inspect engine per the special inspection requirements in the appropriate Allison Operation and Maintenance Manual.	01
After Main Rotor Drive System Sudden Stoppage – Level 2		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as being removed due to Main Rotor Sudden Stoppage – Level 2. Components that require replacement must be scrapped.		
ALL	Overhaul main rotor hub.	62
ALL	Remove and scrap main rotor drive shaft.	63
ALL	Overhaul main transmission assembly (Ref. COM).	63
ALL	Remove and scrap engine-to-transmission drive shaft.	63
ALL	Overhaul overrunning clutch assembly (Ref. COM).	63
AFTER TAIL ROTOR BLADE STRIKE		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be scrapped.		
After tail rotor blade strike, inspect the following:		
369D/E/FF	If equipped with Bendix couplings, remove and scrap couplings.	63
369D/E/FF	Tail rotor blades for dents, nicks, scratches or separation of skin.	64
369D/E/FF	Tail rotor flapping hinge bolt for damage.	64
369D/E/FF	Tail rotor transmission for radial play and run-out of output shaft, cracks in mounting flanges, and chip detector for metal particles. Remove for overhaul tail rotor transmission if damage is indicated.	63
369D/E/FF	If equipped with Kamatics couplings: Perform Tail Rotor Drive Shaft Twist Inspection. Misaligned or missing stripes require removal and scrapping of drive shaft and Kamatics couplings, and an overhaul inspection of tail rotor transmission (Ref. COM).	63-15-10 63-25-10 63-25-20
369D/E/FF	Remove tail rotor drive shaft and inspect couplings for distortion and cracks; damper, damper bracket and bulkheads for damage.	63
<u>NOTE:</u> If damage in excess of allowable limits due to blade strike is noted in above areas, continue with following inspections:		
369D/E/FF	Tail rotor drive fork, pitch links, swashplate, hub and pitch control bearing housing for obvious damage.	64

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
369D/E/FF	Upper fuselage and boom tail rotor control linkage. If tail rotor control rod is damaged, ensure that all rod bulkhead grommets are in place.	67
369D/E/FF	Aft frame of tailboom for cracks and boom skin for loosened or popped rivets.	53
369D/E/FF	Main transmission chip detectors and transmission lube pump oil filter for metal particles.	63
369D/E/FF	Main rotor hub assembly and strap pack assembly for evidence of damage.	62
AFTER TAILBOOM STRIKE		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be scrapped.		
If one or more main rotor blades strike tailboom while blades are rotating, inspect following:		
ALL	Perform Main Rotor Blade Inspection.	62-10-00
ALL	If excessive damage requires replacement of main rotor blade(s), inspect complete main rotor and scissors assembly, including droop stop mechanism and strap packs, for evidence of damage.	62
369D/E/FF	Remove and inspect tail rotor drive shaft for impact damage, buckling or twisting; couplings for cracks and distortion; damper, damper bracket and bulkheads for damage.	63
369D/E/FF	If excessive damage requires replacement of tail rotor drive shaft, replace couplings and perform overhaul inspection of tail rotor transmission (Ref. COM).	63
<u>CAUTION:</u> Any tailboom damage is significant (Ref. CSP-SRM-6).		
ALL	Perform Tailboom Inspection. Dye-check or remove and scrap tailboom attach bolts.	53-40-00 53-40-30
ALL	Structure forward of tailboom attachment for evidence of sheet metal yielding or buckling. Pay particular attention for signs of buckling at right side forward of tailboom attachment (Ref. CSP-SRM-6).	53
ALL	Perform Upper Fuselage and Tailboom Control Linkage Inspection.	67
ALL	Perform Horizontal Stabilizer Inspection. Perform Vertical Stabilizer Inspection. Retorque stabilizer attach bolts.	53-50-10 53-50-30
369D/E/FF	Tail rotor assembly.	64
369D/E/FF	Tail rotor transmission for radial play and run-out of output shaft; cracks in mounted flanges and chip detector for metal particles.	64
ALL	Main rotor brake, if installed, for condition and alignment of brake disc, calipers and security of attachment.	63
If tailboom strike occurred during POWER ON condition, also inspect the following:		
ALL	Remove and inspect main rotor drive shaft, main transmission drive shaft and couplings for distortion, breaks, cracks and other damage.	63
ALL	Main transmission chip detectors and transmission lube system oil filter for metal particles. Re-inspect chip detectors and oil filter after 8 hours of engine operation. Visually check transmission mounting flanges for cracks.	63

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
ALL	Engine air inlet and plenum chamber for foreign objects; motor engine and check for unusual noise.	71 76
	Engine mounts for security, cracks or distortion.	
	Engine control linkage for bends, breaks and proper operation.	
500/600N	Inspect stationary thruster attachment flange for damage; retorque mount bolts.	53
ALL	Inspect tailboom attachment area for damage; retorque mount bolts.	53
AFTER CHIP DETECTOR LIGHT COMES ON		
ALL	Remove chip detector leads, in turn, to determine which chip detector caused indicator to light.	63 71
	Remove and inspect applicable chip detector for metal accumulation.	
ALL	If an engine chip detector caused indicator to light, refer to applicable Allison Engine Operation and Maintenance Manual.	01
ALL	If main transmission chip detector caused indicator to light, perform Main Transmission Filter Replacement.	63-21-00
ALL	If chips measure no longer than 0.125 inch (3.175 mm), drain and refill main and/or fan transmission with new oil. Recheck applicable chip detectors after 4 hours of flight.	12
AFTER ENGINE CHANGE BECAUSE OF INTERNAL ENGINE FAILURE		
NOTE: Oil coolers are NOT cleanable and must be scrapped if an engine failure produces metal and NO scavenge oil filter is installed or if a scavenge oil filter is installed and indicates a by-pass has occurred.		
ALL	Remove, flush and reinstall oil tank.	12 79
	Flush all lines, fittings and associated components.	
	Remove and reverse flush or replace engine oil cooler.	
CAUTION: Failure to bleed fuel system can result in unexpected engine flameout or power loss.		
ALL	Bleed fuel system.	28
ALL	Remove and install new scavenge oil filter element (if installed).	79
AFTER ENGINE FLAMEOUT CAUSED BY FUEL EXHAUSTION		
ALL	Bleed fuel system to remove any entrapped air.	28
AFTER ENGINE SHUTDOWN USING EMERGENCY FUEL SHUTOFF VALVE		
ALL	Bleed fuel system to remove any entrapped air.	28
AFTER MAIN TRANSMISSION CHANGE BECAUSE OF INTERNAL TRANSMISSION FAILURE		
ALL	Reverse flush or replace transmission oil cooler, all lines, fittings and associated components.	63
AFTER FUEL FILTER CAUTION LIGHT COMES ON		
ALL	Check FUEL FILTER caution light and circuit for discrepancies.	95
ALL	Perform Fuel Filter (Bypass) Caution Light Pressure Switch Test.	28-00-00

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
ALL	Remove and install new engine-driven fuel pump filter. Remove and clean gas producer fuel control filter. Clean and flush all lines and fittings. Check bypass valve per applicable Allison Engine Operation and Maintenance Manual.	01
369D/E 500N	Inspect start pump inlet screen for contamination when large amounts of foreign material are found in the engine driven fuel pump filter (or optional airframe fuel filter, if installed).	28
ALL	Perform Fuel Cell Inspection.	28-00-00
AFTER NEW OR REPLACEMENT MAIN ROTOR HUB IS INSTALLED		
ALL	Perform Main Rotor Hub Droop Angle Check.	62-20-00
BEFORE INSTALLATION OF NEW BATTERY		
ALL	Perform Battery Charging – Deep Cycling Procedure. Repeat deep cycling procedure once to ensure complete stabilization of battery.	96-05-00
AFTER MAIN TRANSMISSION DRIVE SHAFT IS REMOVED (ENGINE INSTALLED)		
ALL	Check overrunning clutch for correct oil level.	12
AFTER COOLER BLOWER IS REMOVED		
ALL	Perform Cooling Blower Inspection (Disassembled). Check belt tension and clearance after installation.	63
WHEN MAIN ROTOR DRIVE SHAFT IS REMOVED		
ALL	Perform Main Rotor Drive Shaft Inspection.	63-10-00
AFTER LIGHTNING STRIKE		
<u>WARNING:</u> Any component, assembly or detailed part that is removed for overhaul must be identified as to the reason for removal. Components that require replacement must be scrapped.		
If lightning strike is evident on helicopter exterior:		
ALL	Inspect the fuselage interior and exterior, landing gear, rotor systems and ground wire connection for burn marks, cracks, pitting or other signs of high temperature stress, to determine the lightning entry and exit points.	25 32 53
ALL	Trace the path of the lightning strike to the extent possible using a magnetometer.	
ALL	Check the magnetic compass for accuracy (the degree of inaccuracy may serve as an indicator of the severity of the strike).	95
ALL	Inspect all wiring.	96
ALL	Inspect antenna(s) for burns and pitting.	97
ALL	Inspect all electrically operated components and lighting systems for damage.	96
ALL	Inspect communications and navigation equipment for damage.	97
ALL	If the preceding inspections reveal major damage has occurred, proceed as follows: Bench test all avionics and electrical system and components.	96 97
	Perform a continuity check on all wiring and cables. Perform a Voltage Standing Wave Ratio (VSWR) check on all antennas, antenna cables and connectors.	

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
ALL	Perform specific inspection/replacements as required.	
500/600N	Check fan transmission and interconnecting drive shafts for magnetism and/or burns.	63
500/600N	If previous drive train items show magnetism, overhaul fan transmission.	COM
500/600N	Inspect anti-torque fan and components for evidence of arcing and magnetism; replace any part showing evidence of arcing or magnetism.	64
500/600N	Inspect bellcrank and control rod for any indications of arcing. Scrap parts with indications of arcing.	67
500/600N	Inspect thruster cables, bellcranks and control tubes for any indications of arcing. Scrap parts with indications of arcing.	67
500/600N	Inspect thruster rollers for any indications of arcing. Scrap parts with indications of arcing.	53
ALL	Check oil cooler blower assembly and overrunning clutch for residual magnetism; replace as necessary.	
ALL	Inspect oil cooler assembly for damage; replace as necessary.	
ALL	If previous drive train items show magnetism, overhaul transmission.	
ALL	If overrunning clutch assembly shows magnetism, remove engine and overrunning clutch and overhaul.	
ALL	Perform a ground run operational check on the aircraft. Functionally check the flight control system, and all avionics, electrical, lighting, communication, and navigation systems.	67 96 97
ALL	Repair any damage and replace damaged components as required.	
If lightning strike is evident on main rotor system:		
ALL	Inspect blades for damage such as burns, pitting, skin separation, etc. If damage is evident, scrap damaged blade(s).	62
ALL	Remove hub assembly and return for overhaul.	62
ALL	Inspect all bearings in the fixed and rotating control system located on the main rotor mast.	62
ALL	Remove transmission assembly and overhaul.	63
ALL	Inspect main rotor mast and drive shaft for evidence of burns.	63
ALL	Check drive shafts for residual magnetism. If magnetized or damaged, scrap drive shafts and remove engine for overhaul.	63 71
If lightning strike is evident on tail rotor system:		
369D/E/FF	Inspect blades for damage such as burns, pitting, skin separation, etc. If damage is evident, scrap damaged blade(s).	64
369D/E/FF	Overhaul tail rotor assembly.	COM
369D/E/FF	Scrap pitch change links and pitch change assembly.	64
369D/E/FF	Inspect bellcrank and control rod for any indications of arcing. Scrap parts with indications of arcing.	67
369D/E/FF	Overhaul tail rotor gearbox.	COM
369D/E/FF	Inspect tail rotor drive shaft and drive shaft damper for magnetism and/or burns.	63

Table 1. Conditional Inspections (Cont.)

Model	Requirement	Chap/Sect
369D/E/FF	Check oil cooler blower assembly, overrunning clutch and tail rotor drive shaft couplings for residual magnetism; replace as necessary.	63
369D/E/FF	Inspect oil cooler assembly for damage; replace as necessary.	63
369D/E/FF	If previous drive train items show magnetism, overhaul transmission.	COM
369D/E/FF	If overrunning clutch assembly shows magnetism, remove engine and overrunning clutch and overhaul.	71 COM
369D/E/FF	Inspect engine mounts and fitting for damage. Replace as necessary.	71
AFTER 369F5100 MAIN TRANSMISSION LUBRICATION PUMP IMPENDING BYPASS INDICATOR POPS		
ALL	Refer to Troubleshooting Power Train System	63-00-00
WHENEVER ENGINE IS REMOVED		
ALL	Remove fire blanket from above engine and inspect airframe above engine for evidence of cracks.	53

This Page Intentionally Left Blank

STABILIZER MAINTENANCE PRACTICES

1. Stabilizers Description

The tail surfaces consist of two verticals and a horizontal stabilizer. The tail surfaces (empennage) stabilize the helicopter and maintain it in a relatively contain level attitude and heading during autorotation and forward flight.

A. Horizontal Stabilizer Description

The horizontal stabilizer is constructed of laminated fiber glass composite ribs and skin, bonded to a formed graphite composite spar. The horizontal stabilizer includes a non-structural leading and trailing edges. hollow core spar, sparbox fittings, access panels, torque tubes, bellcranks and control rods.

On the 500N and optional on the 600N, a stability augmentation system (S.A.S.) is attached to the right-hand vertical stabilizer, the early 600N does not have a S.A.S system.

The horizontal stabilizer mounts atop the tailboom. Four eye bolts from the horizontal attach to clevis attachment points on the tailboom. Access plates are attached to the ends caps of the horizontal stabilizer and at center line for access to the control rods, S.A.S. and bellcranks. Two control rods, S.A.S. and bellcranks are routed in the center aft of the sparbox. The angle of incidence of the horizontal stabilizer is preset at -2° . An anti-collision light is mounted in the top center of the stabilizer. Position lighting provisions are provided on both ends of the stabilizers.

On the 600N without S.A.S., gurney flaps were added to the trailing edge of the horizontal for the purpose of increasing lift without increasing the stabilizer area or weight.

Refer to Section 96-40-00 for information on exterior lights and Section 67-20-30 for rigging requirements.

B. Vertical Stabilizers Description

The vertical stabilizers (upper and lower) are constructed of laminated fiber glass composite ribs and skin, bonded to a formed fiberglass composite spar. The vertical stabilizers include

a hollow core spar, retainer fittings and nonstructural leading and trailing edges.

The differences on the 600N are that the vertical stabilizers are slightly longer, the skin is thicker and on standard 600N helicopters, are both controlled by the directional control pedals. The lower vertical stabilizer angle of attack is eight degrees clockwise relative to the upper vertical stabilizer. Refer to Section 67-20-30 for flight controls linkage details.

The left vertical stabilizer is mounted to the horizontal on a torque tube fitting assembly and has approximately 6.5 inches (16.51 cm) of travel.

On the 500N and S.A.S. equipped 600N, the right vertical stabilizer, also mounted on a torque tube, is controlled by the stability augmentation system. From the fully extended to the fully retracted position on the S.A.S. actuator, the tip of the right vertical stabilizer trailing edge will travel a minimum of 2.70 inches (6.86 cm). The amount of travel is determine by the S.A.S. computer and gyro.

NOTE: The anti-torque control system must be re-rigged immediately after removal or replacement of control rods, linkages, and components or if helicopter operation reveals a rigging deficiency.

2. Vertical Stabilizer Replacement

(Ref. Figure 201, Figure 202)

A. Vertical Upper and Lower Stabilizer Removal

- (1). Remove nuts, washers, and bolts.
Remove by lifting vertical stabilizer off torque tube.

B. Vertical Upper and Lower Stabilizer Installation

- (1). Installation with Standard Hardware:



Do not over-torque nut. Over-torquing nut can crack vertical stabilizer fitting.

- (a). Install stabilizer onto torque tube fittings.

- (b). Install bolts, washers and nuts.
Torque to **30 - 40 inch-pounds**
(**3.39 - 4.52 Nm**) plus drag torque.

(2). Installation with Expandable Bolts:

CAUTION Do not over-torque nut. Over-torquing nut can crack vertical stabilizer fitting.

- (a). Install bolt with washer under bolt head and thick washer under nut.

NOTE:

- Do not remove any expanding elements from bolt.
- If 600N2012-5 spacers are not present, up to two spacers may be added to achieve proper installation.
- (b). Remove one (1) or two (2) 600N2012-5 spacers, as required) to obtain 0.005-0.035 inch (0.127-0.889 mm) gap between the washers and the vertical stabilizer, equal on each side.
- (c). Install nut and note drag torque.
- (d). Perform a break in cycle by torquing the nut to **20 - 25 inch-pounds** (**2.26 - 2.82 Nm**) plus drag torque.
- (e). Back off nut until bolt moves freely in hole.
- (f). Torque nut to **20 inch-pounds (2.26 Nm)** plus drag torque.
- (g). Check for equal gap of 0.005-0.035 inch (0.127-0.889 mm) between the washers and the vertical stabilizer.

NOTE: NAS1149C0332R or NAS1149C0363R washers may be added under the nut for adequate cotter pin engagement.

- (h). If necessary, tighten nut until cotter pin hole aligns with castellation in nut.
- (i). Install cotter pin.

3. Horizontal Stabilizer Replacement

(Ref. Figure 201 and Figure 202)

NOTE: Horizontal stabilizer can be removed with vertical stabilizers installed. Support stabilizer during removal.

A. Horizontal Stabilizer Removal

- (1). Remove seven screws securing center access plate to horizontal stabilizer.
- (2). Disconnect position light electrical interconnect.
- (3). On 500N, disconnect S.A.S. electrical interconnect.
- (4). Remove cotter pin, nut, washer and bolt from center bellcrank shaft. Index mark bellcrank with grease pencil in relationship to shaft. Disconnect bellcrank.
- (5). Remove nuts, washers and expandable bolts securing horizontal stabilizer to tailboom attachment clevis fittings. Remove horizontal stabilizer.

B. Horizontal Stabilizer Installation

NOTE: When installing horizontal stabilizer it may be necessary to loosen eye bolts and nuts to align with clevises, if so, install mounting expandable bolts first and torque per step (2). below, then torque clevis nuts to **80 - 120 inch-pounds (9.04 - 13.56 Nm)**.

- (1). Position horizontal stabilizer on tailboom attach fittings.
- (2). Install expandable bolts, washers and nut. Torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)**. Install cotter pin.
- (3). Connect position light/strobe light electrical connector.
- (4). On 500N, connect S.A.S. electrical interconnect.

CAUTION When installing bellcrank on center bellcrank shaft it is possible to be one spline tooth off in either direction, install bellcrank centered on shaft (Ref. Sec. 67-20 -30).

- (5). Connect bellcrank to center bellcrank shaft and install bolt, washers and nut. Torque nut to **30 - 40 inch-pounds (3.39 - 4.52 Nm)** and install cotter pin.
- (6). Install center access plate with seven screws and washers.

TABLE OF CONTENTS

Para/Figure/Table	Title	Page
63-00-00	Transmission and Drive System (369D/E/FF - 500/600N)	A
	Fault Isolation	101
1.	Power Train System	101
2.	Power Train System Troubleshooting	101
	Table 101. Troubleshooting Power Train System	101
	Figure 101. Power Train System	104
63-10-00	Drive Shafts / Clutches / Couplings (369D/E/FF - 500/600N)	A
	Removal/Installation	401
1.	Main Rotor Drive Shaft	401
2.	Main Rotor drive Shaft Replacement	401
	A. Main Rotor Drive Shaft Removal	401
	B. Main Rotor Drive Shaft Installation	401
	Figure 401. Main Rotor Drive Shaft Installation (Sheet 1 of 2)	402
3.	Main Transmission Drive Shaft	404
4.	Main Transmission Drive Shaft Replacement	404
	A. Main Transmission Drive Shaft Removal (Bendix and Kamatic)	404
	B. Main Transmission Drive Shaft Installation (Bendix and Kamatic)	404
	Figure 402. Main Transmission Drive Shaft Installation	405
5.	Overrunning Clutch	406
6.	Overrunning Clutch Replacement	406
	A. Overrunning Clutch Removal	406
	B. Overrunning Clutch Installation	406
	Figure 403. 369A5350 Overrunning Clutch Installation	407
	Figure 404. 369F5450 Overrunning Clutch Installation	408
7.	Overrunning Clutch Subassembly Replacement	409
	A. Overrunning Clutch Subassembly Removal	409
	B. Overrunning Clutch Subassembly Installation	410
8.	Overrunning Clutch-to-Firewall Seal	410
9.	Overrunning Clutch-to-Firewall Seal Replacement	410
10.	Main Transmission Drive Shaft Couplings	411
11.	Main Transmission Drive Shaft Coupling Replacement	411
	A. Main Transmission Drive Shaft Coupling Removal	411
	B. Main Transmission Drive Shaft Coupling Installation	411

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
12.	Tail Rotor Drive Shaft Coupling Replacement	412
A.	Tail Rotor Drive Shaft Coupling Removal	412
B.	Tail Rotor Drive Shaft Coupling Installation	412
	Figure 405. 369F5468/5469 Bolt Removal Tool	413
Inspection/Check	601
1.	369D25510 Main Rotor Drive Shaft Inspection	601
2.	600N5510 and 369F5510 Main Rotor Drive Shaft Inspection	601
	Figure 601. Main Rotor Drive Shaft Inspection	602
	Figure 602. Main Rotor Drive Shaft Overtorque Verification Stripe	603
3.	Main Transmission Drive Shaft Inspection (Bendix)	603
4.	Main Transmission Drive Shaft Inspection (Kamatic)	604
5.	Overrunning Clutch Inspection	605
6.	Overrunning Clutch-to-Firewall Seal Inspection	605
7.	Bendix Tail Rotor Drive Shaft Coupling Inspection	605
8.	Kamatic Coupling Inspection	605
9.	Main Rotor Drive Shaft Inspection (300 Hour)	605
Repairs	801
1.	Main Rotor Drive Shaft Exterior Repair	801
2.	Main Rotor Drive Shaft Corrosion Removal	802
3.	Main Transmission Drive Shaft Repair (Bendix)	802
4.	Main Transmission Drive Shaft Repair (Kamatic)	803
5.	Overrunning Clutch Repair/Overhaul	803
6.	Overrunning Clutch-to-Firewall Seal Repair	803
7.	Main Transmission Drive Shaft Coupling Corrosion Removal	803
8.	Bendix Coupling Repair	804
9.	Kamatic Coupling Repair	804

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
63-15-10 Tail Rotor Drive Shaft (369D/E/FF)		A
Removal/Installation		401
1.	Tail Rotor Drive Shaft	401
2.	Tail Rotor Drive Shaft Replacement	401
A.	Tail Rotor Drive Shaft Removal	401
B.	Tail Rotor Drive Shaft Installation with Bendix Couplings	401
	Figure 401. Tail Rotor Drive Shaft Installation (369D/E/FF) (Sheet 1 of 3)	402
	Figure 402. Tail Rotor Drive Shaft Installation (369FF)	407
C.	Tail Rotor Drive Shaft Installation with Kamatic Couplings	408
3.	Tail Rotor Drive Shaft Damper	409
4.	Tail Rotor Drive Shaft Damper Replacement	409
Inspection/Check		601
1.	Tail Rotor Drive Shaft Inspection	601
2.	Tail Rotor Drive Shaft Twist Inspection	601
	Figure 601. Tail Rotor Drive Shaft – Inspection Markings	602
	Figure 602. Tail Rotor Drive Shaft – Inspection Markings (Extended Tailboom)	603
3.	Tail Rotor Drive Shaft Damper Inspection	604
	Figure 603. Tail Rotor Drive Shaft Damper – Inspection	605
Repairs		801
1.	Tail Rotor Drive Shaft Repair Procedure	801
2.	Tail Rotor Drive Shaft Index Stripe Application	801
63-15-30 NOTAR® Anti-Torque System Drive Shafts (500/600N)		A
Maintenance Practices		201
1.	Anti-Torque System Drive Shafts	201
2.	Fan Gearbox Drive Shaft Replacement	201
A.	Fan Gearbox Drive Shaft Removal	201
B.	Fan Gearbox Drive Shaft Installation	201
3.	Fan Gearbox Drive Shaft Inspection	203
4.	Fan Gearbox Drive Shaft Repair Procedure	203
	Figure 201. Fan Gearbox and Inter-Connecting Drive Shafts	204
5.	Fan Inter-Connect Drive Shaft Replacement	205
A.	Fan Inter-Connect Drive Shaft Removal	205
B.	Fan Inter-Connect Drive Shaft Installation	205
6.	Inter-Connect Drive Shaft Inspection	205
7.	Inter-Connect Drive Shaft Repair	206
8.	Transmission and Fan Coupling Inspection	206

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
9.	Gearbox and Fan Coupling Repair	206
10.	Transmission Coupling / Fan Coupling Replacement	207
A.	Transmission Coupling / Fan Coupling Removal	207
B.	Transmission Coupling / Fan Coupling Installation	207
	Figure 202. Fan Interconnect Drive Shaft Coupling Installation	207
63-20-00	369D25100 Main Transmission (369D/E/FF - 500N)	A
	Maintenance Practices	201
1.	Main Transmission	201
2.	Main Transmission Buildup and Replacement	201
A.	Main Transmission Removal	201
	Figure 201. 369D25100 Main Transmission Installation	202
B.	Main Transmission Installation	203
3.	Main Transmission Inspection Procedure	204
4.	Main Transmission Repair Procedure	204
5.	Input Drive Assembly - Oil Leakage Repair Procedure	204
	Figure 202. Input Drive Assembly O-Ring Replacement	206
	Figure 203. Assembly Aid Tool for Input Drive	207
63-20-25	369F5100 Main Transmission (369D/E/FF - 500/600N)	A
	Maintenance Practices	201
1.	Main Transmission	201
2.	Main Transmission Replacement	201
A.	Main Transmission Removal	201
B.	Main Transmission Installation	201
	Figure 201. 369F5100 Main Transmission Installation	202
3.	Main Transmission Stripping	203
	Figure 202. 369F5100 Main Transmission Build-Up	204
4.	Main Transmission Build-Up	205
5.	Main Transmission Inspection Procedure	205
6.	Main Transmission Repair Procedure	205
7.	Input Drive Assembly - Oil Leakage Repair Procedure	206
A.	Input Pinion O-Ring Replacement	206
	Figure 203. Drive Assembly O-Ring Replacement	207
B.	Input Pinion Seal Replacement	208
8.	Main Transmission Filter Replacement	209
9.	Main Transmission Run-In Procedure	209

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
63-21-00	Main Transmission Lubrication and Cooling System	A
	(369D/E/FF - 500/600N)	A
Removal/Installation		401
1.	Main Transmission Lubrication System	401
2.	Main Transmission Lubrication Pump Replacement (369D25100 Transmission)	401
A.	Main Transmission Lubrication Pump Removal (369D25100 Transmission)	401
B.	Main Transmission Lubrication Pump Installation (369D25100 Transmission)	401
3.	Main Transmission Lubrication Pump Replacement (369F5100 Transmission)	401
A.	Main Transmission Lubrication Pump Removal (369F5100 Transmission)	401
B.	Main Transmission Lubrication Pump Installation (369F5100 Transmission)	401
	Figure 401. Main Transmission Lubrication Pump (369D25100 Transmission)	402
	Figure 402. Main Transmission Lubrication Pump (369F5100 Transmission)	403
4.	Main Transmission Filter Replacement (369D25100 Transmission)	404
5.	Main Transmission Filter Replacement (369F5100 Transmission)	404
6.	Main Transmission Scavenge Pump Replacement (369F5100 Transmission)	404
A.	Main Transmission Scavenge Pump Removal (369F5100 Transmission)	404
B.	Main Transmission Scavenge Pump Installation (369F5100 Transmission) ...	404
7.	Main Transmission Oil Cooler Bypass Valve Replacement	405
8.	Main Transmission Oil Cooler Replacement	405
A.	Main Transmission Oil Cooler Removal	405
B.	Main Transmission Oil Cooler Installation	405
	Figure 403. Main Transmission Oil Cooler Installation	406
9.	Main Transmission Oil Temperature Sender Replacement	407
10.	Main Transmission Oil Pressure Sender Replacement	407
11.	Liquid Level Plug Replacement	407
	Figure 404. Main Transmission - Cross-Section View	408
12.	Chip Detector Replacement	408

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
13.	Cooling Blower Replacement	408
A.	Cooling Blower	408
B.	Cooling Blower Removal	408
C.	Cooling Blower Installation (369D25100 Transmission)	409
	Figure 405. Cooling Blower Installation (369D25100 Transmission)	410
D.	Cooling Blower Installation (369F5100 Transmission)	411
	Figure 406. Oil Cooler Blower Installation (369F5100 Transmission)	412
E.	369H, D, E, F, and 500N – Cooling Blower Belt Tracking	413
	Figure 407. Cooling Blower Belt Tracking	413
Inspection/Check		601
1.	Lubrication System Inspection	601
2.	Cooling Blower Inspection	601
3.	Cooling Blower Inspection (Disassembled)	601
	Figure 601. Main Transmission Cooling Blower and Duct	602
4.	Cooling Blower Belt Tension Check and Adjustment	603
Repairs		801
1.	369D25630 Cooling Blower Disassembly	801
	Figure 801. 369D25630 Cooling Blower – Cross-Section View	802
2.	369D25630 Cooling Blower Reassembly	803
3.	600N5630 Cooling Blower Disassembly	804
	Figure 802. 600N5630 Cooling Blower – Cross-Section View	805
4.	600N5630 Cooling Blower Reassembly	806
5.	Cooling Blower Cleaning (Disassembled)	808
6.	Transmission and Cooling Blower Drain Tube Repair and Replacement	808
7.	Installation of Heating System and Oil Cooling Line Standoff Clamps (0003D – 0539D)	808
	Figure 803. Installation of Standoff Clamps – Heating and Oil Cooling Lines .	810

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
63-22-00 Rotor Brake (369D/E/FF - 500/600N)		A
Maintenance Practices		201
1.	Rotor Brake	201
2.	Rotor Brake Operation	201
3.	Rotor Brake Troubleshooting Procedure	201
4.	Master Cylinder Servicing	201
5.	Rotor Brake Hydraulic System Bleeding	202
6.	Rotor Brake Component Repair	203
7.	Master Cylinder Assembly Overhaul	203
8.	Caliper Assembly Overhaul	203
	Table 201. Troubleshooting Rotor Brake Installation	204
Removal/Installation		401
1.	Rotor Brake Component Access	401
2.	Master Cylinder Assembly Replacement	401
A.	Master Cylinder Assembly Removal	401
	Figure 401. Airframe-Mounted Rotor Brake Components	402
B.	Master Cylinder Assembly Installation	403
3.	Master Cylinder Linkage Assembly Replacement	403
A.	Master Cylinder Linkage Assembly Removal	403
	Figure 402. Master Cylinder Linkage Assembly	404
B.	Master Cylinder Linkage Assembly Installation	404
4.	Caliper Assembly, Brake Disc, and Drive Coupling Replacement (369D25100 Transmission)	405
A.	Caliper Assembly, Brake Disc, and Drive Coupling Removal (369D25100 Transmission)	405
	Figure 403. Transmission-Mounted Rotor Brake Components	406
B.	Caliper Assembly, Brake Disc and Drive Coupling Installation (369D25100 Transmission)	407
	Figure 404. Caliper Assembly and Brake Disc Interface (369D25100 Transmission)	408
	Figure 405. Lockwire Installation (369D25100 Transmission)	408
5.	Caliper Mounting Bracket Replacement (369D25100 Transmission)	409
A.	Caliper Mounting Bracket Removal (369D25100 Transmission)	409
B.	Caliper Mounting Bracket Installation (369D25100 Transmission)	409

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
6.	Caliper Assembly, Brake Disc, and Drive Coupling Replacement (369F5100 Transmission)	409
A.	Caliper Assembly, Brake Disc, and Drive Coupling Removal (369F5100 Transmission)	409
B.	Caliper Assembly, Brake Disc and Drive Coupling Installation (369F5100 Transmission)	410
	Figure 406. Rotor Brake Caliper Installation (369F5100 Transmission)	411
7.	Hydraulic Relief Valve Replacement	412
A.	Hydraulic Relief Valve Removal	412
B.	Hydraulic Relief Valve Installation	412
8.	Hydraulic Tube Assembly Replacement	413
A.	Hydraulic Tube Assembly Removal	413
B.	Hydraulic Tube Assembly Installation	413
9.	Rotor Brake Forward Cover Assembly Installation	413
	Inspection/Check	601
1.	Rotor Brake Assembly Inspection	601
2.	Rotor Brake Operational Check	602
	Initial Installation	901
1.	Rotor Brake Initial Installation	901
A.	Aircraft Preparation	901
B.	Installation Access	901
C.	Removing Components to be Replaced	901
D.	Angle Assembly Installation (500D)	902
E.	Master Cylinder Linkage Assembly and Mount Bracket Installation	902
	Figure 901. Locating Permanently Installed Components (Sheet 1 of 2)	903
F.	Handle Retainer Assembly Installation	905
G.	Rivnut Installation	905
	Figure 902. Rotor Brake Installation (Sheet 1 of 2)	906
H.	Window Support Channel Modification	908
I.	Caliper Mounting Bracket Initial Installation	908
J.	Caliper Assembly, Brake Disc and Drive Coupling Installation	908
	Figure 903. Modifying Window Support Channel	909
	Figure 904. Hydraulic Tube Installation	910

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
K.	Master Cylinder Assembly Initial Installation	911
	Figure 905. Positioning Master Cylinder	911
L.	Hydraulic Relief Valve Initial Installation	912
M.	Hydraulic Tube Assemblies Initial Installation	912
N.	Rotor Brake Installation Servicing	912
	Figure 906. Reworking Master Cylinder Gasket	912
O.	Installing Interior Furnishings	913
P.	Map Case Assembly Modification and Installation	913
Q.	Convenience Panel Cover Assembly Modification and Installation	913
R.	Rotor Brake Forward Cover Assembly Installation	913
	Figure 907. Modifying Map Case Panel	914
	Figure 908. Modifying Rotor Brake Cover Panel Assemblies (Sheet 1 of 2)	915
S.	Weight and Balance	917
	Table 901. Weight and Balance Data	917
63-25-10	Tail Rotor Transmission (Two and Four Blade) (369D/E/FF)	A
Maintenance Practices		201
1.	Tail Rotor Transmission	201
2.	Tail Rotor Transmission Replacement	201
	A. Tail Rotor Transmission Removal	201
	B. Tail Rotor Transmission Installation	201
	Figure 201. Tail Rotor Transmission – Stripping/Buildup	202
3.	Tail Rotor Transmission Inspection	203
	Figure 202. Replacement of Liquid Level Plug and Breather-Filler	204
4.	Tail Rotor Transmission Stripping	205
5.	Tail Rotor Transmission Buildup	205
6.	Tail Rotor Transmission Parts Replacement	205
7.	Input and Output Gearshaft Cover Oil Leak Repair	206
8.	Tail Rotor Transmission Housing Assembly Rework (PN 369D25401)	206
	Figure 203. Tail Rotor Transmission Mount Stud Limits	206
	Figure 204. Rework of Tail Rotor Transmission Housing Assembly	207

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
63-25-30	NOTAR® Anti-Torque System Fan Transmission (500/600N)	A
	Maintenance practices	201
1.	Fan Transmission	201
2.	Fan Transmission Replacement	201
A.	Fan Transmission Removal	201
B.	Fan Transmission Installation	201
	Figure 201. Fan Transmission Removal/Installation	202
3.	Fan Transmission Inspection	203
4.	Tube Support Inspection	203
5.	Fan Transmission Parts Replacement	203
	Figure 202. Fan Transmission Parts Replacement	204
63-30-00	Main Rotor Static Mast (369D/E/FF - 500/600N)	A
	Maintenance Practices	201
1.	Main Rotor Static Mast	201
2.	Main Rotor Static Mast Replacement (369D25100 Transmission Installation) ...	201
A.	Main Rotor Static Mast Removal (369D25100 Transmission Installation)	201
B.	Main Rotor Static Mast Installation (369D25100 Transmission Installation) ..	201
	Figure 201. Main Rotor Mast and Support Structure (369D25100 Transmission Installation)	202
3.	Main Rotor Static Mast Replacement (369F5100 Transmission Installation)	203
A.	Main Rotor Static Mast Removal (369F5100 Transmission Installation)	203
B.	Main Rotor Static Mast Installation (369F5100 Transmission Installation) ...	203
4.	Main Rotor Static Mast Inspection and Repair	203
	Figure 202. Main Rotor Mast and Support Structure (369F5100 Transmission Installation)	205
	Figure 203. Main Rotor Mast – Inspection and Repair	206


- Do not use clutch coupling shims under transmission input coupling. Inside diameter of clutch coupling shims, 1.260–1.270 inches (3.2004–3.2258 cm), is approximately 0.070 inch (1.778 mm) larger than inside diameter of shims used at transmission coupling. Incorrect diameters can cause an improperly seated shim, misalignment and cocked coupling.

NOTE: Transmission input coupling shims are laminated stock. Each lamination is 0.002 inch (0.051 mm) thick. Peel to thickness required.

- (4). Add sufficient shims to get a measurement of 0.010 inch (0.254 mm) minimum between bolt seating surface on coupling and transmission input shaft.
- (5). Lubricate input shaft splines with grease (CM111). Coat bolt threads with anti-seize compound (CM112). Reinstall coupling and bolt. Check coupling bolt for minimum drag of **25 inch-pounds (2.82 Nm)**. Torque bolt to **250 - 300 inch-pounds (28.25 - 33.90 Nm)** plus drag torque.
- (6). Attach drive shaft to clutch coupling with four bolts and washers. Torque

bolts to **50 - 70 inch-pounds (5.65 - 7.91 Nm)**.

- (7). Manually align drive shaft and transmission input coupling flanges:
- (8). Using feeler gage, measure gap between flanges. Gap should be 0.010 inch (0.254 mm) gap to 0.020 inch (0.508 mm) compression.
 - (a). If gap is 0.010 inch (0.254 mm) or less, attach upper end of drive shaft to transmission input coupling with four bolts and washers. Torque bolts to **50 - 70 inch-pounds (5.65 - 7.91 Nm)**.
 - (b). If gap exceeds 0.010 inch (0.254 mm), repeat step (3). thru (5). above, except install thickness of shims equal to measured gap, plus thickness that results in not more than 0.010 inch (0.254 mm) gap between coupling and drive shaft nor more than 0.020 inch (0.508 mm) compression of flexible couplings. Install four bolts and washers and torque bolts to **50 - 70 inch-pounds (5.65 - 7.91 Nm)**.
- (9). Install access door and sound insulation over main transmission drive shaft.



G63-1002B

Figure 402. Main Transmission Drive Shaft Installation

5. Overrunning Clutch

The overrunning clutch transmits power from the engine to the main transmission drive shaft. The clutch disengages the engine from the remainder of the drive system in case of engine failure and during autorotations.

The clutch contains a sprag unit that disengages automatically when N₂ rpm is less than corresponding main rotor rpm.

Repair and overhaul information for the overrunning clutch can be found in COM.

6. Overrunning Clutch Replacement

(Ref. Figure 403 or Figure 404)

A. Overrunning Clutch Removal

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM208	Barrier material

NOTE: For removal of only the internal clutch subassembly as an alternative to complete clutch removal, refer to Overrunning Clutch Subassembly Removal.

- (1). Remove engine.
- (2). Remove bolts, washers, nuts and engine shaft firewall seal from clutch.

NOTE: Removal of clutch coupling from clutch is unnecessary unless clutch is being replaced.

- (3). Remove coupling bolt, packing, clutch coupling and coupling shim(s). Keep shim(s) with coupling for reuse. Reinstall bolt and packing to prevent spillage of lubricating oil from clutch housing during final steps of removal.
- (4). On 369F5450 clutch, remove output shaft cover plate from back of engine accessory drive to gain access to clutch bolt.
 - (a). Insert tool (Ref. Figure 405) to engage bolt in back of clutch.

- (b). Insert a long 3/8 inch (9.525 mm) hex wrench, approximately 10 inches (25.4 cm) long, through tool and into back of clutch assembly.
- (c). While holding internal hex wrench [3/8 inch (9.525 mm)], turn external hex wrench [1.00 inch (2.54 cm)] counter-clockwise to remove bolt from back of clutch.
- (5). Remove nuts and washers that secure overrunning clutch; remove clutch.
- (6). If clutch is being replaced, install spare coupling bolt and O-ring or suitable plug in output shaft (clutch inner race bore) to prevent contamination during clutch handling, shipping or storage.

NOTE: Operating lubricant is an approved preservative for shipping or storage.

- (7). Wrap clutch in barrier material (CM208) to protect splined areas of shafts.

B. Overrunning Clutch Installation

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM111	Grease, aircraft
CM112	Anti-seize compound high temperature
CM125	Oil
CM126	Oil, turbine

- (1). If clutch is new, (369A5350 clutch only) drain preservative oil. Trapped oil can be removed by inverting clutch a minimum of three times. Add lubricating oil (CM125 or CM126) (Ref. Sec. 12-00-00). Temporarily install coupling bolt and packing.

NOTE: Relubricate splines on clutch input shaft and splines inside engine power and accessory gearbox with grease (CM111) prior to reinstalling overrunning clutch.

- (2). Coat clutch splines and internal splines of engine power accessory gearbox with lubricant (CM111). Insert overrunning clutch outer-race spline into engine and install six washers and nuts.
- Deleted.

TAIL ROTOR DRIVE SHAFT REMOVAL/INSTALLATION

1. Tail Rotor Drive Shaft

The tail rotor drive shaft connects the main transmission and the tail rotor transmission. The total drive shaft length is approximately 13 feet long for 369D/E and approximately 14 feet long for 369FF. Flanges at each end of the shaft attach to flexible joint couplings on the transmission shafts.

2. Tail Rotor Drive Shaft Replacement

A. Tail Rotor Drive Shaft Removal

(Ref. Figure 401, and Figure 402)

- (1). Remove (or open) tail rotor drive shaft access doors.
- (2). Remove three bolts and washers that secure tail rotor drive shaft to output shaft coupling on main transmission.
- (3). Disconnect chip detector wire from tail rotor transmission.
- (4). Detach Sta. 284.00 bellcrank from tail rotor transmission.
- (5). Remove nuts and washers that attach tail rotor transmission to tailboom.

CAUTION To prevent damage to transmission input shaft coupling during and after shaft removal, provide level support for both transmission and tail rotor, as weight of these items might buckle coupling diaphragm.

- (6). With assistance in guiding shaft through damper, remove tail rotor, tail rotor transmission and tail rotor drive shaft as an assembly. Slowly and carefully slide assembly aft until drive shaft clears tailboom.

CAUTION Do not carry or otherwise support transmission by use of coupling. Use care with removal tools to prevent scratching of coupling diaphragms.

- (7). Support assembly along its entire length, remove three coupling bolts and

washers, and remove drive shaft from tail rotor transmission.


B. Tail Rotor Drive Shaft Installation with Bendix Couplings

(Ref. Figure 401) Whenever main transmission, tail rotor transmission, forward coupling bolt and/or socket, transmission couplings or coupling shims, tail rotor drive shaft or tailboom assembly have been replaced, start installation with step (1). below. If none of these components has been replaced, and only installation is involved, start with step (7). below.

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM111	Grease, aircraft
CM112	Anti-seize compound high temperature
CM115	Grease, oscillating bearing
CM311	Coating, logo white / Thinner
CM318	Primer

NOTE: If tail rotor drive shaft is replaced for torsional buckling, replace and discard transmission output gear shaft coupling bolt and socket, and tail rotor gearbox coupling and coupling bolt.


- (1). Remove existing shims. Coat coupling splines with grease (CM111) and coupling failsafe bolt threads with anti-seize compound (CM112) before assembly. Install coupling and tighten failsafe coupling bolt to **250 - 300 inch-pounds (28.25 - 33.90 Nm) plus drag torque**. (Check coupling bolt for drag torque serviceability of 25 inch-pounds (2.82 Nm) minimum, 200 inch-pounds (22.60 Nm) maximum.)
- (2). Determine shim thickness required at forward flexible coupling:

**NOTES:**

1. DO NOT LIFT TAIL ROTOR TRANSMISSION OR DRIVE SHAFT BY COUPLING. KEEP THE ASSEMBLY ALIGNED DURING REMOVAL.
2. SHIM AS REQUIRED.
3. ADD 0.005 IN. (0.127 MM) TO MEASURED GAP FOR MINIMUM SHIM THICKNESS.
4. HOLD COUPLING AT 1.370 IN. (34.798 MM) OD ONLY, TO BOTTOM COUPLING.
5. INSTALL BOLT WITH ANTI-SEIZE COMPOUND. MINIMUM DRAG TORQUE FOR COUPLING BOLT, 25 INCH-POUNDS (2.82 NM).
6. MINIMUM 0.010 IN. (0.254 MM) STEP BETWEEN AFT END OF OUTPUT SHAFT AND SHOULDER OF FORWARD COUPLING.
7. INSTALL WITH GAP EITHER SIDE OF FAILSAFE BOLT.


G63-1005-1B

Figure 401. Tail Rotor Drive Shaft Installation (369D/E/FF) (Sheet 1 of 3)



G63-1005-2A

Figure 401. Tail Rotor Drive Shaft Installation (369D/E/FF) (Sheet 2 of 3)



G63-1005-3D

Figure 401. Tail Rotor Drive Shaft Installation (369D/E/FF) (Sheet 3 of 3)

- (a). Install minimum shim thickness on main transmission output shaft.



Bottom the flexible coupling by holding at the 1.370 inch (3.4798 cm) OD of coupling. Do not bottom coupling by pushing on drive shaft attach flange; doing so may damage coupling.

- (b). Bottom forward coupling on main transmission output shaft.
- (c). Measure step between aft end of output shaft and shoulder of flexible coupling, by bottoming coupling against shims (refer to **CAUTION** above).

NOTE: Maintain minimum 0.010 inch (0.254 mm) step between aft end of output shaft and coupling shoulder to prevent coupling bolt from bottoming on output shaft.

- (d). Install additional shims to maintain 0.010 inch (0.254 mm) minimum step as required.
- (3). Position failsafe socket on aft face of forward coupling so that three of the nine holes are indexed to the three nutplates of the coupling in such a way that maximum clearance is obtained between the bolt key and socket. Visually verify proper clearance before installing tail rotor drive shaft.
- (4). Repeat previous step to install failsafe socket on input coupling of tail rotor transmission.
- (5). Support entire length of tail rotor drive shaft and position end stamped **AFT** to align with tail rotor transmission coupling.
- (6). Install three bolts and washers to connect tail rotor transmission coupling to shaft; torque bolts to **80 - 100 inch-pounds (9.04 - 11.30 Nm) plus drag torque**.



- Ensure security of tail rotor gearbox mount studs. Maximum allowable side play at end of stud is 0.004 inch (0.102 mm), maximum allowable axial play is 0.005 inch (0.127 mm) (Ref. Sec. 63-25-10).
 - When installing tail rotor transmission and drive shaft, do not compress the forward or aft couplings as damage to the coupling could result.
- (7). With assistance, support transmission and shaft in line, for minimum deflection of coupling, and guide drive shaft carefully through tailboom and damper into position.
- (8). Secure transmission to four tailboom mounting studs (Ref. Sec. 63-25-10). Install four washers and nuts, torque nuts to **75 - 95 inch-pounds (8.47 - 10.73 Nm) plus drag torque**.
- (9). Align forward end of drive shaft with coupling on main transmission output gearshaft. Partially install two bolts as an alignment aid but do not tighten. Align drive shaft inspection markings. If any of four white stripes is indistinct or does not exist, paint (CM311) replacement stripe:
- (10). Obtain 0.010-0.020 inch (0.254-0.508 mm) gap between forward flange of tail rotor drive shaft and aft end of socket, using the following procedure:
- (a). Back off three attach bolts on forward flange of tail rotor drive shaft assembly 0.050-0.100 inch (1.270-2.540 mm).
 - (b). Push and hold tail rotor output shaft of main rotor transmission forward (into transmission) to remove end play. If rotor brake is installed, make certain that brake pucks do not restrict axial travel of tail rotor output shaft.

- (c). Remove end play in tail rotor transmission by applying force to tail rotor blades in opposite direction of operational rotation (while holding forward coupling of tail rotor drive-shaft on main transmission output shaft to prevent rotation). Do not push tail rotor drive shaft fore or aft.
- (d). Using feeler gage, measure gap between socket and flange of tail rotor drive shaft. Socket flange must be in full contact with flange of flexible coupling.
- (e). With assistance, remove tail rotor transmission and driveshaft in line for minimum deflection of coupling.
- (f). Using measured gap from step (d). above, add or remove required number of shims at tail rotor transmission input pinion shaft and coupling to obtain specified gap of 0.010-0.020 inch (0.254-0.508 mm).
- (12). With assistance, support transmission and shaft in line for minimum deflection of coupling and guide drive shaft carefully through tailboom and damper into position.
- (13). Apply primer (CM318) to the four gearbox mounting studs. Install nuts and washers while the primer is still wet; torque evenly to **75 - 95 inch-pounds (8.47 - 10.73 Nm) plus drag torque.**




Verify that a minimum of (1) one thread protrudes through each nut from the four tail rotor transmission mounting studs. If less than one thread is showing, refer to CSP-DEF-6, Structural Repair Manual, to replace with a longer MS1992A803-14 stud and insert.

- (14). Install three bolts and washers at forward end of tail rotor drive shaft to connect to forward coupling; torque bolts to **80 - 100 inch-pounds (9.04 - 11.30 Nm) plus drag torque.**
- (15). Connect electrical wire to tail rotor transmission chip detector. Torque nut to **12 - 15 inch-pounds (1.36 - 1.69 Nm).**
- (16). Coat pin of Sta. 284.00 bellcrank with grease (CM111) and insert it into bearing in tail rotor pitch control. Pivot bellcrank to align with mating hole in tail rotor transmission and install bolt, washers, nut and cotter pin.
- (17). Check transmission oil level and service as required.
- (18). Slowly rotate drive shaft and visually check to ensure shaft is not bent and for not less than 0.250 inch (6.35 mm) clearance between shaft and fairing tube at Sta. 137.5. In addition, check for minimum clearance of 0.190 inch (4.83 mm) between shaft and cooling blower scroll.
- (19). Install all access doors and covers.

NOTE:

- Maintain minimum 0.010 inch (0.254 mm) step between coupling shoulder and output shaft (Ref. step (2)).
- If less than specified gap, 0.010-0.020 inch (0.254-0.508 mm) exists under minimum shim requirements, install a maximum of one HS306-326 or HS306-326H washer on each of the four tail rotor transmission mounting studs, between gearbox housing and boom fitting. Apply primer (CM318) to both sides of washer at installation. After washer installation, repeat step (10).
- (11). Coat forward coupling splines with grease (CM111) and coupling bolt threads with antiseize compound (36) before assembly. Install coupling and torque failsafe bolt to **250 - 300 inch-pounds (28.25 - 33.90 Nm) plus drag torque.** (Check coupling bolt for drag torque serviceability of 25 inch-pounds minimum (2.82 Nm), 200 inch-pounds (22.60 Nm) maximum.)



G63-1006

Figure 402. Tail Rotor Drive Shaft Installation (369FF)

C. Tail Rotor Drive Shaft Installation with Kamatic Couplings

(Ref. Figure 401 and Figure 402) Whenever main transmission, tail rotor transmission, transmission couplings, coupling shims, tail rotor drive shaft or tailboom assembly have been replaced, start installation with step (1). below. If none of these components have been replaced, and only installation is involved, start with step (5). below.

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM111	Grease, aircraft
CM112	Anti-seize compound high temperature
CM115	Grease, oscillating bearing
CM311	Coating, logo white / Thinner
CM318	Primer

NOTE:

- Kamatic couplings do not require failsafe bolts or sockets.
- When installing 369D25501-3 Kamatic coupling, install SKCP2554-13 coupling bolt supplied with the Kamatic coupling.
- If tail rotor drive shaft is replaced for torsional buckling, replace and discard main transmission output gear shaft coupling, tail rotor gearbox coupling and both coupling bolts.

- (1). Coat coupling splines with grease (CM111) and coupling bolt threads with anti-seize compound (CM112) before assembly. Install coupling onto tail rotor gearbox and torque coupling bolt to **250 - 300 inch-pounds (28.25 - 33.90 Nm) plus drag torque** (Check coupling bolt for drag torque serviceability of 25 inch-pounds (2.82 Nm) minimum, 200 inch-pounds (22.60 Nm) maximum.)
- (2). Coat forward coupling splines with grease (CM111) and coupling bolt threads with anti-seize compound (CM112) before assembly. Install coupling onto main transmission;

torque coupling bolt to **250 - 300 inch-pounds (28.25 - 33.90 Nm) plus drag torque**. (Check coupling bolt for drag torque serviceability of 25 inch-pounds (2.82 Nm) minimum, 200 inch-pounds (22.60 Nm) maximum.)

- (3). Support entire length of tail rotor drive shaft and position end marked **AFT** to align with tail rotor transmission coupling.
- (4). Install three bolts and washers to connect tail rotor gearbox coupling to shaft; torque bolts to **80 - 100 inch-pounds (9.04 - 11.30 Nm) plus drag torque**.



Ensure security of tail rotor gearbox mount studs. Maximum allowable side play at end of stud is 0.004 inch (0.102 mm), maximum allowable axial play is 0.005 inch (0.127 mm) (Ref. Sec. 63-25-10).

- (5). With assistance, support tail rotor transmission and shaft in line, for minimum deflection of coupling, and guide drive shaft carefully through tailboom and damper into position.
- (6). Secure transmission to four tailboom mounting studs with washers and nuts; torque to **75 - 95 inch-pounds (8.47 - 10.73 Nm) plus drag torque**.
- (7). Align forward end of driveshaft with coupling on main transmission output gearshaft. Partially install two bolts as an alignment aid but do not tighten. Align drive shaft inspection markings. If any of four white stripes is indistinct or does not exist, paint replacement stripes.
- (8). Obtain 0.010-0.020 inch (0.254-0.508 mm) gap between forward flange of tail rotor drive shaft and flange of forward coupling using the following procedure:
 - (a). Ensure alignment bolts in previous step are backed off between 0.050-0.100 inch (1.270-2.540 mm).

- (b). Push and hold tail rotor output shaft of main rotor transmission forward (into transmission) to remove end play. If rotor brake is installed, ensure that brake pucks do not restrict axial travel of tail rotor output shaft.
 - (c). Remove end play in tail rotor transmission by applying force to tail rotor blades in opposite direction of operation (while holding forward coupling of tail rotor drive shaft on main transmission to prevent rotation). Do not push tail rotor drive shaft fore or aft.
 - (d). Using feeler gage, measure gap between forward coupling flange and flange of tail rotor drive shaft. Record the gap.
 - (e). With assistance, remove tail rotor transmission and driveshaft in line for minimum deflection of coupling.
 - (f). Using measured gap from step (d). above, add or remove required number of shims at tail rotor transmission input pinion shaft and coupling to obtain specified gap of 0.010-0.020 inch (0.254-0.508 mm).
- NOTE:**
- Maintain minimum 0.010 inch (0.254 mm) step between coupling shoulder and output shaft (Ref. Figure 401).
 - If less than specified gap, 0.010-0.020 inch (0.254-0.508 mm) exists under minimum shim requirements, install a maximum of one HS306-326 or HS306-326H washer on each of the four tail rotor transmission mounting studs, between gearbox housing and boom fitting. Apply primer (CM318) to both sides of washer at installation. After washer installation, repeat step (10).
- (9). Re-install coupling and torque coupling bolt to **250 - 300 inch-pounds (28.25 - 33.90 Nm) plus drag torque.**
 - (10). With assistance, support tail rotor transmission and shaft in line for minimum deflection of coupling and guide drive shaft carefully through tailboom and damper into position.
 - (11). Secure transmission to four tailboom mounting studs with washers and nuts; torque to **75 - 95 inch-pounds (8.47 - 10.73 Nm) plus drag torque.**
 - (12). Install three bolts and washers at forward coupling; torque bolts to **80 - 100 inch-pounds (9.04 - 11.30 Nm) plus drag torque.**
 - (13). Connect electrical wire to tail rotor transmission chip detector. Torque nut to **12 - 15 inch-pounds (1.36 - 1.69 Nm).**
 - (14). Coat pin of Sta. 284.00 bellcrank with grease (CM111) and insert into bearing in tail rotor pitch control. Pivot bellcrank to align with mating hole in tail rotor transmission and install bolt, washers, nut and cotter pin.
 - (15). Check transmission oil level and service as required (Ref. Sec. 12-10-00).
 - (16). Slowly rotate driveshaft and check for not less than 0.25 inch (6.35 mm) clearance between shaft and fairing tube at Sta. 137.50. In addition, check for minimum clearance of 0.190 inch (4.83 mm) between shaft and cooling blower scroll.
 - (17). Install all access doors and covers.

3. Tail Rotor Drive Shaft Damper

(Ref. Figure 603) The tail rotor drive shaft damper is a graphite-filled teflon plate that controls and limits deflection of the tail rotor drive shaft about its approximate mid-point. The damper is spring-loaded against a structural support bracket mounted on the aft section tailboom fairing. On 369FF Model helicopters, a second damper is located at Sta. 137.50 (Ref. Figure 602).

4. Tail Rotor Drive Shaft Damper Replacement

(Ref. Figure 602)

- (1). Remove boom-bolts access covers.
- (2). Remove tail rotor drive shaft.

- (3). Remove two bolts, washers, springs, thin washers, plate and spacers and damper.

NOTE: The damper at Sta. 137.50 (369FF only) has 369DSK152-13 bushings installed inside the Teflon Graphite Damper in conjunction with the spacers.

- (4). Position new damper over mounting holes in support bracket. Install plate and spacers with bolts, washers, springs and spacer washers.

CAUTION Ensure washers under bolt heads are seated against spacer when tightened. Bolts wear rapidly if clamp-up is not solid.

- (5). Adjust damper friction.

- (6). Install tail rotor drive shaft.

- (7). Displace damper so that it touches tail rotor drive shaft.

- (8). Use wire gage to measure damper to shaft clearance 180° from contact point. Minimum acceptable clearance is 0.020 inch (0.508 mm).

- (9). Repeat steps (7). and (8). above at 90° intervals from initial check point.

- (10). Install boom-bolts access covers.

- (5). Secure oil cooler outlet duct to oil cooler with four bolts, washers and nuts.
- (6). Install tee (with drain cap), elbow and tubes that run from oil cooler to oil cooler bypass valve housing, applying light coat of antiseize compound (CM112) to threads.
- (7). Install oil drain tube and fitting on tee.
- (8). Install compressor cooling duct.
- (9). Fill main transmission lubrication system (Ref. Sec. 12-00-00).

9. Main Transmission Oil Temperature Sender Replacement

(Ref. Figure 404) The oil temperature sender for the main transmission lubrication system is installed in a housing inserted in the 1/2 inch oil line to **IN** port of lubrication pump. Switch contacts close when oil temperature exceeds $240^{\circ} \pm 10^{\circ}\text{F}$ ($116^{\circ} \pm 5^{\circ}\text{C}$).

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM112	Anti-seize compound high temperature
CM726	Tape, teflon

- (1). Remove lockwire and detach electrical wire from sender terminal post. Position container for draining transmission oil cooler line. Remove two set screws securing sender within sender housing. Unscrew sender and drain oil in container. Plug housing to prevent oil drainage.
- (2). Apply a light coat of antiseize compound (CM112) or tightly wrap two or three turns of teflon tape (CM726) on tapered threads of sender. Screw temperature sender into housing; torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)**. Install set screws until light contact is made with sender. Lockwire hex of sender to drilled head of ground wire screw in sender housing. Connect electrical wire to sender terminal and

replenish transmission with oil lost (Ref. Sec. 12-00-00).

10. Main Transmission Oil Pressure Sender Replacement


(Ref. Figure 404) The main transmission oil pressure sender provides a ground to cause the **XMSN OIL PRESS** warning light to illuminate when oil Pressure is low. It also provides a ground to the running-time meter. Sender's normally-closed contacts open when oil pressure increases to 15 ± 2 psi (103 ± 14 kPa); simultaneously the sender's normally-open contacts close.

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM112	Anti-seize compound high temperature
CM726	Tape, teflon

- (1). Detach electrical wire or wires and using absorbent cloth, unscrew sender from transmission.
- (2). Apply light coat of antiseize compound (CM112) or wrap two or three turns of teflon tape (CM726) on tapered threads of sender. Screw in sender; torque to **30 - 40 inch-pounds (3.39 - 4.52 Nm)**. Connect wire; make sure that connection is clean and tight. If three wires are present, for information on connection of third wire refer to wiring diagram for running time meter.

11. Liquid Level Plug Replacement

- (1). Drain oil from transmission until oil level is well below edge of plug port (Ref. Sec. 12-00-00).
- (2). Remove safetywire from plug.
- (3). Remove plug by unscrewing counter-clockwise.
- (4). Remove and discard O-ring. Install new O-ring on plug.
- (5). Install plug by screwing clockwise. Torque plug to **80 - 90 inch-pounds (9.04 - 10.17 Nm)**; install safetywire.



63-2001

Figure 404. Main Transmission – Cross-Section View**12. Chip Detector Replacement**

(Ref. Figure 404) For removal and installation instructions, refer to Draining Main Transmission (Ref. Sec. 12-00-00). For functional test information for detector circuit, refer to Sec. 95-30-00.

13. Cooling Blower Replacement**A. Cooling Blower**

(Ref. Figure 405) The cooling blower is mounted to a bracket on the aft underside of the main transmission and coupled to the transmission input shaft by a pulley-driven

belt. The blower exhausts air through the engine oil cooler and the main transmission oil cooler. Exhaust air from transmission and engine oil coolers is directed at various external portions of the engine and engine accessories.

B. Cooling Blower Removal

(Ref. Figure 405)

- (1). Remove main transmission drive shaft and blower access door.
- (2). Remove coupling bolt, coupling, shim(s) and pulley from transmission input shaft.

- (3). Disconnect cooling blower drain tube. Loosen tie-down straps on blower duct rubber connectors and roll back connectors to disconnect ducts from cooling blower.
- (4). Cut lockwire and remove four bolts attaching mounting bracket to transmission. Remove two shims inserted between bracket and transmission pad.
- (5). Remove mounting bracket (with blower, pulley and belt) from helicopter.

NOTE: For 369D25100 transmission installation only; If equipped with 369D25626-11 mount bracket, examine bolts securing mount bracket to cooling blower assembly. If safety wired, remove and discard bolts. Replace with NAS1224-1L self-locking bolts.

- (6). Disassemble cooling blower if required.

C. Cooling Blower Installation (369D25100 Transmission)

(Ref. Figure 405)

- (1). Install pulley guard on main transmission input shaft.
- (2). With belt looped around transmission input shaft, position mounting bracket on main transmission pad and loosely install four bolts and washers. Before tightening bolts, insert two shims between bracket and transmission pad. Verify that blower scroll clears tail rotor drive shaft by at least 0.190 inch (4.83 mm). Torque bolts to **65 - 75 inch-pounds (7.34 - 8.47 Nm)**. Lockwire bolt heads after belt tension is checked.
- (3). Connect drain tube to cooling blower scroll fitting. Clamp tube to fitting with two turns of lockwire.
- (4). Roll exhaust duct rubber connectors onto scroll outlets and secure with tie-down straps (Transmission oil cooler duct and engine oil cooler duct).

CAUTION

In the following step do not use levers or other tools on belt, or in any way force belt onto pulley.


- (5). Slide pulley onto transmission input shaft to engage belt in teeth of both pulleys.
- (6). Adjust belt tension.

NOTE: Instructions in step (7). below, apply only when original shim(s) (same shim thickness) are installed and drive shaft, overrunning clutch and couplings remain unchanged. A distance of 0.010 inch (0.254 mm) between bolt seating surface on coupling and transmission input shaft is required to ensure coupling bolt will not bottom out shaft and to provide proper assembly clamp up. (Ref. Sec. 63-10-00).

CAUTION

The 0.010 inch (0.254 mm) minimum measurement between the bolt seating surface and the input shaft must be obtained to ensure proper clamp up. Warped shims or foreign material could provide a false 0.010 inch (0.254 mm) minimum measurement and improper clamp up could result during normal operation which may damage the main transmission input shaft.

- (7). Install laminated shim and coupling on transmission input shaft. Secure coupling with coupling bolt; torque to **250 - 300 inch-pounds (28.25 - 33.90 Nm) plus drag torque**.
- (8). Make sure belt tracks correctly (Ref. Cooling Blower Belt Tracking).
- (9). Install main transmission drive shaft (.Ref Sec. 63-10-00).
- (10). Install access panels.



G63-2000

Figure 405. Cooling Blower Installation (369D25100 Transmission)

D. Cooling Blower Installation (369F5100 Transmission)

(Ref. Figure 406)

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM111	Grease, aircraft
CM112	Anti-seize compound high temperature
CM425	Sealing compound
CM702	Lockwire CRES

- (1). With belt looped around driven pulley, install oil cooler fan bracket.

NOTE: NAS1304 series bolts may be used in place of NAS6604 series bolts.

- (a). Install four bolts with washers through oil cooler mounting bracket into fan bracket.
- (b). Before tightening bolts, displace cooler toward the transmission flange to eliminate slack in that direction.
- (c). Torque bolts to **70 - 90 inch-pounds (7.91 - 10.17 Nm)** and safety with lockwire (CM702).
- (d). After bolts are torqued, seal around bolt heads with sealant (CM425).

CAUTION When installing pulley and guard, make sure the spring pin in pulley is fully engaged inside hole in pulley guard. If the spring pin does not align correctly with hole in pulley guard, the torque will be incorrect.

- (2). Install pulley guard on main transmission input shaft.
- (3). With belt looped around transmission input shaft, position mounting bracket on main transmission pad and loosely install two bolts with washers from the bottom of bracket and two bolts with washers from top of bracket.
- (4). Before tightening bolts, insert two shims between bracket and transmission pad.
- (5). Verify that blower scroll clears anti-torque drive shaft by a minimum of 0.190 inch (4.826 mm).



In the following step, do not use levers or other tools on belt, or in any way force belt onto pulley.

- (6). Slide driver pulley onto transmission input shaft to engage belt in teeth of both pulleys.




The minimum of 0.010 inch (0.254 mm) measurement between the bolt seating surface and the input shaft must be obtained to ensure proper clamp-up.

- Warped shims or foreign material could provide a false 0.010 inch (0.254 mm) minimum measurement and improper clamp-up could result, which during normal operation, may damage the main transmission input shaft.
 - Do not use clutch coupling shims under transmission input coupling. Inside diameter of clutch coupling shim is different than shim used on transmission input coupling. Incorrect diameters can cause an improperly seated shim, misalignment and cocked coupling.
- (7). Torque bolts to **70 - 90 inch-pounds (7.91 - 10.17 Nm)**.
 - (8). Coat threads of coupling bolt with anti-seize compound (CM112).
 - (9). Lubricate input shaft splines and coupling splines with grease (CM111).
 - (10). Install input coupling shim and coupling on transmission input shaft with coupling bolt.
 - (11). Adjust belt tension (Ref. Cooling Blower Belt Tension Check and Adjustment).

NOTE: Check coupling bolt for a minimum of **25 inch-pounds (2.82 Nm)** drag torque.

- (12). Torque coupling bolt to **315 - 365 inch-pounds (35.59 - 41.24 Nm) plus drag torque**.
- (13). **369H, D, E, F, and 500N** - Make sure belt tracks correctly (Ref. Cooling Blower Belt Tracking).
- (14). Connect drain tube to cooling blower scroll fitting. Clamp tube to fitting with two turns of lockwire (CM702).
- (15). Roll exhaust duct rubber connectors onto scroll outlets (transmission oil cooler duct and engine oil cooler duct) and secure with tie straps.



CSP102-012D

Figure 406. Oil Cooler Blower Installation (369F5100 Transmission)

E. 369H, D, E, F, and 500N – Cooling Blower Belt Tracking

(Ref. Figure 407)

- (1). Make sure the oil cooler belt tracks correctly.
- (2). Rotate the lower driver pulley with your hand in a clockwise direction (as you look at the main rotor transmission input). Make sure the belt tracks axially away from the blower on the upper driven pulley.
- (3). Rotate the lower driver pulley by hand in a counter-clockwise direction. Make sure the belt tracks axially towards the blower on the upper driven pulley.
- (4). If the oil cooler belt does not track correctly, replace with a serviceable belt.




Figure 407. Cooling Blower Belt Tracking

63-2034

This Page Intentionally Left Blank

- (9). Remove fluid catch containers and hoses. Ensure both bleed screws are tightly closed. Raise brake handle to stowed position and engage in handle retainer assembly. Verify that caliper pistons (and attached brake pucks) are retracted when handle is raised.
- (10). Make final check of fluid level in master cylinder reservoir and replenish, if necessary. Secure gasket and cap with attaching screws.
- (11). Connect tube assembly to nipple in cap and to reducer in relief valve and tighten tube nuts.

6. Rotor Brake Component Repair

The master cylinder assembly or caliper assembly may be overhauled as necessary. Overhaul kits are available from MD Helicopters Inc. or an approved MD Helicopter service center. Other parts must be replaced when damaged or otherwise unserviceable.

7. Master Cylinder Assembly Overhaul

- (1). Remove defective master cylinder assembly.
- (2). Disassemble unit and replace defective parts with components of overhaul kit (Vendor PN 12-8310), using manufacturer's instructions supplied with kit.
- (3). Install overhauled master cylinder assembly.

8. Caliper Assembly Overhaul

- (1). Remove defective caliper assembly.
- (2). Disassemble unit and replace defective parts with components of overhaul kit (Vendor PN 12-11780), using manufacturer's instructions supplied with kit.
- (3). Install overhauled caliper assembly.

Table 201. Troubleshooting Rotor Brake Installation

Symptom	Isolating Step	Corrective Action
Brake actuating handle creeps downward under sustained force, with hydraulic fluid leakage from master cylinder assembly.	Defective master cylinder assembly.	Remove defective master cylinder assembly and replace with new unit, or overhaul and reinstall old unit.
Brake actuating handle creeps downward under sustained force, with hydraulic fluid leakage from caliper assembly.	Defective caliper assembly.	Remove defective caliper assembly and replace with new unit, or overhaul and reinstall old unit.
'Spongy' feel at brake actuating handle when force is applied.	Air in hydraulic system.	Bleed air from hydraulic system.
	Hydraulic fluid at low level in master cylinder reservoir.	Add fluid to master cylinder assembly and bleed air from hydraulic system.
Rotor brake system fails to slow rotor effectively.	Any of above components or system faults.	Follow applicable corrective action procedures.
	Brake pucks worn excessively.	Remove defective caliper assembly, replace defective pucks and reinstall repaired unit.
Brake pucks create noises, such as squeals or squeaks, when brakes are applied.	Glazed or worn brake pucks.	Remove defective caliper assembly, replace defective pucks and reinstall repaired unit.
Brake disc creates noises, such as squeals or squeaks, when brakes are applied.	Scored or damaged brake disc.	Remove defective brake disc and replace with new disc.

TABLE OF CONTENTS

Para/Figure/Table	Title	Page
64-00-00 Anti-Torque Assembly (369D/E/FF - 500/600N)		A
Fault Isolation		101
1. Tail Rotor Assembly		101
2. Anti-Torque Fan Assembly		101
Table 101. Troubleshooting Tail Rotor and Vibrations		101
64-00-05 Four-Bladed Tail Rotor Assembly Initial Installation (369D/E)		A
Initial Installation		901
1. Four-Bladed Tail Rotor Initial Installation		901
A. Tail Rotor and Transmission Initial Installation		901
B. Existing Tail Rotor and Transmission Removal		901
C. Four-Bladed Tail Rotor Transmission Build-Up		901
D. Drive Shaft, Tail Rotor Transmission and Tail Rotor Installation		901
Figure 901. Tail Rotor Index Stripe Requirements		902
E. Tail Rotor Control Over-Center Trim System Rework		903
F. Two-Bladed Over-Center Trim System Removal		903
G. Four-Bladed Over Center Trim System Initial Installation		903
Figure 902. Over Center Trim System Installation		904
H. Four-Bladed Tail Rotor Controls Rigging		906
I. Horizontal Stabilizer Tip Weight Removal		906
J. N2 and NR (Rotor) Tachometer Indicator Replacement		906
K. Four-Bladed Tail Rotor System Completion of Installation		906
L. Weight and Balance		907
Table 901. Weight and Balance Data		907
Figure 903. Bracket Installation - Sta. 78.50 Canted Wall		908
64-10-00 Tail Rotor Blades (369D/E/FF)		A
Maintenance Practices		201
1. Tail Rotor Blades		201
2. Tail Rotor Blade Inspection		201
3. Abrasion Strip Dye Penetrant and Tap Test Inspection		201
Figure 201. Tail Rotor Blade		202
Figure 202. Inspection of Tail Rotor Blade Abrasion Strip		203
4. Tail Rotor Blade Tip Cap Repair		204
Figure 203. Installation of Tip Cap-To-Tail Rotor Blade Rivets		205
5. Tail Rotor Blade Replacement Procedure		206
6. Tail Rotor Abrasion Strip Riveting		207
Figure 204. Tail Rotor Blade Abrasion Strip Riveting		208

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
7.	Tail Rotor Blade Abrasion Strip Modification	209
8.	Tail Rotor Blade Protective Tape Installation	210
	Figure 205. Tail Rotor Blade Abrasion Strip Modification	211
9.	Tail Rotor Blade Leading Edge Crack Inspection	212
A.	Tail Rotor Blades with New-Style Abrasion Strips	212
B.	Tail Rotor Blades with Old-Style Abrasion Strips	212
	Figure 206. Tail Rotor Blade Leading Edge Crack Inspection	214
64-20-00	Tail Rotor Hub and Fork (369D/E/FF)	A
	Maintenance Practices	201
1.	Tail Rotor Hub and Fork	201
2.	Tail Rotor Hub and Fork Replacement	201
A.	Tail Rotor Hub and Fork Removal	201
	Figure 201. Tail Rotor Hub and Strap Pack	202
B.	Tail Rotor Hub and Fork Installation	203
	Figure 202. Hub and Fork Assembly Installation (Two-Bladed)	204
	Figure 203. Hub and Fork Assembly Installation (Four-Bladed)	205
3.	Tail Rotor Hub and Fork Inspection	206
4.	Conical Bearing Inspection	206
5.	Elastomeric Fork Bearing Inspection	206
	Figure 204. Blade Flapping Resistance Check	207
6.	Elastomeric Bearing Care and Cleaning	207
64-25-30	Anti-Torque Fan (500/600N)	A
	Removal/Installation	401
1.	Anti-Torque Fan Assembly	401
2.	Anti-Torque Fan Replacement	401
A.	Anti-Torque Fan Removal	401
B.	Anti-Torque Fan Installation	401
3.	Anti-Torque Fan Blade Replacement	401
A.	Anti-Torque Fan Blade Removal	401
B.	Anti-Torque Fan Blade Installation	401
	Figure 401. Anti-Torque Fan	402
4.	Fan Blade Strap and Pitch Horn Replacement	403
A.	Fan Blade Strap and Pitch Horn Disassembly	403
B.	Fan Blade Strap and Pitch Horn Reassembly	403

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
5.	Retention Plate and Pitch Plate Replacement	404
A.	Retention Plate and Pitch Plate Disassembly	404
B.	Retention Plate and Pitch Plate Reassembly	404
6.	Support Shaft Replacement	404
A.	Support Shaft Disassembly	404
B.	Support Shaft Reassembly	404
7.	Fan Balance Stud Replacement	405
A.	Fan Balance Stud Removal	405
B.	Fan Balance Stud Installation	405
	Figure 402. Anti-Torque Fan Support Shaft	406
8.	Pitch Horn Counterweight Set Screw Replacement	407
	Figure 403. Pitch Horn Counterweight Set Screw Replacement	407
Inspection/Check		601
1.	Anti-Torque Fan Inspection	601
2.	Support Shaft Inspection	601
3.	Anti-Torque Fan Liner (Felt Metal Seal) Inspection	601
4.	Fan Blade Inspection (100-Hour)	601
5.	Fan Pitch Slider Inspection	602
Repairs		801
1.	Anti-Torque Fan Liner (Felt Metal Seal) Replacement	801
A.	Anti-Torque Fan Liner (Felt Metal Seal) Removal	801
B.	Anti-Torque Fan Liner (Felt Metal Seal) Installation	801
C.	Anti-Torque Fan Liner (Felt Metal Seal) Machining	801
	Figure 801. Anti-Torque Fan Liner (Felt Metal Seal)	802
	Figure 802. Anti-Torque Fan Liner Felt Metal Seal Machining	803
2.	Anti-Torque Fan Bearing Regreasing	806
	Figure 803. Fan Bearing Regreasing Procedure	806
	Figure 804. Fan Bearing Regreasing Tool (ST614)	807
64-30-00 Tail Rotor Pitch Control Assembly (369D/E/FF)		A
Maintenance Practices		201
1.	Tail Rotor Pitch Control Assembly	201
2.	Tail Rotor Pitch Control Assembly Replacement	201
A.	Tail Rotor Pitch Control Assembly Removal	201
	Figure 201. Pitch Control Assembly - Wobble Check	201
	Figure 202. Swashplate-to-Pitch Control Housing Clearance	202
B.	Tail Rotor Pitch Control Assembly Installation	202

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
3.	Tail Rotor Pitch Control Link Replacement	202
	Figure 203. Tail Rotor Pitch Control Assembly (Two-Bladed)	203
	Figure 204. Tail Rotor Pitch Control Assembly (Four-Bladed)	204
4.	Tail Rotor and Pitch Control Assembly Repair	205
5.	Tail Rotor Pitch Control Assembly Inspection	205
6.	Tail Rotor Blade Stop Inspection	206
7.	Tail Rotor Pitch Control Link Inspection	206
8.	Tail Rotor Conical Bearing Inspection	207
9.	Tail Rotor Pitch Bearing Inspection	207
10.	Tail Rotor Swashplate Bearing Regreasing	207
	Figure 205. Tail Rotor Swashplate Bearing Regreasing	207
	Figure 206. Tail Rotor Swashplate Bearing Regreasing Tool	208
	Figure 207. Tail Rotor Swashplate Holding Block	209
	Figure 208. Tang Washer Inspection and Application of Torque Stripe	210

ANTI-TORQUE FAN REMOVAL/INSTALLATION

1. Anti-Torque Fan Assembly

The purpose of the fan is to provide anti-torque control using a variable flow of air, across variable pitch blades, down the tailboom. The anti-torque fan liner, felt metal seal, provides a controlled gap between the fan and the felt metal seal for optimum efficiency of the fan during flight.

NOTE: The NOTAR® anti-torque control system must be re-rigged immediately after replacement of any component, control rods, or linkages, and if helicopter operation reveals a rigging deficiency.

2. Anti-Torque Fan Replacement

(Ref. Figure 401 and Figure 402)

Special Tools (Ref. Section 91-00-00)	
Item	Nomenclature
ST605	Fan nut socket

A. Anti-Torque Fan Removal

- (1). Remove tailboom (Ref. Sec. 53-40-30).
- (2). Remove nut and lock washer from aft tube assembly.
- (3). Remove fan pitch control tube (Ref. Sec. 67-20-30, Fan Pitch Control Tube Removal).
- (4). Remove six bolts, washers and pitch control housing from fan.
- (5). Remove lock washer from nut and shaft by releasing the holding tangs from lock nut and pull locking ring from support shaft knurl.
- (6). Remove locknut in a counter-clockwise direction, using coupling socket (ST605) and coupling holding fixture tool.
- (7). Remove washer from shaft.

- (8). Remove fan from helicopter.

B. Anti-Torque Fan Installation

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM702	Lockwire CRES

- (1). Align and install fan assembly on support shaft.
- (2). Install washer on shaft.
- (3). Install locknut and torque nut to **40 - 42 foot-pounds (54 - 57 Nm)**. Install lock washer.
- (4). Install pitch bearing housing using six bolts and washers, Torque bolts to **80 - 100 inch-pounds (9.04 - 11.30 Nm) and lockwire** (CM702).
- (5). Install fan pitch control tube (Ref. Sec. 67-20-30, Fan Pitch Control Tube Installation).
- (6). Install tailboom (Ref. Sec. 53-40-30).

3. Anti-Torque Fan Blade Replacement

(Ref. Figure 401)


NOTE: When a blade needs replacement for any reason, whether it be service related or at overhaul, replace associated bolt, washer, and nut.

A. Anti-Torque Fan Blade Removal

- (1). Remove anti-torque fan from helicopter (Ref. Anti-Torque Fan Removal).
- (2). Remove fan blade from strap assembly by removing cotter pin, washer and pin.

B. Anti-Torque Fan Blade Installation

- (1). Install fan blade and align retention hole with upper strap assembly retention hole.

**NOTE:**

1. INSTALL STRAP WITH SERIAL NUMBER FACING AFT DIRECTION.
2. INSTALL WASHER WITH COUNTERSINK AGAINST BOLT-HEAD.

G64-2005C

Figure 401. Anti-Torque Fan

- (2). Install pin, washer and cotter pin.
- (3). Reinstall anti-torque fan in helicopter (Ref. Anti-Torque Fan Installation).
- (4). Perform fan balance check (Ref. Sec. 18-20-30, Fan Balance Check).

Consumable Materials
(Ref. Section 91-00-00)

Item	Nomenclature
CM312	Ink stamp, permanent

4. Fan Blade Strap and Pitch Horn Replacement

(Ref. Figure 401) Remove and install the pitch horn and strap assembly using the following procedures.

NOTE:

- The following procedure covers the individual removal of one strap assembly and pitch horn. If disassembly of all is required, use the following steps for each one requiring removal.
- When strap is replaced, replace related bolt, washer, and nut.

A. Fan Blade Strap and Pitch Horn Disassembly

- (1). Remove anti-torque fan from helicopter (Ref. Anti-Torque Fan Removal).
- (2). Remove fan blade(s) (Ref. Anti-Torque Fan Blade Replacement).
- (3). Remove bolt and washer retaining bottom half of strap assembly between two retention plates.
- (4). Remove strap assembly thru top hole of fan hub.
- (5). Remove pitch horn from fan hub.

B. Fan Blade Strap and Pitch Horn Reassembly

NOTE: Counterweights on pitch arms are set by the factory; do not attempt to adjust.

- (1). Install pitch horn in fan assembly. Ensure ball on lower side of pitch horn is inserted in bushing of pitch plate.

NOTE: Inspect strap assembly for condition and expiration date. Pay particular attention to area around the two spools. Inspect for cracks in the polyurethane coating. If any cuts or breaks are found that exceed 0.020 inch (0.508 mm) in depth or 0.25 inch (6.35 mm) in length, replace the strap.

- Tension-torsion straps have a life limit that starts when their package is opened. If the date the package was opened is unknown, the 5 year calendar life is based on the manufacturing cure date.
- Tension-torsion straps can be put back in their package, and life limit not started, if not out of the package more than five days.

- (2). If tension-torsion strap is removed from package for no more than five days, do the steps that follow:

- (a). Replace desiccant in package, use desiccant (CM826).

NOTE: If you can not seal package; put, tension-torsion strap, package, and desiccant (CM826) in new plastic bag.

- (b). Put tension-torsion strap in package and seal package opening with tape.
- (c). Put package in box and seal box with tape.

- (3). If replacement strap is new, remove from package and write the words **EXPIRATION DATE** on the strap face and date five years after the package is opened. Use permanent ink (CM312).

- (4). Make an item component record card for each tension-torsion strap.

NOTE: Install tension-torsion straps so that the cure date is in view when fan is assembled.

- (5). Insert strap assembly thru top of fan hub and pitch horn until lower (smaller diameter) hole is aligned between holes of two retention plates.
- (6). Install blade and align spar before torquing inboard nut, this ensures proper alignment of strap with blade.
- (7). Install new bolt, washers (countersunk washer against bolt-head), and nut thru holes of retention plates and of strap assembly.

- (8). Install fan blade(s) and torque bolts to **100 inch-pounds (11.30 Nm)** (Ref. Anti-Torque Fan Blade Installation).

- (9). Reinstall anti-torque fan in helicopter (Ref. Anti-Torque Fan Replacement).
- (10). Perform fan balance (Ref. Sec. 18-20-30, Fan Balance Check).

5. Retention Plate and Pitch Plate Replacement

(Ref. Figure 401) Remove and install the retention strap and pitch plate using the following procedures.

A. Retention Plate and Pitch Plate Disassembly

- (1). Remove anti-torque fan from helicopter (Ref. Anti-Torque Fan Removal).
- (2). Remove fan blades (Ref. Anti-Torque Fan Blade Replacement).
- (3). Remove strap assemblies and pitch horns.
- (4). Remove pitch plate and retention plates from fan hub.

B. Retention Plate and Pitch Plate Reassembly

- (1). Position retention plates in fan hub.

NOTE: Install tension-torsion straps so that the cure date is in view when fan is assembled.

- (2). Install pitch horn and strap assemblies (Ref. Strap and Pitch Horn Reassembly).
- (3). Place pitch plate over retention plates within fan hub.
- (4). Install fan blades (Ref. Anti-Torque Fan Blade Installation).
- (5). Reinstall anti-torque fan in helicopter (Ref. Anti-Torque Fan Installation).

6. Support Shaft Replacement

(Ref. Figure 402) Remove and install the support shaft using the following procedures.

NOTE: When replacing pitch plate and/or support shaft bearings, do not use 900R bearings in the 500/600N helicopters.

A. Support Shaft Disassembly

- (1). Remove anti-torque fan from helicopter (Ref. Anti-Torque Fan Removal).
- (2). Remove fan pitch control tube (Ref. Sec. 67-20-30).
- (3). Remove fan interconnect driveshaft (Ref. Sec. 63-15-30).
- (4). Remove fan interconnect shaft coupling from support shaft (Ref. Sec. 63-15-30).
- (5). Remove support shaft and fan hub housing from fan support assembly by removing four cotter pins, nuts, washers and bolts.
- (6). Remove hub spacer from shaft.
- (7). Remove bearing retainer from support housing.
- (8). Press shaft and fan support bearing out of support housing.

NOTE: Removal of bearing seal at disassembly is not required unless seals need replacement.

- (9). Remove bearing seal from support housing and bearing retainer.
- (10). Press bearing off support shaft using removal ring.

B. Support Shaft Reassembly

Consumable Materials (Ref. Section 91-00-00)

Item	Nomenclature
CM111	Grease, aircraft
CM425	Sealing compound

- (1). Install removal ring on support shaft until firmly seated against shoulder of support shaft.
- (2). Install support bearing on support shaft.
- (3). Install bearing seal in support housing and bearing retainer using sealant (CM425).
- (4). Fill seal cavity with 3.3-4.0 CCs of grease (CM111).

ANTI-TORQUE FAN INSPECTION/CHECK

1. Anti-Torque Fan Inspection

Inspect the anti-torque fan for the following conditions:

- (1). All components for cracks, nicks, corrosion or excessive wear.
- (2). Tension-torsion straps for nicks or cuts in polyurethane coating. No exposed kevlar fibers allowed. Spools for cracks.
- (3). Hub-to-blade bushings for cracks.
- (4). Pitch horn for excessive wear (out-of-round condition).
- (5). Counterweights on pitch horn for security. If loose, perform Pitch Horn Counterweight Set Screw Replacement.

NOTE: Access the forward counterweights through the fan inlet. Fan hub fairing must be removed for access (Ref. Sec. 53-30-30).

- (6). Pitch plate bushing for excessive wear, grooves or cracking.
- (7). Blades for cracks, nicks or impact damage.
- (8). Inspect gap between fan blade and tip seal. Inspect gap between fan blade and hub (inboard end of the blade). If gap for any blade end exceeds the average gap of the other blades by more than 0.10 inch (2.54 mm), remove and inspect the tension-torsion strap for that blade.

2. Support Shaft Inspection

Inspect the support shaft and its associated components as follows:

NOTE: Ensure proper pitch plate and/or support shaft bearings are installed. 900R bearings are not to be used in the 500/600N helicopters.

- (1). Support shaft for:
 - (a). Cracks; none allowed.
 - (b). Wear.

(c). Scoring; axial marks from bearing installation or removal.

(d). Damaged spines; none allowed.

(e). Corrosion and pitting.

(2). Fan support bearing for free movement of set.

(3). Fan support bearing retainer and housing for:

(a). Cracks; none allowed.

(b). Wear.

(c). Scoring; axial marks from bearing installation or removal.

(4). Bearing seals for condition.

(5). Hub spacer for cracks and wear.

3. Anti-Torque Fan Liner (Felt Metal Seal) Inspection

(1). Inspect for cracks and debonding of liner material.

(2). Inspect for cracks around the radius cutouts of fan support.

(3). If cracks are found, stop drill and inspect every 50 hours (Ref. Sec. 05-20-20).

NOTE: Cracks protruding into the Felt Metal Seal are unacceptable, replace seal (Ref. Anti-Torque Fan Liner (Felt Metal Seal) Replacement).

(4). Inspect aft P-seal for tears, deterioration and debonding.

4. Fan Blade Inspection (100-Hour)

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM437	Sealing compound

- (1). Inspect polypropylene portion of fan blade for nicks, scratches, abrasions and bulges; pay particular attention to

leading edge and area around the pin near the outboard edge of blade.

- (a). Nicks and abrasion pits that are less than 0.040 inch (1.016 mm) deep and 0.25 inch (6.35 mm) in diameter may be blended out. (No more than two such repairs can be made per blade.)
- (b). Nicks, scratches and abrasion pits less than 0.020 inch (0.508 mm) and 1.5 inch (3.81 cm) long may be blended out. (Total length of all repairs not to exceed 2.0 inch (5.08 cm).)
- (2). Any bulges or blisters over 0.10 inch (2.54 mm) long in area of pin near

outboard end of blade are reason for blade rejection.

- (3). Seal cracks up to 0.10 inch (2.54 mm), coming from area of pin with sealing compound (CM437).
- (4). If any cracks larger than 0.10 inch (2.54 mm) are found, replace blade.

5. Fan Pitch Slider Inspection

- (1). Inspect slider for dents, scratches, nicks, gouges and corrosion, none allowed.
- (2). Inspect Karon coating on slider for condition.
- (3). Measure across slider, minimum diameter is 0.805 in. (20.447 mm).

ANTI-TORQUE FAN REPAIRS

1. Anti-Torque Fan Liner (Felt Metal Seal) Replacement

(Ref. Figure 801)

A. Anti-Torque Fan Liner (Felt Metal Seal) Removal

- (1). Remove tailboom (Ref Sec. 53-40-30).
- (2). Disconnect safety wire and remove nut, lockwasher, 3 bolts, washers and pitch bearing retainer plate.
- (3). Remove pitch bearing and inner pitch bearing retainer; remove pitch slider from pitch bearing housing (Ref. Sec. 67-20-30).
- (4). Remove fan assembly (Ref. Anti-Torque Fan Replacement).
- (5). Remove sealant around liner edges with plastic scraper.
- (6). Remove four screws that secure the liner to the aircraft structure.

NOTE: Mark liner to aircraft structure to ensure proper clocking upon installation. If liner is not installed in same position, felt metal seal machining will be necessary for correct fan clearance.

- (7). Carefully slide liner aft through support structure and fan support struts.

B. Anti-Torque Fan Liner (Felt Metal Seal) Installation

Consumable Materials (Ref. Section 91-00-00)

Item	Nomenclature
CM425	Sealing compound

- (1). Install fan liner so that the larger cutouts fit around the fan support struts and the smaller cutouts fit around the rivets that secure the fan inlet fairing.

NOTE: On installation of liner assembly, peel shim laminates equally among the four shims to provide a tight fit without deforming the liner at screw holes and aircraft structure.

- (2). Install four screws. Torque screws per standard aircraft practices.



Do not install sealant in butt splices of liner until after felt-metal is turned/cut to correct clearance. Doing so will damage cutting tool and cause incorrect cutting radius to liner seal.

- (3). Install sealant (CM425) in mating bores (cutouts) and around liner edges.
- (4). After installing the fan liner and before installing the fan, trim liner felt metal seal (Ref. Anti-Torque Fan Liner (Felt Metal Seal) Machining). Refer to MD Helicopter Field Service Representative for additional information.

C. Anti-Torque Fan Liner (Felt Metal Seal) Machining

(Ref. Figure 801 and Figure 802)

Special Tools (Ref. Section 91-00-00)

Item	Nomenclature
ST603	Tip seal cutter

NOTE:

- Do this procedure only after a new fan liner is installed.
- Felt metal material can cause FOD contamination.


- (1). Apply masking tape and plastic sheet to fan duct and fan diffuser areas.



Use only cutter and equipment supplied with (ST603) tip seal tool.


NOTE: Make sure (ST603) tip seal tool is clean before you install it.

- (2). Install pin (5) and spacer (6) in fan support assembly.



G64-2007

Figure 801. Anti-Torque Fan Liner (Felt Metal Seal)



CALIBRATION OF CUTTING TOOL HEIGHT

G64-2008A

- | | |
|--------------------------------|------------------------|
| 1. FAN TIP SEAL TOOL (PART 1) | 13. CAP SCREW |
| 2. CALIBRATION ARM | 14. WASHER |
| 3. CUTTER | 15. POSITION LOCK KNOB |
| 4. MOTOR COLLET | 16. ADJUSTMENT KNOB |
| 5. PIN | 17. SPEED HANDLE |
| 6. SPACER | 18. AIR PRESSURE VALVE |
| 7. THRUST BEARING | 19. BOLT |
| 8. SPACER | 20. WASHER |
| 9. NYLON WASHER | 21. NUT |
| 10. THRUST BEARING RETAINER | 22. BALL LOCK PIN |
| 11. THREADED KNOB | 23. SPACER |
| 12. FAN TIP SEAL TOOL (PART 2) | |

Figure 802. Anti-Torque Fan Liner Felt Metal Seal Machining

- (3). Install bolts (19), washers (20), and nuts (21). Torque nuts.
- (4). Put cutter (3) in motor collet (4). Do not tighten collet.
- (5). Apply a thin film of oil to inner side of pin (5) and outer side of tool (1) shaft.
- (6). Put thrust bearing (7) on tool (1) shaft.
- (7). Put tool (1) in pin (5) and push forward.
- (8). Turn tool (1) by hand and adjust cutter (3) to highest point on fan liner. Tighten collet (4).
- (9). Remove tool (1).
- (10). Remove thrust bearing (7) from tool (1) shaft.
- (11). Put calibration arm (2) on tool (1).
- (12). Measure dimension between cutter (3) and stop on calibration arm (2).
- (13). Loosen motor collet (4) and move cutter (3) out **0.040-0.050 in. (1.02-1.27 mm)** or until cutter touches stop on calibration arm (2). Tighten collet.
- (14). Loosen position lock knob (15) and turn adjustment knob (16) until cutter (3) is at aft most position. Tighten position lock knob.
- (15). Put thrust bearing (7) on tool (1) shaft.
- (16). Put tool (1) in pin (5) and push forward.
- (17). Install spacer (8), thrust bearing (7), thrust bearing retainer (10), nylon washer (9), and threaded knob (11). Tighten knob.
- (18). Put tool (12) on tool (1) and install ball lock pin (22).
- (19). Install cap screws (13), washers (14), and spacers (23). Torque cap screws.
- (20). Make sure there is no radial or axial movement in tool (1).
- (21). Lubricate tool motor, use pneumatic tool oil.

WARNING

Eye protection, a respirator, gloves, and protective clothing must be worn during fan liner machining.

- (22). Loosen position lock knob (15) and turn adjustment knob (16) to position cutter (3) for a cut of not more than one fourth width of cutter (3). Tighten lock knob.
- (23). Connect speed handle (17) to tool (12).
- (24). Connect pneumatic pressure source to tool (12).
- (25). Turn valve (18) to adjust cutter (3) speed.
- (26). Turn speed handle (17) and turn tool (1) counter-clockwise at a moderate to slow rate. Do not force cut.
- (27). After one full turn, again loosen position lock knob (15) and turn adjustment knob (16) to position cutter (3) for a cut of not more than one fourth width of cutter (3). Tighten lock knob.
- (28). Do step (27). again and again until fan liner is fully machined.
- (29). Disconnect pneumatic pressure source to tool (12).
- (30). Disconnect speed handle (17) from tool (12).
- (31). Remove cap screws (13), washers (14), and spacers (23).
- (32). Remove ball lock pin (22) and tool (12).
- (33). Remove threaded knob (11), nylon washer (9), thrust bearing retainer (10), thrust bearing (7), and spacer (8).
- (34). Remove tool (1).
- (35). Remove thrust bearing (7) from tool (1) shaft.

NOTE: The following clearance may vary because of variations in blade length.

- (36). Install fan assembly and check for a **0.10 in. (2.54 mm) maximum** clearance between fan blade ends and felt metal seal.

- (37). In step (13). did cutter touch stop on calibration arm?
 - (a). No, go to step (11).
 - (b). Yes, go to step (38).
- (38). Remove nuts (21), washers (20), and bolts (19).
- (39). Remove pin (5) and spacer (6) from fan support assembly.
- (40). Clean fan duct and diffuser areas and remove masking tape and plastic sheet.

NOTE: The anti-torque control system must be re-rigged immediately after removal or replacement of control rods, linkages and components or if helicopter operation reveals a rigging deficiency.

- (41). Install fan assembly (Ref. Anti-Torque Fan Replacement).
- (42). Install interconnect driveshaft (Ref. Sec. 63-15-30).
- (43). Install fan pitch control rod (Ref. Sec. 67-20-30).
- (44). Install pitch slider and inner pitch bearing retainer (Ref. Sec. 67-20-30).
- (45). Install tailboom (Ref. Sec. 53-40-30).

2. Anti-Torque Fan Bearing Regreasing**Special Tools**
(Ref. Section 91-00-00)

Item	Nomenclature
ST614	Fan bearing regreasing tool

(Ref. Figure 803 and Figure 804) The following procedure is for the regreasing of the 500N5364 and 500N7120 bearings.

Consumable Materials
(Ref. Section 91-00-00)

Item	Nomenclature
CM111	Grease, aircraft

NOTE:

- Ensure proper pitch plate and shaft support bearings are installed. 900R bearings are not to be used in the 500/600N helicopters.
- Refer to Figure 804 for instructions on the manufacture of a regreasing tool.

- (1). Remove bearings from fan assembly (Ref. Support Shaft Disassembly).


- (2). Carefully remove both seals from bearings (seals will be reused at reassembly).
- (3). Inspect seals for damage; no damage is allowed.
- (4). Install bearings between regreasing tools with a 4 inch (10 cm) 10-24 threaded bolt, washers and wing nut.

NOTE: The following procedure provides 100% grease fill. Normal grease fill is 30 to 50%. Excess grease will extrude past seals for several hours of operation until the proper level is met.

- (5). Purge bearing with grease (CM111) until clean grease protrudes from all four holes in back of tool.
- (6). Remove regreasing tool.
- (7). Hand spin bearing to purge excess grease.


NOTE: Ensure seals are serviceable. If new seals are required, seals and bearings must come from the same vendor.

- (8). Carefully install seals.
- (9). Reinstall bearings (Ref. Support Shaft Reassembly).



G64-2010A

Figure 803. Fan Bearing Regreasing Procedure



NOTES:

1. DIMENSION MAY VARY DEPENDING ON SEAL MATERIAL THICKNESS AVAILABLE.
2. ALL OTHER DIMENSIONS SAME AS PART A.

MATERIALS:

1. 6061-T651 ALUMINUM PER QQ-A-250/11 OR EQUIVALENT.
2. SURFACE FINISH 125 RMS.
3. BREAK SHARP EDGES 0.002-0.015 IN. (0.0508-0.381 MM).
4. CHEMICAL FILM TREAT PER MIL-C-5541.
5. DIMENSION TOLERANCE ± 0.010 IN. (± 0.254 MM).
6. GROOVE DIAMETERS TO BE CONCENTRIC TO 0.188 IN. 4.7752 MM) DIA WITHIN 0.002 IN. (0.0508 MM).

QUANTITY	STOCK SIZE	DESCRIPTION
1	4 x 4 x .50	PLATE
1	4 x 4 x .50	PLATE
1	AN23-64	BOLT
2	AN960D10L	WASHER
1	AN315-3R	NUT
2	MS15002-1	GREASE FITTING
1	M6855/2	RUBBER

G64-2009B

Figure 804. Fan Bearing Regreasing Tool (ST614)

This Page Intentionally Left Blank

TABLE OF CONTENTS

Para/Figure/Table	Title	Page
67-00-00 Flight Controls (369D/E/FF - 500/600N)		A
Fault Isolation		101
1.	Main Rotor Flight Control System Troubleshooting	101
2.	Anti-Torque Flight Controls	101
3.	Anti-Torque and Control System Troubleshooting	101
4.	Stability Augmentation System Troubleshooting	101
	Table 101. Troubleshooting Main Rotor Controls	102
	Table 102. Isolating Main Rotor Control System Troubles	103
	Table 103. Isolating Tail Rotor Control System Troubles	104
	Table 104. Anti-torque Fan System Troubleshooting	104
	Figure 101. YSAS Electrical Diagram (Sheet 1 of 2)	105
	Figure 102. YSAS Troubleshooting (Sheet 1 of 4)	107
	Figure 103. YSAS Ground Test Box	111
67-10-00 Main Rotor Flight Controls (369D/E/FF - 500/600N)		A
Description and Operation		1
1.	Main Rotor Flight Controls	1
A.	Collective Mixer, Lateral and Longitudinal Mixer (Tunnel-Routed) Control Rods	1
B.	Controls Support Bracket and Bellcranks	1
C.	Collective Controls	1
D.	Pilot's Collective Pitch Stick	1
E.	Copilot's Collective Pitch Stick	1
F.	Collective Pitch Stick Friction	1
G.	Collective Control Interconnecting Torque Tube	2
H.	Collective Bungee	2
I.	Inboard Collective Stick Socket Assembly	2
J.	Cyclic Controls	2
K.	Pilot's Cyclic Control Stick	2
L.	Copilot's Cyclic Control Stick	3
M.	Pilot's Compartment Lateral and Longitudinal Cyclic Control Linkage	3
N.	One-Way Lock Control System	3
O.	Cyclic Trim Actuators	3
P.	Roof-Mounted Control Rods (600N)	3
Q.	Roof-Mounted Bellcranks (600N)	3
	Figure 1. Main Rotor and Control System (369D/E/FF - 500N)	4
	Figure 2. Main Rotor and Control System (600N)	5

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
Removal/Installation		401
1.	Tunnel-Routed Control Rod Replacement	401
A.	Tunnel-Routed Control Rod Removal	401
B.	Tunnel-Routed Control Rod Installation	401
2.	Roof-Mounted Control Rod Replacement (600N)	401
A.	Roof-Mounted Control Rod Removal (600N)	401
	Figure 401. Tunnel-Routed Control Rod Installation	402
	Figure 402. Roof-Mounted Controls Installation	403
B.	Roof-Mounted Control Rod Installation (600N)	403
3.	Roof-Mounted Bellcrank Replacement (600N)	403
A.	Roof-Mounted Bellcrank Removal (600N)	403
B.	Roof-Mounted Bellcrank Installation (600N)	404
4.	Link Assembly Replacement (600N)	404
A.	Link Assembly Removal (600N)	404
B.	Link Assembly Installation (600N)	404
5.	Controls Support Bracket and Bellcrank Replacement	404
A.	Controls Support Bracket and Bellcrank Removal	404
	Figure 403. Controls Support Bracket, Idler Bellcranks and Cyclic Trim Actuators Installation	405
B.	Controls Support Bracket and Bellcrank Installation	406
6.	Pilot's Collective Pitch Stick Replacement (L/H Command)	406
A.	Pilot's Collective Pitch Stick Removal (L/H Command)	406
	Figure 404. Dual Collective Controls (L/H Command)	407
B.	Pilot's Collective Pitch Stick Installation (L/H Command)	408
7.	Pilot's Collective Pitch Stick Replacement (R/H Command)	408
A.	Pilot's Collective Pitch Stick Removal (R/H Command)	408
B.	Pilot's Collective Pitch Stick Installation (R/H Command)	408
	Figure 405. Dual Collective Controls (R/H Command)	409
8.	Copilot's Collective Pitch Stick Replacement (L/H Command)	410
A.	Copilot's Collective Pitch Stick Removal (L/H Command)	410
B.	Copilot's Collective Pitch Stick Installation (L/H Command)	410
	Figure 406. CoPilot's Collective Stick Assembly Installation (L/H Command)	410
9.	Copilot's Collective Pitch Stick Replacement (R/H Command)	411
A.	Copilot's Collective Pitch Stick Removal (R/H Command)	411
B.	Copilot's Collective Pitch Stick Installation (R/H Command)	411

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
10.	Collective Control Interconnecting Torque Tube Replacement	411
A.	Collective Control Interconnecting Torque Tube Removal	411
B.	Collective Control Interconnecting Torque Tube Installation	412
11.	Collective Bungee Replacement	412
A.	Collective Bungee and Over-Center Fitting - Removal	412
	Figure 407. Collective Torque Tube, Gas Producer Torque Tube and Collective Bungee	413
	Figure 408. Inboard Collective Stick Socket Assembly (L/H Command)	414
B.	Collective Over-Center Fitting and Bungee - Installation and Preliminary Adjustment	415
12.	Inboard Collective Stick Socket Assembly Replacement	415
A.	Inboard Collective Stick Socket Assembly Removal	415
B.	Inboard Collective Stick Socket Assembly Installation	415
13.	Cyclic Control Stick Replacement (Inboard)	416
A.	Cyclic Control Stick Removal (Inboard)	416
B.	Cyclic Control Stick Installation (Inboard)	416
	Figure 409. Cyclic Stick Assembly Installation (Inboard)	417
14.	Cyclic Control Stick Replacement (Outboard)	417
A.	Cyclic Control Stick Removal (Outboard)	417
B.	Cyclic Control Stick Installation (Outboard)	417
	Figure 410. Cyclic Stick Assembly Installation (Outboard)	418
15.	Lateral Control Rods and Sta. 67 Lateral Cyclic Bellcrank Replacement (L/H Command)	418
A.	Lateral Control Rods and Sta. 67 Lateral Cyclic Bellcrank Removal (L/H Command)	418
B.	Lateral Control Rods and Sta. 67 Lateral Cyclic Bellcrank Installation (L/H Command)	418
	Figure 411. Cyclic Controls (R/H Command)	419
16.	Lateral Control Rods and Sta. 67 Lateral Cyclic Bellcrank Replacement (R/H Command)	420
A.	Lateral Control Rods and Sta. 67 Lateral Cyclic Bellcrank Removal (R/H Command)	420
B.	Lateral Control Rods and Sta. 67 Lateral Cyclic Bellcrank Installation (R/H Command)	420
17.	Cyclic Pitch Interconnecting Torque Tube Replacement (L/H Command)	420
A.	Cyclic Pitch Interconnecting Torque Tube Removal (L/H Command)	420
	Figure 412. Cyclic Torque Tube and One-Way Lock Installation	421
B.	Cyclic Pitch Interconnecting Torque Tube Installation (L/H Command)	422

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
18.	Cyclic Pitch Interconnecting Torque Tube Replacement (R/H Command)	422
A.	Cyclic Pitch Interconnecting Torque Tube Removal (R/H Command)	422
B.	Cyclic Pitch Interconnecting Torque Tube Installation (R/H Command)	422
19.	One-Way Lock Replacement	422
A.	One-Way Lock Removal	422
B.	One-Way Lock Installation	423
20.	Cyclic Trim Actuator Replacement	423
A.	Cyclic Trim Actuator Removal	423
B.	Cyclic Trim Actuator Installation	423
Adjustment/Test		501
1.	Cyclic and Collective Control System Rigging	501
2.	Collective Controls Rigging (L/H Command) (369D/E/FF – 500N)	501
	Figure 501. Main Rotor Control System Rigging (369D/E/FF – 500N) (Sheet 1 of 3)	502
	Figure 502. Rigging Main Rotor Control System (600N) (Sheet 1 of 3)	505
	Figure 503. Cyclic and Collective Controls Rigging Tools (R/H Command)	508
3.	Collective Controls Rigging (R/H Command) (369D/E/FF – 500N)	509
4.	Collective Control System Rigging (L/H Command) (600N)	509
5.	Collective Controls Rigging (R/H Command) (600N)	510
6.	Cyclic Controls Rigging (L/H Command) (369D/E/FF – 500N)	510
7.	Cyclic Controls Rigging (R/H Command) (369D/E/FF – 500N)	513
8.	Cyclic Controls Rigging (L/H Command) (600N)	513
9.	Cyclic Controls Rigging (R/H Command) (600N)	515
10.	Gas Producer Linkage Adjustment	515
	Figure 504. Gas Producer Drive Backlash Adjustment (Outboard Collective Stick)	516
	Figure 505. Gas Producer Drive Backlash Adjustment (Inboard Collective Stick)	517
11.	Pipe Plug Adjustment	518
12.	Gas Producer Interconnecting Torque Tube Assembly Shimming (0003D thru 0929D)	518
	Figure 506. Gas Producer Interconnecting Torque Tube Shimming Procedure (0003D thru 0929D) (Sheet 1 of 2)	519
13.	Collective Stick Friction Mechanism Adjustment	521
	Figure 507. Collective Stick Friction Adjustment	522
14.	Collective Bungee Adjustment	523
15.	Cyclic Trim Actuator Bench Testing (369D/E/FF – 500N)	524

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
16.	Cyclic Trim Actuator Bench Testing (600N)	525
	Figure 508. Cyclic Trim Actuator Assembly	527
	Figure 509. Cyclic Trim Wiring Diagram	528
	Figure 510. Wiring Diagram and Cable Routing (Collective Stick)	529
	Figure 511. Wiring Diagram and Cable Routing (Cyclic Stick)	530
Inspection/Check		601
1.	Tunnel-Routed Control Rod Inspection	601
	Figure 601. Tunnel-Routed Control Rod Inspection	602
2.	Controls Support Bracket and Bellcrank Inspection	603
3.	Pilot's Collective Pitch Stick Inspection	603
4.	Copilot's Collective Pitch Stick Inspection	603
5.	Collective Stick Friction Mechanism Operational Check	603
	Figure 602. Outboard Collective Stick Inspection (L/H Command)	604
	Figure 603. Outboard Collective Stick Inspection (R/H Command)	605
6.	Collective Control Interconnecting Torque Tube Inspection	606
7.	Collective Bungee Inspection	606
8.	Inboard Collective Stick Socket Assembly Inspection	606
9.	Pilot's Cyclic Control Stick Inspection	606
10.	Copilot's Cyclic Control Stick Inspection	607
11.	One-Way Lock Inspection	607
12.	Cyclic Trim Actuator Inspection	607
13.	Cyclic Control System Operational Check	607
	Figure 604. Cyclic Stick and Friction Inspection	608
14.	Main Rotor Flight Control System 600-Hour Inspection	609
Repairs		801
1.	Tunnel-Routed Control Rod Repair	801
2.	Tunnel-Routed Control Tube Inspection and Sleeve Installation	801
	A. Control Tube End Sleeve Installation	801
	Figure 801. Sleeve Fabrication and Installation	802
	Table 801. Control Tube Re-Identification	803
	B. Control Tube Straight Area Sleeve Installation	804
	Table 802. Control Tube Straight Area Repair Limits	804
3.	Controls Support Bracket and Bellcrank Disassembly	805
4.	Controls Support Bracket and Bellcrank Repair	805
5.	Controls Support Bracket and Bellcrank Reassembly	805
6.	Pilot's Collective Pitch Stick Disassembly (L/H Command)	805
	Figure 802. Control Tube Boot Rework	806

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
7.	Pilot's Collective Pitch Stick Repair (L/H Command)	806
8.	Pilot's Collective Pitch Stick Reassembly (L/H Command)	807
9.	Pilot's Collective Pitch Stick Disassembly (R/H Command)	808
10.	Pilot's Collective Pitch Stick Reassembly (R/H Command)	808
11.	Copilot's Collective Pitch Stick Disassembly (L/H and R/H Command)	809
12.	Copilot's Collective Pitch Stick Repair	809
13.	Copilot's Collective Pitch Stick Reassembly	809
14.	Collective Control Interconnecting Torque Tube Repair	810
15.	Collective Bungee Disassembly	811
16.	Collective Bungee Reassembly	811
17.	Inboard Collective Stick Socket Assembly Disassembly	811
18.	Inboard Collective Stick Socket Assembly Repair	812
19.	Inboard Collective Stick Socket Assembly Reassembly	812
20.	Cyclic Control Stick Repair	813
21.	Cyclic Friction Mechanism Repair	813
22.	Lateral Control Rods and Sta. 67 Bellcrank Repair	813
23.	Cyclic Pitch Interconnecting Torque Tube Repair	814
24.	One-Way Lock Repair	814
25.	Cyclic Trim Actuator Spring Assembly Replacement	814
26.	Cyclic Trim Actuator Housing or Trim Tube Replacement	815
27.	Cyclic Trim Actuator (Motor/Gear Drive Mechanism) Replacement	815
28.	Cyclic Trim Actuator Rework (Calco P/N 8222M6 and 8222M7)	815
67-10-20	Collective and Cyclic Stick Grips (369D/E/FF - 500/600N)	A
	Maintenance Practices	201
1.	Collective Pitch Stick Switches	201
2.	Collective Pitch Stick Switches Replacement	201
3.	Cyclic Stick Grip Switches	201
4.	Cyclic Control Stick Grip Replacement	201
A.	Cyclic Control Stick Grip Removal	201
B.	Cyclic Control Stick Grip Installation	201
	Figure 201. Collective Pitch Stick Switch Replacement	202
	Figure 202. Cyclic Stick Grips	203
	Figure 203. Cyclic Stick Grip Disassembly (Sheet 1 of 2)	204

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
5.	Cyclic Stick Grip Switch Replacement (Standard Grip)	206
6.	Cyclic Stick Grip Disassembly (Optional T-Grip, PN 369D297846 Only)	207
7.	Cyclic Stick Grip Reassembly and Modification	207
	Figure 204. Rework of Cyclic Stick Grip	208
67-20-10	Anti-Torque Flight Controls (Two and Four Blade) (369D/E/FF)	A
	Description and Operation	1
1.	Tail Rotor Control Configuration	1
2.	Upper Fuselage and Tailboom Control Linkage	1
	Figure 101. Tail Rotor and Control System	2
	Removal/Installation	401
1.	Sta. 120 Control Rod or Sta. 142 Bellcrank Replacement	401
	A. Sta. 120 Control Rod or Sta. 142 Bellcrank Removal	401
	B. Sta. 120 Control Rod or Sta. 142 Bellcrank Installation	401
	Figure 401. Upper Fuselage and Boom Tail Rotor Control Linkage	402
2.	Sta. 284 Bellcrank Replacement	403
	A. Sta. 284 Bellcrank Removal	403
	B. Sta. 284 Bellcrank Installation	403
3.	Tailboom Control Rod Replacement	403
	A. Tailboom Control Rod Removal	403
	B. Tailboom Control Rod Installation	403
4.	Sta. 95 Bellcrank and Support Replacement	403
	A. Sta. 95 Bellcrank and Support Removal	403
	Figure 402. Tail Rotor Pedal Installation (Sheet 1 of 2)	404
	B. Sta. 95 Bellcrank and Support Installation	405
	C. Tail Rotor Pedal Assembly - General	405
	D. Co-Pilot's Pedal Installation	406
5.	Tail Rotor Pedal Assembly Replacement	406
	A. Tail Rotor Pedal Assembly Removal	406
	B. Tail Rotor Pedal Assembly Installation	406
6.	Dual Tail Rotor Pedal Initial Installation	407
	Adjustment/Test	501
1.	Tail Rotor Controls Rigging	501
	Figure 501. Rigging - Tail Rotor Control System	502
2.	Tail Rotor Bungee Adjustment	503
	Figure 502. Tail Rotor Bungee Adjustment	504

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
Inspection/Check		601
1.	Upper Fuselage and Tailboom Control Linkage Inspection	601
2.	Tail Rotor Pedal Assembly Inspection	601
	Table 601. Isolating Control System Troubles	602
Repairs		801
1.	Floor- and Tunnel-Routed Control Rods	801
2.	Floor-Routed Tail Rotor Control Rod Repair	801
3.	Upper Fuselage and Tailboom Control Linkage Repair	801
	Figure 801. Rework of Sta. 142 Bellcrank Assembly	803
4.	Station 78.50 Tail Rotor (Tunnel-Routed) Control Rod	803
	A. Tail Rotor Idler Bellcrank	803
5.	Tail Rotor Pedal Disassembly	803
6.	Tail Rotor Pedal Repair	803
7.	Tail Rotor Pedal Reassembly	804
8.	Tail Rotor Bungee Spring Forward Attachment Relocation	804
	Figure 802. Relocation of Tail Rotor Bungee Spring Forward Attachment	805
67-20-30 NOTAR® Anti-Torque System Flight Controls (500/600N)		A
Description and Operation		1
1.	NOTAR Anti-Torque System Control Linkages Configuration and Description	1
2.	Stability Augmentation System Description and Operation	1
3.	500NM7301 YSAS Fin Position Indicator (U.K. Only)	2
	Table 1. 500NM7301 YSAS Fin Position Indicator Components	2
Removal/installation		401
1.	Anti-Torque Flight Controls	401
2.	Upper Fuselage Sta. 97.50 (500N) or Sta. 95 (600N) Bellcrank and Support Bracket Replacement	401
	A. Sta. 97.50 (500N) or Sta. 95 (600N) Bellcrank and Support Bracket Removal	401
	B. Sta. 97.50 (500N) or Sta. 95 (600N) Bellcrank and Support Bracket Installation	401
3.	Forward Directional Control Tube Replacement	401
	A. Forward Directional Control Tube Removal	401
	B. Forward Directional Control Tube Installation	401

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
4.	Splitter Bungee Spring Replacement (500N)	401
A.	Splitter Bungee Spring Removal	402
B.	Splitter Bungee Spring Installation	402
5.	Upper Fuselage Station 113.00 Splitter Assembly and Bellcrank Replacement ..	402
A.	Station 113.00 Splitter Assembly and Bellcrank Removal	402
B.	Station 113.00 Splitter Assembly and Bellcrank Installation	402
6.	Intermediate Control Tube Replacement	402
A.	Intermediate Control Tube Removal	402
	Figure 401. Anti-Torque Control System	403
B.	Intermediate Control Tube Installation	404
7.	Station 137.50 Support Bracket and Bellcrank Replacement	404
A.	Station 137.50 Support Bracket and Bellcrank Removal	404
B.	Station 137.50 Support Bracket and Bellcrank Installation	404
8.	Fan Pitch Control Tube Replacement	405
A.	Fan Pitch Control Tube Removal	405
B.	Fan Pitch Control Tube Installation	405
9.	Forward Cable Assembly Replacement	406
A.	Forward Cable Assembly Removal	406
	Figure 402. Upper Fuselage and Boom Control Linkage (Sheet 1 of 2)	407
B.	Forward Cable Assembly Installation	409
10.	Center Cable Assembly Replacement	409
A.	Center Cable Assembly Removal	409
B.	Center Cable Assembly Installation	410
11.	Aft Control Rod Assembly Replacement	410
A.	Aft Control Rod Assembly Removal	410
B.	Aft Control Rod Assembly Installation	410
12.	Sector Assembly and Control Cable Replacement	411
A.	Sector Assembly and Control Cable Removal	411
B.	Sector Assembly and Control Cable Installation	411
13.	Drum Assembly and Idler Pulley Replacement	411
A.	Drum Assembly and Idler Pulley Removal	411
B.	Drum Assembly and Idler Pulley Installation (500N)	412
C.	Drum Assembly and Idler Pulley Installation (600N)	412

TABLE OF CONTENTS (Cont.)


Para/Figure/Table	Title	Page
14.	Anti-Torque Pedal Friction Replacement	412
A.	Anti-Torque Pedal Friction Removal	412
B.	Anti-Torque Pedal Friction Installation	412
15.	Anti-Torque Pedal Assembly Replacement	412
A.	Anti-Torque Pedal Assembly Removal	412
	Figure 403. Pedal Installation (Sheet 1 of 2)	413
B.	Anti-Torque Pedal Assembly Installation	414
16.	Stability Augmentation System (S.A.S.) Actuator Replacement	415
A.	S.A.S. Actuator Removal	415
B.	S.A.S. Actuator Installation	415
17.	S.A.S. Rate Gyro and Electronic Control Box (Computer) Replacement	415
A.	S.A.S. Rate Gyro and Electronic Control Box (Computer) Removal	416
B.	S.A.S. Rate Gyro and Electronic Control Box (Computer) Installation	416
Adjustment/Test		501
1.	Directional Controls Rigging	501
2.	Fan Pitch Control Rigging	501
	Figure 501. Fan Pitch Control Rigging	502
3.	Pilot Pedal Rigging	503
	Figure 502. Pilot Pedal Rigging	504
4.	Anti-Torque Pedal Friction Installation and Adjustment	505
5.	Thruster Control Rigging (500N)	505
	Figure 503. Thruster Control Rigging (Sheet 1 of 2)	506
6.	Thruster Control Rigging (600N)	508
7.	Left Vertical Stabilizer Assembly Rigging (500N, and 600N with YSAS)	508
8.	Stability Augmentation System Rigging Instructions (500N, and 600N with YSAS)	509
9.	Vertical Stabilizer Assembly Rigging (600N without YSAS System)	509
	Figure 504. Left Vertical Stabilizer Rigging (500N, and 600N with YSAS)	510
	Figure 505. Stability Augmentation System S.A.S. (Sheet 1 of 2)	511
	Figure 506. Vertical Stabilizer Rigging (600N without YSAS)	513

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
10.	Vertical Stabilizer Trim Tab Adjustment and Tool Manufacturing (600N without YSAS)	514
A.	Trim Tab Tool Manufacturing	514
B.	Trim Tab Adjustment	514
	Figure 507. Vertical Stabilizer Trim Tab Bending Tool	515
	Table 501. Flight Controls Troubleshooting	516
Inspection/Check		601
1.	Upper Fuselage and Tailboom Control Linkage Inspection	601
2.	Anti-Torque Pedal Assembly Inspection	601
3.	Sta. 97.50 (500N) or Sta. 95 (600N) Bellcrank and Support Bracket Inspection ..	601
4.	Forward and Intermediate Directional Control Tube, and Link Inspection	601
5.	Splitter Bungee Spring Inspection (500N)	602
6.	Sta. 113.00 Splitter Assembly and Bellcrank Inspection	602
7.	Forward and Center Cable Assembly Inspection	602
8.	YSAS Actuator, Rate Gyro and Electronic Control Box Inspection	602
9.	Fan Pitch Control Tube Inspection	602
	Table 601. Isolating Control System Troubles	603
	Figure 601. Control Cable Coupling Inspection	603
	Figure 602. Forward and Center Cable Relief Area Inspection	604
	Figure 603. Control Cable Telescopic Swivel End Inspection	605
10.	Sector Assembly, Control Cables and Drum Assembly Inspection	606
Repairs		801
1.	Anti-Torque Flight Control Repair - General	801
2.	Sta. 97.50 (500N) or Sta. 95 (600N) Bellcrank and Support Bracket Repair	801
3.	Forward Directional Control Tube Repair	801
4.	Upper Fuselage Sta. 113.00 Splitter Assembly Repair	801
5.	Intermediate Control Tube Repair	801
6.	Sta. 137.50 Support Bracket and Bellcrank Repair	802
7.	Fan Pitch Control Tube Repair	802
8.	Forward Cable Assembly Repair	802
9.	Center Cable Assembly Repair	802

TABLE OF CONTENTS (Cont.)

Para/Figure/Table	Title	Page
10.	Aft Control Rod Repair	802
11.	Thruster Sector Assembly Repair	802
12.	Drum Assembly and Idler Pulleys Repair	802
13.	Anti-Torque Pedal Disassembly	802
14.	Anti-Torque Pedal Repair	803
15.	Anti-Torque Pedal Reassembly	803
16.	YSAS Actuator Regrease Procedure	804
A.	YSAS Actuator Disassembly	804
B.	YSAS Actuator Regrease and Reassembly	805
Figure 801.	YSAS Actuator (Cross-Section View)	806



500N

G67-2016-1C

Figure 101. YSAS Electrical Diagram (Sheet 1 of 2)






Figure 101. YSAS Electrical Diagram (Sheet 2 of 2)



G67-1012-2

Figure 501. Main Rotor Control System Rigging (369D/E/FF - 500N) (Sheet 2 of 3)



G67-1012-3E

Figure 501. Main Rotor Control System Rigging (369D/E/FF - 500N) (Sheet 3 of 3)

- (2). Remove bellcrank from pedal bracket.
- (3). Remove nut and washer of two bushing assemblies that secure left pedal arm and control rod fitting to torque tube.
- (4). Carefully remove bushing bolt and temporarily reinstall washer and nut on bolt.
- (5). Slide pedal bracket and pedal arms off end of torque tube.

NOTE:

- Do not remove two teflon-lined bushings from right pedal arm unless replacement is required.
 - Do not remove two stop bolts, jam nuts on stop bolts or bearings from pedal bracket unless replacement is required.
- (6). Slide torque tube bracket and control rod fitting off torque tube.

14. Anti-Torque Pedal Repair

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM425	Sealing compound
CM431	Sealing, locking and retaining compound

- (1). Replace parts that are cracked or have elongated attachment holes.

CAUTION Do not attempt to straighten bent torque tube or pedal link.

- (2). Replace unserviceable pedal covers. Apply sealing compound (CM425) to approximately 30 percent of upper and lower edge surfaces that contact pedal. Cure according to container instructions.
- (3). Replace complete pedal link if cracked or contains unserviceable bearings; bearings are not replaceable.
- (4). Replace unserviceable bearings in mounting brackets or pedal link bellcrank.
- (5). Install replacement with grade A locking compound (CM431).

CAUTION Right pedal arm bushings are glass-filled phenolic. Do not cock bushings during replacement; ensure bushing is fully seated in arm bore. Keep tools from contact with bushing liners to avoid fraying.

- (6). Replace bearings in right pedal arm when teflon-reinforced liner is galled or frayed. Pull bushing to remove; press to install.
- (7). Remove corrosion from pedal brackets (Ref. Sec. 20-40-00 and CSP-A-3, Corrosion Control Manual).

15. Anti-Torque Pedal Reassembly

(Ref. Figure 403)

- (1). When reassembling components, check for correct matchmark identification.
- (2). If previously removed, thread jamnut on each of two stop bolts and install two stop bolts into threaded inserts of pedal brackets.
- (3). Slide torque tube bracket and control rod fitting onto torque tube.
- (4). Locate pedal bracket and pedal arms for correct position on torque tube; slide bracket and arms onto torque tube.
- (5). Fasten left pedal arm and control rod fitting to torque tube with adjustable bushing assemblies.
- (6). Install bushing bolt so shank at bolt-head end protrudes at least 0.002 inch (0.051 mm).
- (7). Torque nut to **50 - 80 inch-pounds (5.65 - 9.04 Nm) plus drag torque**; do not allow bolt to turn.
- (8). Ensure each end of bushing assembly shank protrudes a minimum of 0.002 inch (0.051 mm). If not, loosen and repeat above steps.
- (9). Ensure slotted bushing is in place; then attach bellcrank to pedal bracket with bolt, two washers, nut and cotter pin.
- (10). Ensure slotted bushings are in place; then fasten each link to bellcrank with bolt, two washers, nut and cotter pin.

- (11). Ensure slotted bushings are in place; then fasten each link in pedal arm lugs with bolt, two washers, nut and cotter pin.
- (12). Ensure outboard pedals clear windows by a minimum of 0.20 inch (5.08 mm) with 20 pounds (9.07 kg) of force applied.

16. YSAS Actuator Regrease Procedure

A. YSAS Actuator Disassembly

(Ref. Figure 801)

CAUTION Do not attempt to loosen or tighten nut by grasping actuator housing, damage to spline housing can occur.

- (1). Cut and remove lockwire from lockwasher and nut.
- (2). Hold hex end of output shaft and loosen nut.
- (3). Remove rod end, nut and lockwasher.
- (4). Record output shaft orientation by marking the notch on the connector side of the shaft with a pencil.
- (5). Measure endplay of the actuator as follows:
 - (a). Push the output shaft in towards the actuator housing by applying a load of 20 -100 lbs (9.07 - 45.36 kg).
 - (b). Using a depth gage, measure and record dimension "C".
 - (c). Screw the rod end into the output shaft a few turns.
 - (d). Pull on the output shaft by applying a load of 20 -100 lbs (9.07 - 45.36 kg).
 - (e). Unscrew and remove the rod end without changing dimension "C".

NOTE: If the variation in dimension "C" exceeds 0.013 inch (0.3302 mm), the actuator should be returned to the manufacturer for repair rather than regrease.

- (f). Remeasure and record dimension "C".

- (6). Cut lockwire and remove the four screws that hold the seal housing and splined housing.

NOTE: It may be necessary to grasp the cylindrical portion of the seal housing or splined housing with a rubber-tipped clamping tool to loosen the housing because of primer applied to the screws at assembly.

- (7). If there is an inspection seal at the housing joint, remove enough of the label so that it cannot get pinched between the housings when the actuator is re-assembled. Leave some of the label on the actuator to aid in re-assembly. If there is no inspection seal, use pieces of tape.

NOTE: Belleville spring, spacer and shims (if installed) are installed between the seal housing and splined housing.

- (8). Remove seal housing and splined housing.
- (9). Note the order of assembly of these parts.
- (10). Measure and record the thickness of the spacer and the total thickness of the shims (if installed) to avoid confusion with the spacer and shims on the other side of the splined housing.

NOTE: The teflon washer attached to the end of the LVDT core is a close fit to the bore through the LVDT housing, it may be necessary to carefully tug a little to fully remove the shaft.

- (11). Unscrew and remove the output shaft. This shaft has the LVDT core and associated hardware attached to it; Do not unscrew the nylon screw or the LVDT core.
- (12). Note the orientation of the belleville spring, spacer and shims (if installed). Measure and record the thickness of the spacer and shims.

CAUTION Do not use any cleaning solvents. Damage to the motor bearings and the molybdenum disulfide finish on the acme nut and spline surfaces may occur.

- (13). Wipe off old grease from all parts using lint-free cloth.
- (14). Using cotton swabs, remove grease from acme nut area. Be sure to reach into the cavity just beyond the acme nut threads to remove grease deposits.
- (15). Use the acme screw to remove grease from the acme nut threads.
 - (a). Run screw in and out, then wipe threads clean.
 - (b). Repeat above step until no more grease appears on screw threads.

B. YSAS Actuator Regrease and Reassembly

(Ref. Figure 801)

Consumable Materials (Ref. Section 91-00-00)	
Item	Nomenclature
CM109	Molybdenum disulfide powder lubricant
CM111	Grease, aircraft
CM127	Grease, YSAS Actuator
CM318	Primer
CM731	Lockwire CRES

NOTE: Use YSAS actuator grease (CM127) or mix aircraft grease (CM111) and molybdenum disulfide powder (CM109) to regrease the actuator.


- (1). Prior to applying new grease, re-assemble the output shaft with attached hardware (splined housing, belleville spring, spacer and shims (if installed)) to the actuator to avoid confusion at re-assembly.
- (2). Remove and weigh output shaft with LVDT core and associated hardware attached; Record weight.
- (3). Adjust scale up 2.5 grams.

NOTE: If you mix grease, only use Mobil Grease 28 which meets MIL-G-81322.

- (4). If necessary, mix 95% aircraft grease (CM111) with 5% molybdenum disulfide powder (CM109) by weight.
- (5). Apply special grease (CM127) to acme screw threads until scale is balanced again.
- (6). Evenly distribute grease around the acme screw threads to form a fairly even cylinder in order to fit through the belleville spring without scraping off too much grease.
- (7). With belleville spring, spacer and shims (if installed) in place within end bore in motor housing, carefully assemble greased output shaft to actuator.
 - (a). Screw in the shaft until the leading edge of the spline on the shaft is about flush with the end of the motor housing and oriented so that the splined housing can be put on in it's proper orientation.
- (8). Apply grease (CM127) to splined surfaces of splined housing until grooves are completely full. Install splined housing as originally oriented.
- (9). Apply film of grease (CM127) to smallest inside diameter of seal housing.
- (10). With belleville spring, spacer and shims (if installed) in place within end bore of seal housing, slide seal housing into position over output shaft as originally oriented.
- (11). Replace four screws which hold down seal housing; Use only NAS1352-04H8P screws.
 - (a). Install screws with wet primer (CM318).
 - (b). Torque screws to **9 inch-pounds (1.02 Nm)**.
 - (c). Using lockwire (CM731), safety screws.


(12). Re-install rod end, nut and lockwasher with rod end face (surface "A") oriented at $90^\circ \pm 2^\circ$ with respect to surface "B". Torque nut to **170 - 200 inch-pounds (19.21 - 22.60 Nm)**.

(13). Using lockwire (CM731), safety nut to lockwasher, washer may be oriented with lockwire end up or down.



G67-2021

Figure 801. YSAS Actuator (Cross-Section View)



G76-1006C

Figure 207. Power Turbine Governor Adjustments (250-C30 Engine)

8. Governor Controls Final Check and Adjustment (250-C20B, -C20R/2)

- (1). Have an assistant move collective through full range of travel while inspecting all movable linkage for clearance with adjacent parts. Check that control rod, N₂ actuator and override link bearings are not jammed when linkage is at extreme control positions.
- (2). Start and operate engine at idle with main rotor blades in flat pitch per Pilot's Flight Manual.
- (3). Decrease N₂ trim to minimum.
- (4). Throttle up to maximum rpm.
- (5). Observe N₂ tachometer pointer for (98% or less rpm: 369D/E) (94% or less: 500N) when rotor rpm pointer is superimposed on N₂ pointer and N₁ tachometer pointer is stabilized.
- (6). Check for the following engine power out (EPO) indications:
 - (a). Engine-out flashing light.
 - (b). Audio signal in headset.
 - (c). Horn; sounds when N₂ pointer on dual indicator is stable.
- (7). With collective stick down, increase N₂ trim to (104% to 105% rpm: 369D/E) (103% to 104% rpm: 500N). Observe N₂ tachometer pointer when rotor rpm pointer is superimposed on N₂ pointer and N₁ tachometer pointer is stabilized.
- (8). Without decreasing N₂ trim, rotate pilot's throttle to ground idle.

NOTE: Perform a deceleration time check per PFM after rigging and testing power turbine controls. Refer to Allison Operation and Maintenance Manual for adjustment procedures if deceleration time is less than allowable minimum.

- (9). Shut down engine per Pilot's Flight Manual.

WARNING

Make all engine compartment control rod adjustments with engine shut down.

- (10). Mark N₂ lever position on governor quadrant.
- (11). Connect external electric power.
- (12). With collective at bottom stop, beep N₂ trim to maximum rpm.
- (13). Adjust governor lever control rod (105% N₂ maximum: 369D/E) (104% N₂ maximum: 500N).
- (14). Start engine. With main rotor blades in flat pitch, beep N₂ trim to (102% rpm: 369D/E) (100% rpm: 500N). Lift off and hover.
- (15). Observe N₂ tachometer pointer when pointer of N₁ tachometer is stabilized. N₂ pointer indication, that is, droop compensation, should be (1/2% to 1% rpm: 369 D/E) (1% to 2% rpm: 500N) above indication in previous step.
- (16). Land and shut down engine.
- (17). If droop compensation occurred as required, no further adjustments are required.
- (18). If droop compensation did not occur per step (15)., check and re-rig power turbine and gas producer linkage systems as required.
- (19). Where N₁ and N₂ linkage are correctly adjusted, additional adjustment may be made to droop compensation adjustment fork; as follows:

NOTE: Three to five turns of droop compensation fork may be necessary to change droop compensation approximately 0.5% rpm.

- (a). Shorten droop compensation adjustment fork to increase compensation.
- (b). Lengthen fork extension to decrease compensation.
- (c). Align fork with override link rod-end before tightening fork jamnut.
- (20). Move collective through full travel after adjustment and check for clearance

between movable linkage and adjacent parts.

- (21). When full power is demanded in flight and high N_1 and TOT operating range cannot be reached, gas producer fuel control maximum throttle stop may require adjustment. Refer to Allison Operation and Maintenance Manual for adjustment procedure.

9. Governor Controls Final Check and Adjustment (250-C30)

- (1). Have an assistant move collective through full range of travel while inspecting all movable linkage for clearance with adjacent parts. Check that control rod, N_2 actuator and override link bearings are not jammed when linkage is at extreme control positions.
- (2). Start and operate engine at idle with main rotor blades in flat pitch per Pilot's Flight Manual.
- (3). Rotate pilots throttle counterclockwise up to maximum rpm.
- (4). Decrease N_2 trim to minimum.
- (5). Observe N_2 tachometer pointer for 94% or less rpm and N_1 tachometer is stabilized.
- (6). With collective stick down, increase N_2 trim to maximum.
- (7). Observe N_2 tachometer pointer for 103% to 104% rpm and N_1 tachometer pointer is stabilized.

WARNING Make all engine compartment control rod adjustments with engine shut down.

- (8). Stop engine. Adjust length of governor control lever rod until N_2 trim is within limits specified in steps (5). and (7). above. Adjust one rod end not more than one turn at a time.

- (9). Restart engine. With main rotor blades in flat pitch, actuate N_2 trim for 100 percent, lift-off and hover.

- (10). Observe N_2 tachometer pointer when pointer of N_1 tachometer is stabilized. N_2 pointer indication (droop compensation) should be 1 to 2 percent above N_2 setting in step (9).

- (11). Land and shut down engine.

NOTE: If droop compensation occurs as required in (10). above, skip steps (12). and (13). below.

- (12). If droop compensation does not occur as required in step (10). above, recheck entire power turbine governor (N_2 RPM) control linkage rigging and gas producer (N_1 fuel control) linkage adjustment.

CAUTION Any change to initial droop compensation fork length may result in interference between N_2 trim actuator case and fork threaded end. Move collective through full travel after adjustment and check for clearance between movable linkage and adjacent parts.

- (13). If N_1 and N_2 linkage are correctly installed, an additional adjustment may be made at droop compensation adjustment fork. Shorten droop compensation adjustment fork to increase compensation. Lengthen fork extension to decrease compensation. Align fork with override link rod end before tightening fork jam nut. Three to five turns of droop compensation fork may be necessary to change droop compensation fork approximately 0.5 percent.

NOTE: Perform a deceleration time check per PFM after rigging and testing power turbine controls. Refer to Allison Operation and Maintenance Manual for adjustment procedures if deceleration time is less than allowable minimum.

10. Governor Controls Replacement

(Ref. Figure 208)

- (1). Remove and replace control rods, bellcranks and supports as required, except as follows:

WARNING Only high temperature all metal self-locking nuts are to be used for attaching control idler support to engine gearcase accessory pad.

NOTE: Remove droop control override link, N₂ trim actuator, and Sta. 72.00 bellcrank from airframe as a unit.

- (2). Leave Sta. 72.00 bellcrank attached to N₂ trim actuator and remove as a unit.
- (3). Disconnect the bonding jumper and electrical connector from the actuator.
- (4). Disconnect the actuator from Sta. 68 bellcrank.
- (5). Disconnect Sta. 72 bellcrank from the fuselage-routed control rod end.
- (6). Remove the pivot bolt that attaches Sta. 72 bellcrank to structure rib and controls support bracket; remove actuator and bellcrank.
- (7). Disconnect the trim actuator from Sta. 72 bellcrank. Use care to keep sleeve bushings with bellcrank.
- (8). Check replacement actuator for a maximum extended length of 5.44–5.50 inches (13.82–13.97 cm) measured between bolt hole centers. Test actuator for proper operation (Ref. N₂ Trim Actuator Test).
- (9). Assemble original or replacement trim actuator to original or replacement Sta. 72 bellcrank with a bolt, two washers, nut and new cotter pin.
- (10). Check that both sleeve bushings are in place in Sta. 68 bellcrank arm before connecting the actuator; then install assembled unit in controls support bracket and connect linkage as shown in Figure 208.
- (11). The sleeve bushings in Sta. 68 bellcrank arm must rotate freely, without any binding, after the actuator is attached and the connecting hardware is tightened.
- (12). Connect replacement droop control override link to collective torque tube.
- (13). Push on rod end and check that the link assembly plunger head is free to slide back and forth in the link housing end fitting.
- (14). Connect rod end to droop compensation fork; the rod end should align with the fork.
- (15). Connect the bonding jumper and electrical connector to the actuator.

NOTE: Replacement trim actuator may have a tab or use a bonding strap/clamp for connection of the bonding jumper.

- (16). Rig power turbine governor controls if any linkage components have been removed and replaced.

NOTE: Perform a deceleration time check per PFM after rigging and testing power turbine controls. Refer to Allison Operation and Maintenance Manual for adjustment procedures if deceleration time is less than allowable minimum.

11. Control Rod Inspection

(Ref. Figure 208)

- (1). Inspect rod end bearings for binding and excessive wear, 0.040 inch (1.013 mm) maximum axial play).
- (2). Inspect control rod for surface damage and evidence of bending.
- (3). When necessary, perform straightness check on control rods that appear bent or bowed. Total length of gas producer control rods (excluding rod ends) must be straight within the following tolerances, with straightness variation limited to maximum of 0.010 inch (0.254 mm) in each foot of length.
 - (a). Fuselage-routed control rods: 0.050 inch (1.27 mm).

Table 3. Special Tools (Cont.)

Item No.	Part No.	Nomenclature	Function	Vendor (Table 4)
ST508	369D29936 369A7300-ATP-1	Collective bungee installation tool (369D/E/FF - 500N) (600N)	Remove bungee installation tool. Dismantle bungee assembly.	
ST509	Not used at this time			
ST510	369D29985	Bungee spring compression tool rod and channel (369D/E/FF - 500N)	Compress collective bungee.	
ST511	369D29910-32501	Test fixture	Shop aid for rigging main rotor controls.	
Anti-Torque				
ST601	500N9901-3	Rigging pin	Rigging of NOTAR® anti-torque flight controls.	
ST602	830006-809-00653	Spring tension removal tool	Removal of anti-torque bungee spring & splitter spring.	
ST603	ATP1-500N5365-1-TD	Tip seal cutting fixture	Anti-torque tip seal felt metal cutting tool.	
ST604	500N9505-1	Coupling socket	Fan & gearbox coupling socket.	
ST605	500N9506-1	Fan nut socket	Anti-torque fan removal.	
ST606	369D29931 369D29907	T/R swashplate rigging tool (2-bladed tail rotor) (4-bladed tail rotor)	Rig tail rotor controls.	
ST607	369D29823 369D29826	Adapter, torque wrench (2-bladed tail rotor) (4-bladed tail rotor)	Install tail rotor nut.	
ST608	369D29822-3	Pitch control assembly holding block	Secure tail rotor swashplate block to remove/install nut.	
ST609	369D29822-5	Adapter, torque wrench	Remove/install tail rotor swashplate housing bearing nut.	
ST610	369A1600-80902	Bushing wrench	Install and torque tail rotor hub threaded bushing.	
ST611	83006-809-00090-1	Arbor press fixture, 369A7951-5 bearing	Install tail rotor pitch control link bearings.	
ST612	83006-809-00090-15	Staking tool, 369A7951-5 bearing	Stake tail rotor pitch control link bearings.	
ST613	269A9232	Plug, bearing removal	Remove tail rotor pitch control housing bearings.	
ST614	500N5364-ATP1	Regreasing tool, fan bearing	Regreasing of the 500N5364 and 500N7120 fan bearings.	

Table 3. Special Tools (Cont.)

Item No.	Part No.	Nomenclature	Function	Vendor (Table 4)
Main Rotor				
ST701	369A9829	Main rotor wrench assembly	Loosening/torquing of main rotor mast nut.	
ST702	369D29932 600N9932	Hub puller (369D/E/FF - 500N) (600N)	Separate main rotor hub from mast.	
ST703	369A9933 *369A9933-5	Main rotor hub driver	Seat main rotor hub.	
ST704	369D29957 old FRDH101 new	Adapter, torque wrench	Install main rotor drive shaft fasteners.	
ST705	369A9825	Pitch bearing stud wrench	Remove main rotor hub pitch bearing pivot pin.	
ST706	83006-809-00090 -1	Arbor press fixture (369A7951-5 bearing)	Install main rotor pitch housing bearings.	
ST707	83006-809-00090 -15	Staking tool (369A7951-5 bearing)	Staking main rotor pitch housing bearings.	
ST708	83006-809-00088	Staking tool (pilot and punch) (369A7951-45 bearing)	Install pitch control housing bearings and swage rings.	
ST709	3006-809-00090 -1/-8	Arbor press fixture (369A7951-15 bearing)	Install main rotor blade bearings.	
ST710	3006-809-00090 -15/-20	Staking tool (369A7951-15 bearing)	Stake main rotor blade bearings.	
Fuel				
ST801	MITYVACR #4000	Hand operated vacuum pump kit	Pump down airframe and engine fuel systems for vacuum leak check.	TS13
ST801-1	AN840-D	Nipple, hose	Vacuum pump adaptive hardware.	
ST801-2	AN910-1D	Coupling		
ST801-3	AN816-4D	Nipple		
ST801-4	AS3084-04	O-ring		
ST802	369A8100-80902	Spanner wrench	Fuel cross-over fitting torquing.	
Track and Balance				
ST901	369D29942	Tip cap assembly	Tracking main rotor blades.	
ST902	369H9928	Main rotor blade fixture and tab bending tool	Adjusting main rotor blade tab angle/blade track.	
ST903		Balancer/analyzer instrument kit	Track and balance of dynamic components.	TS5