

# HANSEN HELICOPTERS

## STRAIGHT IN—POWER ON

### AUTOROTATION

1000' AGL, 70-80 kts — LZ is around chin bubble upper frame, Smoothly lower collective to full down position and close throttle to idle detent. Establish autorotative glide at 70 kts.

200' AGL - **Throttle Full On** with **No Hesitation.**

30' AGL— Moderate flare, add collective as necessary to stop the tail from settling and to reduce forward airspeed.

When airspeed decreases to about 5 kts, immediately go to a level attitude, apply collective as necessary to establish a 3' hover.

*Note: This should be a coordinated maneuver; it is taken for granted that the pilot possesses the skills to apply appropriate pedal when necessary.*

