

**CESSNA AIRCRAFT COMPANY
MODEL 300 SERIES
CONTINUED AIRWORTHINESS PROGRAM**

TITLE **Rudder Torque Tube**

MODEL	EFFECTIVITY	INSPECTION COMPLIANCE	
T303 310 Thru T310R 320 Thru 320F	T30300001 Thru T30300315 607, 35549 Thru 310R2140 623, 658, 320-0001 Thru 320F0045	INITIAL	7500 HRS OR 10 YRS
335 336	335-0001 Thru 335-0065 633, 636, 336-0001 Thru 336-0195	REPEAT	2500 HRS OR 3 YRS Thereafter
337 Thru T337H-SP T337G Thru P337H F337E/FT337F FT337GP/FT337HP 340 Thru 340A	337-0002 Thru 33701955 P3370001 Thru P3370356 F3370001 Thru F33700055 FP33700001 Thru FP33700023 340-0001 Thru 340A1817		

PURPOSE

To ensure structural integrity of rudder torque tube assembly.

INSPECTION INSTRUCTIONS

1. Remove rudder torque tube access plates in accordance with applicable Service Manual.
2. Inspect weld on torque tube for cracks.
3. Inspect torque tube for internal rusting.
4. Install rudder torque tube access plates in accordance with applicable Service Manual.

ACCESS/LOCATION

Rudder

DETECTABLE CRACK SIZE

N/A

INSPECTION PROCEDURE


Visual

REPAIR/MODIFICATION

Repairs may be made in accordance with applicable Cessna Service Manual. Any repair not covered by recommendations in above documents should be coordinated with Cessna Technical Information Service prior to beginning repair.

COMMENTS

**CESSNA AIRCRAFT COMPANY
MODEL 300 SERIES
CONTINUED AIRWORTHINESS PROGRAM**



Rudder Torque Tube
Figure 3-6

51333002