

**CESSNA AIRCRAFT COMPANY
MODEL 300 SERIES
CONTINUED AIRWORTHINESS PROGRAM**

TITLE **Aileron Trim Actuator Structure**

MODEL	EFFECTIVITY	INSPECTION COMPLIANCE
T303 310 Thru T310R 320 Thru 320F	T30300001 Thru T30300315 607, 35000 Thru 310R2140 623, 658, 320-0001 Thru 320F0045	INITIAL 1000 HRS OR 3 YRS
335 336	335-0001 Thru 335-0065 633, 636, 336-0001 Thru 336-0195	REPEAT 1000 HRS OR 3 YRS Thereafter
337 Thru T337H-SP T337G Thru P337H F337E/FT337F FT337GP/FT337HP 340 Thru 340A	337-0002 Thru 33701955 P3370001 Thru P3370356 F3370001 Thru F33700055 FP33700001 Thru FP33700023 340-0001 Thru 340A1817	

PURPOSE

Verify integrity of aileron trim actuator clamps attachment.

INSPECTION INSTRUCTIONS

1. Remove aileron trim actuator in accordance with the applicable Service Manual.
2. Inspect all fasteners and attaching structure for integrity.
3. Inspect actuator mounting structure for corrosion, bent or deformed flanges, cracks, and fasteners integrity.
4. Install aileron trim actuator in accordance with applicable Service Manual.

ACCESS/LOCATION

Wing

DETECTABLE CRACK SIZE

N/A

INSPECTION PROCEDURE

Visual

REPAIR/MODIFICATION

Repairs may be made in accordance with applicable Cessna Service Manual. Any repair not covered by recommendations in above documents should be coordinated with Cessna Technical Information Service prior to beginning repair.

COMMENTS