

**CESSNA AIRCRAFT COMPANY
MODEL 300 SERIES
CONTINUED AIRWORTHINESS PROGRAM**

TITLE Emergency Exit Door Lever Mechanism Inspection

MODEL	EFFECTIVITY	INSPECTION COMPLIANCE	
T303 310 Thru T310R 320 Thru 320F	T30300001 Thru T30300315 607, 35549 Thru 310R2140 623, 658, 320-0001 Thru 320F0045	INITIAL	1000 HRS
335 336	335-0001 Thru 335-0065 633, 636, 336-0001 Thru 336-0195	REPEAT	1000 HRS Thereafter
337 Thru T337H-SP T337G Thru P337H F337E/FT337F FT337GP/FT337HP 340 Thru 340A	337-0002 Thru 33701955 P3370001 Thru P3370356 F3370001 Thru F33700055 FP33700001 Thru FP33700023 340-0001 Thru 340A1817		

PURPOSE

To ensure emergency exit door lever mechanism has not deteriorated and is functioning properly.

INSPECTION INSTRUCTIONS

1. Remove Royalite panels and visually inspect lever for cracks, wear and damage.
2. Visually inspect other lever mechanism parts and components for cracks, wear, damage and deterioration.
3. Check operation of lever mechanism.

ACCESS/LOCATION

Emergency Exit Door

DETECTABLE CRACK SIZE

N/A

INSPECTION PROCEDURE

Visual

REPAIR/MODIFICATION

Replace any worn, cracked, damaged or deteriorated parts with new parts as required.

COMMENTS